



61  
62  
63  
64  
65  
66  
67  
68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86

RTU PANEL  
WIRING DIAGRAM DETAIL

LEGEND:

- X DENOTES A TERMINAL BLOCK POINT
- \* DENOTES ITEM REMOTE FROM CONTROL PANEL
- DENOTES WIRING EXTERNAL TO CONTROL PANEL