

# Brunswick County Public Utilities - NC

PO Box 249  
Bolivia, NC 28422-0249

## Northwest Water Plant

Samples Received: 1/12/2023

Analytical Report  
0123-735

PFAS by Isotope Dilution  
Brunswick PFAS List

Report Issue Date: 1/31/2023

I certify that to the best of my knowledge all analytical data presented in this report have been checked for completeness, accuracy, errors and legibility in addition to having been conducted in accordance with approved protocol, and that all deviations and analytical problems are summarized in the appropriate narrative(s). This analytical report was prepared in Portable Document Format (.PDF) and contains 20 pages. This report shall not be reproduced except in full without approval of the laboratory. This will provide assurance that parts of the report are not taken out of context.

Signature:



Laura Boivin, QA Associate II

Amendments:



Enthalpy Analytical, LLC – Ultratrace  
Mark Hager, Project Manager  
O: 910-876-6894 / F: 910-212-6886  
mark.hager@enthalpy.com / www.enthalpy.com  
2714 Exchange Drive, Wilmington, NC 28405

# Summary of Results

## Enthalpy Analytical

Job No.: 0123-735-1 PFAS by Isotope Dilution (non-potable water)

Brunswick County Public Utilities - NC Client Project: N/A Site: Northwest Water Plant

### Summary

	Compound	CAS	011223-SO1 ng/L	011223-EO1 ng/L	
Acids	PFBA	375-22-4	2.93	3.22	
	PFPeA	2706-90-3	4.96	5.93	
	PFHxA	307-24-4	5.15	5.96	
	PFHpA	375-85-9	2.63	2.70	
	PFOA	335-67-1	4.54	5.09	
	PFNA	375-95-1	0.523 J	0.600	
	PFDA	335-76-2	0.175 J	0.143 L	
	PFUnDA	2058-94-8	ND U	ND U	
	PFDoDA	307-55-1	ND U	ND U	
	PFTTrDA	72629-94-8	ND U	ND U	
	PFTeDA	376-06-7	ND U	ND U	
	Sulfonates	PFBS	375-73-5	4.26	4.57
		PFPeS	2706-91-4	0.424 J	0.397 J
PFHxS		355-46-4	3.45	2.77	
PFHpS		375-92-8	ND U	0.207 L	
PFOS		1763-23-1	7.55	7.74	
PFNS		68259-12-1	ND U	ND U	
PFDS		335-77-3	ND U	ND U	
4:2 FTS		757124-72-4	ND U	ND U	
6:2 FTS		27619-97-2	0.402 JB	0.423 JB	
8:2 FTS		39108-34-4	ND U	ND U	
Other	PFOSA	754-91-6	ND U	ND U	
	N-MeFOSAA	2355-31-9	ND U	ND U	
	N-EtFOSAA	2991-50-6	ND U	ND U	
	HFPO-DA	13252-13-6	1.74	1.64	
	PFMOAA	674-13-5	11.2	9.23	
	PFMOPrA	377-73-1	ND U	ND U	
	PFO2HxA	39492-88-1	2.45	2.12	
	PFO3OA	39492-89-2	0.564	0.383 J	
	PFO4DA	39492-90-5	ND U	ND U	
	Nafion Byproduct 1	29311-67-9	ND U	ND U	
	ADONA	919005-14-4	ND U	ND U	
	9Cl-PF3ONS	756426-58-1	ND U	ND U	
	11Cl-PF3OUdS	763051-92-9	ND U	ND U	
	10:2 FTS	120226-60-0	ND U	ND U	
	EVE Acid	69087-46-3	ND U	ND U	
	FBSA	30334-69-1	0.503 J	0.413 J	
	Hydro-EVE Acid	773804-62-9	ND U	ND U	
	Hydrolyzed PSDA	2416366-19-1	1.33	1.64	
	Nafion Byproduct 2	749836-20-2	ND U	ND U	
	N-EtFOSA	4151-50-2	ND U	ND U	
	N-EtFOSE	1691-99-2	ND U	ND U	
	NFDHA	151772-58-6	ND U	ND U	
	N-MeFOSA	31506-32-8	ND U	ND U	
	N-MeFOSE	24448-09-7	ND U	ND U	
	NVHOS	1132933-86-8	1.73	1.08	
	PEPA	267239-61-2	0.539 J	0.475 J	
	PFECA-G	801212-59-9	ND U	ND U	
	PFEESA	113507-82-7	ND U	ND U	
	PFHxDA	67905-19-5	ND U	ND U	
	PFMOBA	863090-89-5	ND U	ND U	
	PFO5DA	39492-91-6	ND U	ND U	
	PMPA	13140-29-9	2.44	2.11	
	R-EVE	2416366-22-6	1.52	ND U	
	R-PSDA	2416366-18-0	ND U	ND U	
R-PSDCA	241636-21-5	ND U	ND U		

# Detailed Results

### Enthalpy Analytical

Job No.: 0123-735-1 PFAS by Isotope Dilution (non-potable water)

Brunswick County Public Utilities - NC Client Project: N/A Site: Northwest Water Plant

Enthalpy ID	0123-735-001-1	Prep Batch	EU14582	Sample Vol (mL)	285.86
Sample Name	011223-SO1	Prep Date	2023-01-13 11:20	Extract Vol (mL)	0.4
Matrix	AQ	Analysis Date	1/13/2023 6:08:49 PM	Split Factor	N/A
Sampling Date	20230112 08:00	Analyst	bmay	Method Code	WM-026
Received Date	2023-01-12 02:30	Instrument	Pippin	Sample Type	Sample

	Compound	CAS	Extract Concentration ng/L	Sample Concentration ng/L	Formatted Result ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags	
Acids	PFBA	375-22-4	2096.73	2.93	2.93	0.222	0.560				
	PFPeA	2706-90-3	3542.31	4.96	4.96	0.160	0.560				
	PFHxA	307-24-4	3681.46	5.15	5.15	0.187	0.560				
	PFHpA	375-85-9	1881.45	2.63	2.63	0.196	0.560				
	PFOA	335-67-1	3247.03	4.54	4.54	0.128	0.560				
	PFNA	375-95-1	373.69	0.523	0.523	0.126	0.560			J	
	PFDA	335-76-2	125.38	0.175	0.175	0.160	0.560			J	
	PFUnDA	2058-94-8	ND	ND	ND	0.126	0.560			U	
	PFDoDA	307-85-1	ND	ND	ND	0.227	0.560			U	
	PFTriDA	72629-94-8	ND	ND	ND	0.185	0.560			U	
	PFTeDA	376-06-7	ND	ND	ND	0.213	0.560			U	
	Sulfonates	PFBS	375-73-5	3041.79	4.26	4.26	0.297	0.560			
		PFPeS	2706-91-4	303.00	0.424	0.424	0.115	0.527			J
PFHxS		355-46-4	2464.77	3.45	3.45	0.432	0.513				
PFHpS		375-92-8	ND	ND	ND	0.271	0.533			U	
PFOS		1763-23-1	5394.62	7.55	7.55	0.296	0.518				
PFNS		68259-12-1	ND	ND	ND	0.174	0.539			U	
PFDS		335-77-3	ND	ND	ND	0.294	0.539			U	
4:2 FTS		757124-72-4	ND	ND	ND	0.0726	0.524			U	
6:2 FTS		27619-97-2	287.08	0.402	0.402	0.264	0.533			JB	
8:2 FTS		39108-34-4	ND	ND	ND	0.125	0.536			U	
PFOSA		754-91-6	ND	ND	ND	0.0785	0.560			U	
N-MeFOSAA		2355-31-9	ND	ND	ND	0.157	0.560			U	
N-EtFOSAA		2991-50-6	ND	ND	ND	0.227	0.560			U	
Other	HFPO-DA	13252-13-6	1245.66	1.74	1.74	0.0593	0.560				
	PFMOAA	674-13-5	8004.66	11.2	11.2	0.283	0.560				
	PFMOPrA	377-73-1	ND	ND	ND	0.199	0.560			U	
	PFO2HxA	39492-88-1	1751.85	2.45	2.45	0.180	0.560				
	PFO3OA	39492-89-2	403.29	0.564	0.564	0.257	0.560				
	PFO4DA	39492-90-5	ND	ND	ND	0.443	2.80			U	
	Nafion Byproduct 1	29311-67-9	ND	ND	ND	0.299	0.560			U	
	ADONA	919005-14-4	ND	ND	ND	0.152	0.530			U	
	9Cl-PF3ONS	756426-58-1	ND	ND	ND	0.359	0.521			U	
	11Cl-PF3OUds	763051-92-9	ND	ND	ND	0.264	0.527			U	
	10:2 FTS	120226-60-0	ND	ND	ND	0.429	0.560			U	
	EVE Acid	69087-46-3	ND	ND	ND	0.178	1.26			U	
	FBSA	30334-69-1	359.14	0.503	0.503	0.266	0.560			J	
	Hydro-EVE Acid	773804-62-9	ND	ND	ND	0.184	0.560			U	
	Hydrolyzed PSDA	2416366-19-1	951.77	1.33	1.33	0.373	0.560				
	Nafion Byproduct 2	749836-20-2	ND	ND	ND	0.464	0.560			U	
	N-EtFOA	4151-50-2	ND	ND	ND	0.346	0.560			U	
	N-EtFOSE	1691-99-2	ND	ND	ND	0.857	2.52			U	
	NFDHA	151772-58-6	ND	ND	ND	0.118	0.560			U	
	N-MeFOA	31506-32-8	ND	ND	ND	0.231	0.560			U	
	N-MeFOSE	24448-09-7	ND	ND	ND	0.532	2.52			U	
	NVHOS	1132933-86-8	1235.38	1.73	1.73	0.0862	0.560				
	PEPA	267239-61-2	385.06	0.539	0.539	0.105	0.560			J	
	PFECA-G	801212-59-9	ND	ND	ND	0.0747	0.560			U	
	PFEEA	113507-82-7	ND	ND	ND	0.168	0.560			U	
	PFHxDA	67905-19-5	ND	ND	ND	0.297	0.560			U	
	PFMOBA	863090-89-5	ND	ND	ND	0.939	1.26			U	
	PFO5DA	39492-91-6	ND	ND	ND	0.448	2.80			U	
	PMPA	13140-29-9	1746.07	2.44	2.44	0.132	0.560				
	R-EVE	2416366-22-6	1086.83	1.52	1.52	0.929	1.26				
	R-PSDA	2416366-18-0	ND	ND	ND	2.47	2.47			U	
	R-PSDCA	241636-21-5	ND	ND	ND	0.236	0.560			U	
	ES	MFPBA		4609.36	6.45				20-150%	92.2%	
M5PFPeA			5650.09	7.91				20-150%	113.0%		
M3PFBS			5969.21	8.35				20-150%	119.4%		
M2-4:2 FTS			5436.28	7.61				20-150%	108.7%		
M5PFHxA			3731.17	5.22				20-150%	74.6%		
M3HFPO-DA			3701.91	5.18				20-150%	74.0%		
M4PFHpA			3928.76	5.50				20-150%	78.6%		
M3PFHxS			4661.93	6.52				20-150%	93.2%		
M2-6:2 FTS			7724.60	10.8				20-150%	154.5%	Q	
M8PFOA			4868.43	6.81				20-150%	97.4%		
M9PFNA			5091.66	7.12				20-150%	101.8%		
M8PFOS			4424.36	6.19				20-150%	88.5%		
M2-8:2 FTS			5982.11	8.37				20-150%	119.6%		
M8FOSA-I			4737.86	6.63				20-150%	94.8%		
M6PFDA			4567.61	6.39				20-150%	91.4%		
d3-N-MeFOSAA			5754.84	8.05				20-150%	115.1%		
d5-N-EtFOSAA			4720.06	6.60				20-150%	94.4%		
M7PFUDa			4609.00	6.45				20-150%	92.2%		
MPPDoA			3511.32	4.91				20-150%	70.2%		
M2PFTeDA			2990.80	4.18				20-150%	59.8%		
d3-N-MeFOSA			2048.46	2.87				10-200%	20.5%		
d5-N-EtFOA		1669.51	2.34				10-200%	16.7%			
d7-N-MeFOSE		5428.74	7.60				10-200%	54.3%			
d9-N-EtFOSE		4493.25	6.29				10-200%	44.9%			

**Enthalpy Analytical**

Job No.: 0123-735-1 PFAS by Isotope Dilution (non-potable water)  
 Brunswick County Public Utilities - NC Client Project: N/A Site: Northwest Water Plant

Enthalpy ID	0123-735-002-1	Prep Batch	EU14582	Sample Vol (mL)	284.93
Sample Name	011223-EO1	Prep Date	2023-01-13 11:20	Extract Vol (mL)	0.4
Matrix	AQ	Analysis Date	1/13/2023 6:31:28 PM	Split Factor	N/A
Sampling Date	20230112 08:00	Analyst	bmay	Method Code	WM-026
Received Date	2023-01-12 02:30	Instrument	Pippin	Sample Type	Sample

	Compound	CAS	Extract Concentration ng/L	Sample Concentration ng/L	Formatted Result ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags
Acids	PFBA	375-22-4	2291.77	3.22	3.22	0.223	0.562			
	PFPeA	2706-90-3	4223.10	5.93	5.93	0.161	0.562			
	PFHxA	307-24-4	4243.85	5.96	5.96	0.188	0.562			
	PFHpA	375-85-9	1920.76	2.70	2.70	0.197	0.562			
	PFOA	335-67-1	3626.50	5.09	5.09	0.128	0.562			
	PFNA	375-95-1	427.60	0.600	0.600	0.127	0.562			
	PFDA	335-76-2	101.65	0.143	0.143	0.161	0.562			L
	PFUnDA	2058-94-8	ND	ND	ND	0.127	0.562			U
	PFDoDA	307-85-1	ND	ND	ND	0.228	0.562			U
	PFTriDA	72629-94-8	ND	ND	ND	0.186	0.562			U
	PFTeDA	376-06-7	ND	ND	ND	0.214	0.562			U
	Sulfonates	PFBS	375-73-5	3257.94	4.57	4.57	0.298	0.562		
PFPeS		2706-91-4	282.62	0.397	0.397	0.115	0.529			J
PFHxS		355-46-4	1972.47	2.77	2.77	0.433	0.514			
PFHpS		375-92-8	147.44	0.207	0.207	0.272	0.535			L
PFOS		1763-23-1	5514.06	7.74	7.74	0.297	0.520			
PFNS		68259-12-1	ND	ND	ND	0.174	0.541			U
PFDS		335-77-3	ND	ND	ND	0.295	0.541			U
4:2 FTS		757124-72-4	ND	ND	ND	0.0728	0.526			U
6:2 FTS		27619-97-2	301.16	0.423	0.423	0.265	0.535			JB
8:2 FTS		39108-34-4	ND	ND	ND	0.126	0.538			U
PFOSA		754-91-6	ND	ND	ND	0.0788	0.562			U
Other		N-MeFOSAA	2355-31-9	ND	ND	ND	0.158	0.562		
	N-EtFOSAA	2991-50-6	ND	ND	ND	0.228	0.562			U
	HFPO-DA	13252-13-6	1168.81	1.64	1.64	0.0595	0.562			
	PFMOAA	674-13-5	6577.89	9.23	9.23	0.284	0.562			
	PFMOPrA	377-73-1	ND	ND	ND	0.200	0.562			U
	PFO2HxA	39492-88-1	1507.04	2.12	2.12	0.181	0.562			
	PFO3OA	39492-89-2	272.63	0.383	0.383	0.258	0.562			J
	PFO4DA	39492-90-5	ND	ND	ND	0.444	2.81			U
	Nafion Byproduct 1	29311-67-9	ND	ND	ND	0.300	0.562			U
	ADONA	919005-14-4	ND	ND	ND	0.152	0.532			U
	9Cl-PF3ONS	756426-58-1	ND	ND	ND	0.360	0.523			U
	11Cl-PF3OUds	763051-92-9	ND	ND	ND	0.265	0.529			U
	10:2 FTS	120226-60-0	ND	ND	ND	0.430	0.562			U
	EVE Acid	69087-46-3	ND	ND	ND	0.179	1.26			U
	FBSA	30334-69-1	294.38	0.413	0.413	0.267	0.562			J
	Hydro-EVE Acid	773804-62-9	ND	ND	ND	0.184	0.562			U
	Hydrolyzed PSDA	2416366-19-1	1166.42	1.64	1.64	0.374	0.562			
	Nafion Byproduct 2	749836-20-2	ND	ND	ND	0.465	0.562			U
	N-EtFOA	4151-50-2	ND	ND	ND	0.347	0.562			U
	N-EtFOSE	1691-99-2	ND	ND	ND	0.860	2.53			U
	NFDHA	151772-58-6	ND	ND	ND	0.118	0.562			U
	N-MeFOA	31506-32-8	ND	ND	ND	0.232	0.562			U
	N-MeFOSE	24448-09-7	ND	ND	ND	0.533	2.53			U
	NVHOS	1132933-86-8	768.01	1.08	1.08	0.0865	0.562			
	PEPA	267239-61-2	338.08	0.475	0.475	0.105	0.562			J
	PFECA-G	801212-59-9	ND	ND	ND	0.0749	0.562			U
	PFEEA	113507-82-7	ND	ND	ND	0.169	0.562			U
	PFHxDA	67905-19-5	ND	ND	ND	0.298	0.562			U
	PFMOBA	863090-89-5	ND	ND	ND	0.942	1.26			U
	PFOSDA	39492-91-6	ND	ND	ND	0.449	2.81			U
	PMPA	13140-29-9	1504.59	2.11	2.11	0.132	0.562			
	R-EVE	2416366-22-6	ND	ND	ND	0.932	1.26			U
R-PSDA	2416366-18-0	ND	ND	ND	2.47	2.47			U	
R-PSDCA	241636-21-5	ND	ND	ND	0.237	0.562			U	
ES	MFPBA		5066.40	7.11				20-150%	101.3%	
	M5PFPeA		6239.37	8.76				20-150%	124.8%	
	M3PFBS		6590.47	9.25				20-150%	131.8%	
	M2-4:2 FTS		5543.22	7.78				20-150%	110.9%	
	M5PFHxA		3158.77	4.43				20-150%	63.2%	
	M3HFPO-DA		3299.56	4.63				20-150%	66.0%	
	M4PFHpA		3738.92	5.25				20-150%	74.8%	
	M3PFHxS		5145.34	7.22				20-150%	102.9%	
	M2-6:2 FTS		8530.25	12.0				20-150%	170.6%	Q
	M8PFOA		4308.47	6.05				20-150%	86.2%	
	M9PFNA		4361.16	6.12				20-150%	87.2%	
	M8PFOS		4923.16	6.91				20-150%	98.5%	
	M2-8:2 FTS		6484.30	9.10				20-150%	129.7%	
	M8FOSA-I		4379.27	6.15				20-150%	87.6%	
	M6PFDA		4601.96	6.46				20-150%	92.0%	
	d3-N-MeFOSAA		5995.44	8.42				20-150%	119.9%	
	d5-N-EtFOSAA		5647.87	7.93				20-150%	113.0%	
	M7PFUDa		4732.22	6.64				20-150%	94.6%	
	MPPDoA		3562.67	5.00				20-150%	71.3%	
	M2PFTeDA		3047.42	4.28				20-150%	60.9%	
	d3-N-MeFOSA		1054.34	1.48				10-200%	10.5%	
	d5-N-EtFOA		964.09	1.35				10-200%	9.6%	Q
	d7-N-MeFOSE		4868.84	6.84				10-200%	48.7%	
d9-N-EtFOSE		4229.07	5.94				10-200%	42.3%		

# QC Data

### Enthalpy Analytical

Job No.: 0123-735-1 PFAS by Isotope Dilution (non-potable water)  
 Brunswick County Public Utilities - NC Client Project: N/A Site: Northwest Water Plant

Enthalpy ID	MB-14582-PFAS	Prep Batch	EU14582	Sample Vol (mL)	250
Sample Name	MB-14582-PFAS	Prep Date	2023-01-13 11:20	Extract Vol (mL)	0.4
Matrix	aqueous	Analysis Date	1/13/2023 5:23:29 PM	Split Factor	N/A
Sampling Date		Analyst	bmay	Method Code	WM-026
Received Date		Instrument	Pippin	Sample Type	Blank

	Compound	CAS	Extract Concentration ng/L	Sample Concentration ng/L	Formatted Result ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags	
Acids	PFBA	375-22-4	ND	ND	ND	0.254	0.640			U	
	PFPeA	2706-90-3	ND	ND	ND	0.183	0.640			U	
	PFHxA	307-24-4	ND	ND	ND	0.214	0.640			U	
	PFHpA	375-85-9	ND	ND	ND	0.224	0.640			U	
	PFOA	335-67-1	ND	ND	ND	0.146	0.640			U	
	PFNA	375-95-1	ND	ND	ND	0.145	0.640			U	
	PFDA	335-76-2	ND	ND	ND	0.183	0.640			U	
	PFUnDA	2058-94-8	ND	ND	ND	0.145	0.640			U	
	PFDoDA	307-85-1	ND	ND	ND	0.260	0.640			U	
	PFTriDA	72629-94-8	ND	ND	ND	0.212	0.640			U	
	PFTeDA	376-06-7	ND	ND	ND	0.244	0.640			U	
	Sulfonates	PFBS	375-73-5	ND	ND	ND	0.340	0.640			U
		PFPeS	2706-91-4	ND	ND	ND	0.131	0.603			U
		PFHxS	355-46-4	ND	ND	ND	0.494	0.586			U
PFHpS		375-92-8	ND	ND	ND	0.310	0.610			U	
PFOS		1763-23-1	ND	ND	ND	0.338	0.593			U	
PFNS		68259-12-1	ND	ND	ND	0.199	0.616			U	
PFDS		335-77-3	ND	ND	ND	0.336	0.616			U	
4:2 FTS		757124-72-4	ND	ND	ND	0.0830	0.600			U	
6:2 FTS		27619-97-2	62.70	0.100	0.100	0.302	0.610			L	
8:2 FTS		39108-34-4	ND	ND	ND	0.143	0.613			U	
Other		PFOSA	754-91-6	ND	ND	ND	0.0898	0.640			U
	N-MeFOSAA	2355-31-9	ND	ND	ND	0.180	0.640			U	
	N-EtFOSAA	2991-50-6	ND	ND	ND	0.260	0.640			U	
	HFPO-DA	13252-13-6	ND	ND	ND	0.0678	0.640			U	
	PFMOAA	674-13-5	ND	ND	ND	0.324	0.640			U	
	PFMOPrA	377-73-1	ND	ND	ND	0.228	0.640			U	
	PFO2HxA	39492-88-1	ND	ND	ND	0.206	0.640			U	
	PFO3OA	39492-89-2	ND	ND	ND	0.294	0.640			U	
	PFO4DA	39492-90-5	ND	ND	ND	0.506	3.20			U	
	Nafion Byproduct 1	29311-67-9	ND	ND	ND	0.342	0.640			U	
	ADONA	919005-14-4	ND	ND	ND	0.173	0.606			U	
	9Cl-PF3ONS	756426-58-1	ND	ND	ND	0.410	0.596			U	
	11Cl-PF3OUds	763051-92-9	ND	ND	ND	0.302	0.603			U	
	10:2 FTS	120226-60-0	ND	ND	ND	0.490	0.640			U	
	EVE Acid	69087-46-3	ND	ND	ND	0.204	1.44			U	
	FBSA	30334-69-1	ND	ND	ND	0.304	0.640			U	
	Hydro-EVE Acid	773804-62-9	ND	ND	ND	0.210	0.640			U	
	Hydrolyzed PSDA	2416366-19-1	ND	ND	ND	0.426	0.640			U	
	Nafion Byproduct 2	749836-20-2	ND	ND	ND	0.530	0.640			U	
	N-EtFOA	4151-50-2	ND	ND	ND	0.396	0.640			U	
	N-EtFOSE	1691-99-2	ND	ND	ND	0.980	2.88			U	
	NFDHA	151772-58-6	ND	ND	ND	0.135	0.640			U	
	N-MeFOA	31506-32-8	ND	ND	ND	0.264	0.640			U	
	N-MeFOSE	24448-09-7	ND	ND	ND	0.608	2.88			U	
	NVHOS	1132933-86-8	ND	ND	ND	0.0986	0.640			U	
	PEPA	267239-61-2	ND	ND	ND	0.120	0.640			U	
	PFECA-G	801212-59-9	ND	ND	ND	0.0854	0.640			U	
	PFEEA	113507-82-7	ND	ND	ND	0.192	0.640			U	
	PFHxDA	67905-19-5	ND	ND	ND	0.340	0.640			U	
	PFMOBA	863090-89-5	ND	ND	ND	1.07	1.44			U	
	PFO5DA	39492-91-6	ND	ND	ND	0.512	3.20			U	
	PMPA	13140-29-9	ND	ND	ND	0.151	0.640			U	
R-EVE	2416366-22-6	ND	ND	ND	1.06	1.44			U		
R-PSDA	2416366-18-0	ND	ND	ND	2.82	2.82			U		
R-PSDCA	241636-21-5	ND	ND	ND	0.270	0.640			U		
ES	MPFBA		4003.41	6.41				20-150%	80.1%		
	M5PFPeA		4071.25	6.51				20-150%	81.4%		
	M3PFBS		3562.64	5.70				20-150%	71.3%		
	M2-4:2 FTS		4524.36	7.24				20-150%	90.5%		
	M5PFHxA		2807.54	4.49				20-150%	56.2%		
	M3HFPO-DA		2839.91	4.54				20-150%	56.8%		
	M4PFHpA		3207.30	5.13				20-150%	64.1%		
	M3PFHxS		3925.73	6.28				20-150%	78.5%		
	M2-6:2 FTS		7207.21	11.5				20-150%	144.1%		
	M8PFOA		3636.50	5.82				20-150%	72.7%		
	M9PFNA		3734.72	5.98				20-150%	74.7%		
	M8PFOS		4089.19	6.51				20-150%	81.4%		
	M2-8:2 FTS		5685.92	9.10				20-150%	113.7%		
	M8FOSA-I		4060.82	6.50				20-150%	81.2%		
	M6PFDA		3976.88	6.36				20-150%	79.5%		
	d3-N-MeFOSAA		5338.99	8.54				20-150%	106.8%		
	d5-N-EtFOSAA		5176.17	8.28				20-150%	103.5%		
	M7PFUDa		4100.77	6.56				20-150%	82.0%		
	MPPDoA		3598.72	5.76				20-150%	72.0%		
	M2PFTeDA		3345.49	5.35				20-150%	66.9%		
	d3-N-MeFOSA		3974.36	6.36				10-200%	39.7%		
d5-N-EtFOA		4062.48	6.50				10-200%	40.6%			
d7-N-MeFOSE		6842.35	10.9				10-200%	68.4%			
d9-N-EtFOSE		6123.54	9.80				10-200%	61.2%			

# Enthalpy Analytical

Job No.: 0123-735-1 PFAS by Isotope Dilution (non-potable water)

Brunswick County Public Utilities - NC Client Project: N/A Site: Northwest Water Plant

Enthalpy ID	OPR-14582-PFAS	Prep Batch	EU14582	Sample Vol (mL)	250
Sample Name	OPR-14582-PFAS	Prep Date	2023-01-13 11:20	Extract Vol (mL)	0.4
Matrix	aqueous	Analysis Date	1/13/2023 5:46:09 PM	Split Factor	N/A
Sampling Date		Analyst	bmay	Method Code	WM-026
Received Date		Instrument	Pippin	Sample Type	Control

	Compound	CAS	Extract Concentration ng/L	Sample Concentration ng/L	Formatted Result ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags
Acids	PFBA	375-22-4	13115.56	21.0	21.0	0.254	0.640	73-129%	104.9%	
	PFPeA	2706-90-3	13097.23	21.0	21.0	0.183	0.640	72-129%	104.8%	
	PFHxA	307-24-4	12360.11	19.8	19.8	0.214	0.640	72-129%	98.9%	
	PFHpA	375-85-9	12298.21	19.7	19.7	0.224	0.640	72-130%	98.4%	
	PFOA	335-67-1	14245.91	22.8	22.8	0.146	0.640	71-133%	114.0%	
	PFNA	375-95-1	12654.42	20.2	20.2	0.145	0.640	69-130%	101.2%	
	PFDA	335-76-2	12592.50	20.1	20.1	0.183	0.640	71-129%	100.7%	
	PFUnDA	2058-94-8	12049.51	19.3	19.3	0.145	0.640	69-133%	96.4%	
	PFDODA	307-55-1	14102.98	22.6	22.6	0.260	0.640	72-134%	112.8%	
	PFTeDA	72629-94-8	13590.59	21.7	21.7	0.212	0.640	65-144%	108.7%	
	PFTeDA	376-06-7	12814.36	20.5	20.5	0.244	0.640	71-132%	102.5%	
Sulfonates	PFBS	375-73-5	11643.50	18.6	18.6	0.340	0.640	72-134%	105.0%	
	PFPeS	2706-91-4	13816.49	22.1	22.1	0.131	0.603	71-127%	117.5%	
	PFHxS	355-46-4	10222.34	16.4	16.4	0.494	0.586	68-131%	89.5%	
	PFHpS	375-92-8	13529.78	21.6	21.6	0.310	0.610	69-134%	113.6%	
	PFOS	1763-23-1	13388.36	21.4	21.4	0.338	0.593	65-140%	115.4%	
	PFNS	68259-12-1	12977.45	20.8	20.8	0.199	0.616	69-127%	107.9%	
	PFDS	335-77-3	13552.27	21.7	21.7	0.336	0.616	53-142%	112.4%	
	4:2 FTS	757124-72-4	11850.16	19.0	19.0	0.0830	0.600	63-143%	101.2%	
	6:2 FTS	27619-97-2	12075.84	19.3	19.3	0.302	0.610	64-140%	101.6%	
8:2 FTS	39108-34-4	12525.32	20.0	20.0	0.143	0.613	67-138%	104.4%		
Other	PFOSA	754-91-6	12690.18	20.3	20.3	0.0898	0.640	67-137%	101.5%	
	N-MeFOSAA	2355-31-9	14101.79	22.6	22.6	0.180	0.640	65-136%	112.8%	
	N-EtFOSAA	2991-50-6	12600.83	20.2	20.2	0.260	0.640	61-135%	100.8%	
	HFPO-DA	13252-13-6	12592.12	20.1	20.1	0.0678	0.640	70-130%	100.7%	
ES	MPFBA		4428.49	7.09				20-150%	88.6%	
	M5PFPeA		4393.79	7.03				20-150%	87.9%	
	M3PFBS		4205.71	6.73				20-150%	84.1%	
	M2-4:2 FTS		5685.42	9.10				20-150%	113.7%	
	M5PFHxA		3473.49	5.56				20-150%	69.5%	
	M3HFPO-DA		3602.00	5.76				20-150%	72.0%	
	M4PFHpA		4174.65	6.68				20-150%	83.5%	
	M3PFHxS		5886.31	9.42				20-150%	117.7%	
	M2-6:2 FTS		9056.43	14.5				20-150%	181.1%	Q
	M8PFOA		4298.53	6.88				20-150%	86.0%	
	M9PFNA		4636.14	7.42				20-150%	92.7%	
	M8PFOS		4512.41	7.22				20-150%	90.2%	
	M2-8:2 FTS		6807.64	10.9				20-150%	136.2%	
	M8FOSA-I		4883.10	7.81				20-150%	97.7%	
	M6PFDA		4718.39	7.55				20-150%	94.4%	
	d3-N-MeFOSAA		5709.21	9.13				20-150%	114.2%	
	d5-N-EtFOSAA		5599.23	8.96				20-150%	112.0%	
	M7PFUDa		4459.25	7.13				20-150%	89.2%	
	MPFDoA		3610.38	5.78				20-150%	72.2%	
	M2PFTeDA		3732.00	5.97				20-150%	74.6%	

# Narrative Summary

# Enthalpy Analytical Narrative Summary

Company	Brunswick County Public Utilities - NC
Job No.	0123-735-1 PFAS by Isotope Dilution (non-potable water)
Client ID.	N/A Site: Northwest Water Plant

## 1. Custody

Megan Holden received the samples on January 12, 2023 at 2.6 °C after being relinquished by Brunswick County Public Utilities - NC. The samples were received in good condition.

Prior to, during, and after analysis, the samples were kept under lock with access only to authorized personnel by Enthalpy Analytical, LLC.

## Table 1 - Sample Inventory

EU Lab Sample ID	Client Sample ID	Matrix
0123-735-001-1	011223-SO1	AQ
0123-735-002-1	011223-EO1	AQ

## 2. Methods and Analytes

A list of analytes of interest and corresponding methods of analysis is shown in Table 3. Abbreviations are defined in the listed Appendices.

## Table 3 - Methods and Analytes

EU Method	Analytes	Cleanup Method
EU-047	Brunswick PFAS List	ENVI-Carb

## 3. Analysis

The samples were analyzed using Waters Acquity UPLC equipped with Xevo TQ MS (LC/MS/MS "Pippin").

For aqueous samples, the sample volume was measured gravimetrically by the laboratory, and spiked with Extraction Standard (ES). The sample was then mixed well and centrifuged, if needed. The samples were then extracted via SPE, and the extracts were cleaned up using ENVI-Carb.

Each final sample extract was transferred to an autosampler vial, spiked with Injection Standard (IS), and brought to a final volume of 400µL prior to analysis.

## 4. Calibration

In the initial calibration, the reported analytes exhibited  $R^2$  of  $\geq 0.99$ . The reported analytes in the calibration standards, continuing calibration (concal) and Initial Calibration Verification (ICV) met the 30% accuracy criterion for native analytes.

The Technical Director extended the method criteria for certain non-legacy analytes that do not have their own internal standard and exhibit observed variability during calibration.

# Enthalpy Analytical Narrative Summary

Company	Brunswick County Public Utilities - NC
Job No.	0123-735-1 PFAS by Isotope Dilution (non-potable water)
Client ID.	N/A Site: Northwest Water Plant

## 5. QC Notes

Except where noted below, the QC sample analyses passed all method criteria.

QC samples that did not meet method acceptance criteria were:

OPR-14582-PFAS M2-6:2 FTS

Labeled standards in the method blank (MB) and OPR that fell outside the control limits for ES recovery are denoted by the "Q" qualifier. The target analytes are quantified based on their ratio to their labeled standard analogs. As a result, low or high labeled standard recovery does not cause any change to ratios or contribute any additional error in the measurement of the target analyte(s). The data is reported without adverse impact.

The samples were extracted within the 28-day from collection holding time and analyzed within the 28-day from extraction to analysis holding time required by the method.

## 6. Reporting Notes

This report provides all results including detections below LOD following client instruction.

Analyte(s) were detected in the method blank (MB) at less than 1/2 LOQ that may also be less than LOD. Any of these analyte(s) detected in the samples with less than 10 times the amount detected in MB were notated with a B qualifier and are reported with no adverse impact.

Some labeled extraction standards in the sample analyses fell outside the control limits for ES recovery, as denoted by the "Q" qualifier. The target analytes are quantified based on their ratio to their labeled standard analogs. As a result, low or high labeled standard recovery do not cause any change to ratios or contribute any additional error in the measurement of the target analytes. The data have been accepted and reported with no further actions.

The results presented in this report are representative of the samples as provided to the laboratory.

These analyses met the requirements of the TNI Standard. Any deviations from the requirements of the reference method or TNI Standard have been stated above.

Enthalpy Analytical, LLC in Wilmington NC is accredited by the Louisiana Department of Environmental Quality to the 2009 TNI Standard under certificate number 05075.



## General Reporting Notes – Data Qualifiers

The following are general reporting notes that are applicable to all Enthalpy Analytical, LLC - Wilmington, NC data reports, unless specifically noted otherwise.

### General Data Qualifiers

- B – The analyte was found in the method blank, at a concentration that was at least 10% of the amount in the sample.
- Cxx – Two or more congeners co-elute. In EDDs, C denotes the lowest IUPAC congener in a co-elution group and additional co-eluters for the group ('xx') are shown with the number of the lowest IUPAC co-eluter.
- E – The reported concentration exceeds the calibration range (upper point of the calibration curve). For HRMS data, this condition does not imply additional measurement uncertainty. For LC-MS/MS data, these values should be considered as having measurement uncertainty higher than values within the calibration range.
- EDL – Estimated Detection Level: The EDL is unique to isotope dilution methods and reflects the conditions of analysis at the time of analysis, including the equipment used. Where the MDL is a static value, the EDL is a dynamic value.
- EMPC – Estimated Maximum Possible Concentration: EMPC is specific to Dioxin/Furan tests to indicate the determined ion-abundance ratio was outside the allowed theoretical range (usually due to being near the detection limit, although it can very rarely be caused by a co-eluting interference). The EMPC concentration is adjusted to reflect the value at the theoretical ion-abundance ratio.
- IR – The ion ratio between the primary and secondary ions was observed to be outside the method criteria. The analyte concentration may be inaccurate due to interference.
- J – The analyte has a concentration below the minimum calibration level (LOQ value) but greater than the LOD. These values should be considered as having measurement uncertainty higher than values within the calibration range
- L - Indicates that an analyte has a concentration below the Minimum Detection Limit (MDL). The reported concentration is not recommended for regulatory use as the analyte signal may have a signal-to-noise ratio less than the criteria deemed necessary to be considered a detected analyte.
- LOD – Limit of Detection: For reports conforming to the DOD ELAP QSM, this is the QSM-defined LOD. For reports conforming to TNI requirements (but not DOD ELAP QSM requirements), this value is the minimum detection limit (MDL). The LOD is adjusted for sample weight or volume.
- LOQ – Limit of Quantitation: For reports conforming to the DOD ELAP QSM, this is the QSM-defined LOQ. For reports conforming to TNI requirements (but not DOD ELAP QSM requirements), this value is the reporting limit (RL). The LOQ is adjusted for sample weight or volume.

## General Reporting Notes – Data Qualifiers

- <LOD() – Analyte was not found at a concentration high enough to be reported as detected. It is reported as less than the LOD, and the LOD is given in the parentheses.
- <LOQ() – Analyte was not found at a concentration high enough to be reported as above the QSM-defined LOQ or TNI defined Reporting Limit. It is reported as less than the LOQ, and the LOQ is given in the parentheses.
- ND – Indicates a non-detect.
- NR – Indicates a value that is not reportable due to issues observed in sample preparation or analysis.
- PR – The associated congener(s) is(are) poorly resolved.
- QI – Indicates the presence of a quantitative interference.
- RL – Reporting Limit. Lowest reportable value. The level is higher than the MDL.
- SI – Denotes “Single Ion Mode” and is utilized for PCBs where the secondary ion trace has a significantly elevated noise level due to background PFK. Responses for such peaks are calculated using an EMPC approach based solely on the primary ion area(s) and may be considered estimates.
- U – The analyte was not detected.
- V / Q – The labeled standard recovery is not within method control limits.
- X – Indicates the result is from re-injection/repeat/second-column analysis.

### **Lab Identifiers/ Data Attributes**

- AR – Indicates use of the archived portion of the sample extract.
- CU – Indicates a sample that required additional clean-up prior to HRMS injection/processing.
- D – Dilution Data. Result was obtained from the analysis of a dilution. The number that follows the “D” indicates the dilution factor.
- DE – Indicates a dilution performed with the addition of ES (Extraction Standard) solution.
- DUP – Designation for a duplicate sample.
- MS – Designation for a matrix spike.
- MSD – Designation for a matrix spike duplicate.
- R – Indicates a re-extraction of the sample.
- RJ – Indicates a reinjection of the sample extract.



## General Reporting Notes – Data Qualifiers

- S – Indicates a sample split. The number that follows the “S” indicates the split factor.
- SAT – Indicates an analyte saturated the detector.

PFAS Compound Acronym List		
Acronym	CAS #	Compound Name
<b>Target Analytes</b>		
<b>* Analyte is not accredited</b>		
PFBA	375-22-4	Perfluorobutanoic Acid
PFPeA	2706-90-3	Perfluoropentanoic Acid
PFHxA	307-24-4	Perfluorohexanoic Acid
PFHpA	375-85-9	Perfluoroheptanoic Acid
PFOA	335-67-1	Perfluorooctanoic Acid
PFNA	375-95-1	Perfluorononanoic Acid
PFDA	335-76-2	Perfluorodecanoic acid
PFUnA (PFUnDA)	2058-94-8	Perfluoroundecanoic acid
PFDoA (PFDoDA)	307-55-1	Perfluorododecanoic acid
PFTriA (PFTriA)	72629-94-8	Perfluorotridecanoic acid
PFTeDA (PFTA)	376-06-7	Perfluorotetradecanoic acid
PFBS	375-73-5	Perfluorobutane sulfonic acid
PFPeS	2706-91-4	Perfluoropentane sulfonic acid
PFHxS	355-46-4	Perfluorohexane sulfonic acid
PFHpS	375-92-8	Perfluoroheptane sulfonic acid
PFOS	1763-23-1	Perfluorooctane sulfonic acid
PFNS	68259-12-1	Perfluorononane sulfonic acid
PFDS	335-77-3	Perfluorodecane sulfonic acid
4:2 FTS	757124-72-4	4:2 fluorotelomer sulfonic acid
6:2 FTS	27619-97-2	6:2 fluorotelomer sulfonic acid
8:2 FTS	39108-34-4	8:2 fluorotelomer sulfonic acid
PFOSA (FOSA)	754-91-6	Perfluorooctane sulfonamide
N-MeFOSAA	2355-31-9	N-methyl perfluorooctane sulfonamido acetic acid
N-EtFOSAA	2991-50-6	N-ethyl perfluorooctane sulfonamido acetic acid
HFPO-DA	13252-13-6	2,3,3,3-Tetrafluoro-2-(1,1,2,2,3,3,3-heptafluoropropoxy)-propanoic acid (Gen-X)
11Cl-PF3OUdS	763051-92-9	11-chloroeicosafluoro-3-oxaundecane-1-sulfonic acid
9Cl-PF3ONS	756426-58-1	9-chlorohexadecafluoro-3-oxanonane-1-sulfonic acid
ADONA	919005-14-4	4,8-dioxa-3H-perfluorononanoic acid
PFEESA	113507-82-7	Perfluoro(2-ethoxyethane)sulphonic acid
PFMOBA (PFMBA)	863090-89-5	Perfluoro-4-methoxybutanic acid
NFDHA	151772-58-6	Nonafluoro-3,6-dioxaheptanoic acid
PFMOPra (PFMPA)	377-73-1	Perfluoro-3-methoxypropanoic acid
* PFMOAA	674-13-5	Perfluoro-2-methoxyacetic acid
* PFO2HxA	39492-88-1	Perfluoro (3,5-dioxaheptanoic) acid
* PFO3OA	39492-89-2	Perfluoro (3,5,7-trioxaoctanoic) acid
* PFO4DA	39492-90-5	Perfluoro (3,5,7,9-tetraoxadecanoic) acid
* PFO5DA	39492-91-6	Perfluoro(3,5,7,9,11-pentaoxadodecanoic) acid
* Nafion Byproduct 1	29311-67-9	Nafion Byproduct 1
* Nafion Byproduct 2	749836-20-2	Nafion Byproduct 2
* PEPA	267239-61-2	Perfluoro-2-ethoxypropanoic acid
* PMPA	13140-29-9	Perfluoro-2-methoxypropanoic acid
* 10:2 FTS	120226-60-0	Fluorotelomer sulfonate 10:2
* N-EtFOSA	4151-50-2	N-ethylperfluoro-1-octanesulfonamide
* N-EtFOSE	1691-99-2	2-(N-methylperfluoro-1-octanesulfonamido)-ethanol
* N-MeFOSA	31506-32-8	N-methylperfluoro-1-octanesulfonamide
* N-MeFOSE	24448-09-7	2-(N-methylperfluoro-1-octanesulfonamido)-ethanol
* PFECA-G	801212-59-9	4-(Heptafluoroisopropoxy)hexafluorobutanoic acid
* PFHxDA	67905-19-5	Perfluorohexadecanoic acid
* R-PSDA (Nafion Byproduct 4)	2416366-18-0	Perfluoro-4-(2-sulfoethoxy)pentanoic acid

PFAS Compound Acronym List		
Acronym	CAS #	Compound Name
<b>Target Analytes</b>		
<b>* Analyte is not accredited</b>		
* Hydrolyzed PSDA (Nafion Byproduct 5)	2416366-19-1	2-fluoro-2-[1,1,2,3,3,3-hexafluoro-2-(1,1,2-tetrafluoro-2-sulfoethoxy)propoxy]-acetic acid
* R-PSDCA (Nafion Byproduct 6)	2416366-21-5	1,1,2,2-tetrafluoro-2-[1,2,2,3,3-pentafluoro-1-(trifluoromethyl)propoxy] ethanesulfonic acid
* EVE Acid	69087-46-3	2,2,3,3-tetrafluoro-3-({1,1,1,2,3,3-hexafluoro-3-[(1,2,2-trifluoroethenyl)oxy]propan-2-yl)oxy}propionic acid
* FBSA	30334-69-1	Perfluorobutylsulfonamide
* Hydro-EVE Acid	773804-62-9	2,2,3,3-Tetrafluoro-3-{{1,1,1,2,3,3-hexafluoro-3-(1,2,2,2-tetrafluoroethoxy)propan-2-yl}oxy}propanoic acid
* R-EVE Acid	2416366-22-6	4-(2-carboxy-1,1,2,2-tetrafluoroethoxy)-2,2,3,3,4,5,5,5-octafluoro-pentanoic acid
* NVHOS	1132933-86-8	Perfluoroethoxysulfonic acid
* PFDoS	79780-39-5	Perfluorododecane sulfonic acid
* PFOA	16517-11-6	Perfluorooctadecanoic acid
* 3:3 FTCA	356-02-5	2H,2H,3H,3H-Perfluorohexanoic acid
* 5:3 FTCA	914637-49-3	2H,2H,3H,3H-Perfluorooctanoic acid
* 7:3 FTCA	812-70-4	2H,2H,3H,3H-Perfluorodecanoic acid
* N-AP-FHxSA	50598-28-2	N-(3-(Dimethylamino)propyl)tridecafluoro-1-hexanesulfonamide
* N-CMAmP-6:2 FOSA	34455-29-3	N-(Carboxymethyl)-N,N-dimethyl-3-(((3,3,4,4,5,5,6,6,7,7,8,8,8-tridecafluorooctyl)sulfonyl)amino)1-propanaminium

# Sample Custody



0123-735  
Chain of Custody Record

Enthalpy Ultratrace Job#: \_\_\_\_\_ COC Page 1 of 1

**Special Handling:**

- Standard Turn Around Time
- Rush Turn Around Time -- Date Needed \_\_\_\_\_
- All Fast TATs Subject to Approval by Enthalpy Analytical, Inc.
- All Samples Disposed of After 6 months Unless Otherwise Instructed.

Enthalpy Analytical Wilmington, NC has added enhancements to standard methods to improve accuracy, precision and permit an assessment of laboratory performance in the context of your specific data needs. For more information email Cindy.James@enthalpy.com.

Client Name: BRUNSWICK COUNTY UTILITIES  
Project Manager: GLENN WALKER  
Report To: SAME

Project Number: \_\_\_\_\_  
Site Name: NORTHWEST WATER PLANT  
Location: LELAND N.C.

PO#: \_\_\_\_\_  
Telephone#: \_\_\_\_\_  
Email: \_\_\_\_\_

This Chain of Custody is applicable to Non-Air samples. Standard TAT differ per analysis and are provided by request.

**Client Special Instructions:**  
  
Matrix: GW-Groundwater, WW-Wastewater, NW-Non-Potable Water, DW-Drinking Water, S-Soil, SL-Sludge, BT-Biological Tissue, O-Other  
Type: G=Grab C=Composite Q=Quality Control

Sample ID	Date	Time	Sample Volume	Type	Matrix	Sample Containers				Analyses:						Notes:		
						# of Bottles	# of Jars	# of Bags	# Other	Method 1613	Method 8290	Method 1668A/B/C PCB:	PFAS by LC/MS/MS	PAHs by HRGC/HRMS	Sample on Hold		Method 23	ALL PFAS
011223-SO1	1/12/2023	0800AM	250 ml	G	NW	2												X
011223-EO1	1/12/2023	0800AM	250 ml	G	DW	2												X
<p style="font-size: 24px; font-family: cursive;">COURIER, COOLER, ON ICE, NO SEALS, good condition - MVR 01-12-23</p>																		

Relinquished By:	Date:	Received By:	Date:	Time:	Sample Temperature Upon Receipt:
BILLY BENTON	1/12/2023	Megan Holden	01.12.23	2:30	<input checked="" type="checkbox"/> Iced <input type="checkbox"/> Ambient    °C <u>2.6 TL</u> <input type="checkbox"/> Iced <input type="checkbox"/> Ambient    °C _____ <input type="checkbox"/> Iced <input type="checkbox"/> Ambient    °C _____

**This Is The Last Page  
Of This Report.**