

Brunswick County Public Utilities - NC

3954 Clearwell Dr NE
Leland, NC 28451

Northwest Water Plant

Leland, NC

Samples Received: 09/22/22

Analytical Report 0922-778

Isotope Dilution Method PFAS



Enthalpy Analytical, LLC – Ultratrace

Mark Hager

O: 910-876-6894/ F: 910-212-6886

mark.hager@enthalpy.com / www.enthalpy.com

2714 Exchange Drive, Wilmington, NC 28405

I certify that to the best of my knowledge all analytical data presented in this report:

- Have been checked for completeness
- Are accurate, error-free, and legible
- Have been conducted in accordance with approved protocol, and that all deviations and analytical problems are summarized in the appropriate narrative(s)

This analytical report was prepared in Portable Document Format (.PDF) and contains _____ pages.

....."Report Issued Date: _____



Summary of Results



Enthalpy Analytical

Job No.: 0922-778-1 PFAS by Isotope Dilution (non-potable water)

Brunswick County Public Utilities - NC Client Project: N/A Site: Northeast Water Plant Leland, NC

Summary

	Compound	CAS	092222S01 ng/L	092222E01 ng/L
Acids	PFBA	375-22-4	5.57	5.88
	PFPeA	2706-90-3	11.4	13.7
	PFHxA	307-24-4	8.46	9.86
	PFHpA	375-85-9	3.90	3.77
	PFOA	335-67-1	5.14	5.86
	PFNA	375-95-1	0.751	0.747
	PFDA	335-76-2	0.473 J	0.534 J
	PFUnDA	2058-94-8	0.138 L	ND U
	PFDoDA	307-55-1	0.00823 L	ND U
	PFTrDA	72629-94-8	ND U	ND U
	PFTeDA	376-06-7	ND U	ND U
Sulfonates	PFBS	375-73-5	6.21	7.22
	PFPeS	2706-91-4	0.845	1.17
	PFHxS	355-46-4	6.25	6.84
	PFHpS	375-92-8	0.277 J	0.307 J
	PFOS	1763-23-1	11.3	12.6
	PFNS	68259-12-1	ND U	ND U
	PFDS	335-77-3	ND U	ND U
	4:2 FTS	757124-72-4	ND U	ND U
6:2 FTS	27619-97-2	0.0986 L	0.389 J	
8:2 FTS	39108-34-4	ND U	ND U	
Other	PFOSA	754-91-6	ND U	ND U
	N-MeFOSAA	2355-31-9	ND U	ND U
	N-EtFOSAA	2991-50-6	ND U	ND U
	HFPO-DA	13252-13-6	2.50	3.10
	PFMOAA	674-13-5	28.0	29.4
	PFMOPra	377-73-1	0.0368 L	0.0497 L
	PFO2HxA	39492-88-1	4.57	5.05
	PFO3OA	39492-89-2	1.08 L	0.932 L
	PFO4DA	39492-90-5	0.226 L	0.243 L
	Nafion Byproduct 1	29311-67-9	ND U	ND U
	ADONA	919005-14-4	ND U	ND U
	9Cl-PF3ONS	756426-58-1	ND U	ND U
	11Cl-PF3OUdS	763051-92-9	ND U	ND U
	10:2 FTS	120226-60-0	ND U	ND U
	EVE Acid	69087-46-3	ND U	ND U
	FBSA	30334-69-1	0.601	0.765
	Hydro-EVE Acid	773804-62-9	0.0755 L	0.0807 L
	Hydrolyzed PSDA	2416366-19-1	3.33	5.05
	Nafion Byproduct 2	749836-20-2	0.272 J	0.404 J
	N-EtFOSA	4151-50-2	ND U	ND U
	N-EtFOSE	1691-99-2	ND U	ND U
	NFDHA	151772-58-6	ND U	ND U
	N-MeFOSA	31506-32-8	ND U	ND U
	N-MeFOSE	24448-09-7	ND U	ND U
	NVHOS	1132933-86-8	3.21	3.46
	PEPA	267239-61-2	1.12 L	1.43
	PFECA-G	801212-59-9	ND U	ND U
	PFEESA	113507-82-7	ND U	ND U
	PFHxDA	67905-19-5	ND U	ND U
	PFMOBA	863090-89-5	ND U	ND U
PFO5DA	39492-91-6	0.0611 L	0.0417 L	
PMPA	13140-29-9	4.35	4.52	
R-EVE	2416366-22-6	2.49	2.98	
R-PSDA	2416366-18-0	11.5	12.1	
R-PSDCA	241636-21-5	0.0422 L	0.0537 L	

Detailed Results



Enthalpy Analytical

Job No.: 0922-778-1 PFAS by Isotope Dilution (non-potable water)

Brunswick County Public Utilities - NC Client Project: N/A Site: Northeast Water Plant Leland, NC

Enthalpy ID	0922-778-001-1	Prep Batch	EU14037	Sample Vol (mL)	290.87
Sample Name	092222S01	Prep Date	2022-09-23 15:18	Extract Vol (mL)	0.4
Matrix	AQ	Analysis Date	9/25/2022 7:57:45 AM	Split Factor	N/A
Sampling Date	09-22-22 0920	Analyst	brneff	Method Code	WM-026
Received Date	2022-09-22 10:00	Instrument	Pippin	Sample Type	Sample

	Compound	CAS	Extract Concentration ng/L	Sample Concentration ng/L	Formatted Result ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags
Acids	PFBA	375-22-4	4046.98	5.57	5.57	0.132	0.550			
	PFPeA	2706-90-3	8305.00	11.4	11.4	0.146	0.550			
	PFHxA	307-24-4	6152.29	8.46	8.46	0.166	0.550			
	PFHpA	375-85-9	2834.11	3.90	3.90	0.105	0.550			
	PFOA	335-67-1	3737.92	5.14	5.14	0.152	0.550			
	PFNA	375-95-1	546.46	0.751	0.751	0.0654	0.550			
	PFDA	335-76-2	343.69	0.473	0.473	0.0726	0.550			J
	PFUnDA	2058-94-8	100.43	0.138	0.138	0.159	0.550			L
	PFDoDA	307-55-1	5.99	0.00823	0.00823	0.174	0.550			L
	PFTriDA	72629-94-8	ND	ND	ND	0.130	0.550			U
PFTeDA	376-06-7	ND	ND	ND	0.187	0.550			U	
Sulfonates	PFBS	375-73-5	4519.33	6.21	6.21	0.305	0.642			
	PFPeS	2706-91-4	614.48	0.845	0.845	0.177	0.518			
	PFHxS	355-46-4	4542.10	6.25	6.25	0.164	0.504			
	PFHpS	375-92-8	201.70	0.277	0.277	0.116	0.524			J
	PFOS	1763-23-1	8219.08	11.3	11.3	0.138	0.510			
	PFNS	68259-12-1	ND	ND	ND	0.0743	0.530			U
	PFDS	335-77-3	ND	ND	ND	0.165	0.530			U
	4:2 FTS	757124-72-4	ND	ND	ND	0.101	0.515			U
	6:2 FTS	27619-97-2	71.68	0.0986	0.0986	0.0997	0.524			L
	8:2 FTS	39108-34-4	ND	ND	ND	0.147	0.527			U
Other	PFOSA	754-91-6	ND	ND	ND	0.112	0.550			U
	N-MeFOSAA	2355-31-9	ND	ND	ND	0.124	0.550			U
	N-EiFOSAA	2991-50-6	ND	ND	ND	0.0937	0.550			U
	HFPO-DA	13252-13-6	1819.67	2.50	2.50	0.196	0.550			
	PFMOA	674-13-5	20379.12	28.0	28.0	1.24	1.24			
	PFMOPrA	377-73-1	26.79	0.0368	0.0368	0.206	0.550			L
	PFO2HxA	39492-88-1	3324.67	4.57	4.57	1.24	1.24			
	PFO3OA	39492-89-2	785.99	1.08	1.08	1.24	1.24			L
	PF04DA	39492-90-5	164.49	0.226	0.226	1.31	1.31			L
	Nafion Byproduct 1	29311-67-9	ND	ND	ND	0.261	0.550			U
	ADONA	919005-14-4	ND	ND	ND	0.103	0.521			U
	9Cl-PF3ONS	756426-58-1	ND	ND	ND	0.103	0.512			U
	11Cl-PF3OUdS	763051-92-9	ND	ND	ND	0.103	0.518			U
	10:2 FTS	120226-60-0	ND	ND	ND	0.206	0.550			U
	EVE Acid	69087-46-3	ND	ND	ND	1.24	1.24			U
	FBSA	30334-69-1	437.18	0.601	0.601	0.206	0.550			
	Hydro-EVE Acid	773804-62-9	54.93	0.0755	0.0755	1.24	1.24			L
	Hydrolyzed PSDA	2416366-19-1	2422.82	3.33	3.33	1.24	1.24			
	Hydrolyzed PSDA	2416366-19-1	1474.56	2.03	2.03	1.24	1.24			
	Nafion Byproduct 2	749836-20-2	197.61	0.272	0.272	0.261	0.550			J
	N-EiFOSA	4151-50-2	ND	ND	ND	0.206	0.550			U
	N-EiFOSE	1691-99-2	ND	ND	ND	6.19	6.19			U
	NFDHA	151772-58-6	ND	ND	ND	0.206	0.550			U
	N-MeFOSA	31506-32-8	ND	ND	ND	0.206	0.550			U
	N-MeFOSE	24448-09-7	ND	ND	ND	6.19	6.19			U
	NVHOS	1132933-86-8	2337.50	3.21	3.21	1.24	1.24			
	PEPA	267239-61-2	815.88	1.12	1.12	1.24	1.24			L
	PFECA-G	801212-59-9	ND	ND	ND	0.261	1.24			U
	PFEEA	113507-82-7	ND	ND	ND	0.206	0.550			U
	PFHxDA	67905-19-5	ND	ND	ND	1.24	1.24			U
PFMOBA	863090-89-5	ND	ND	ND	1.24	1.24			U	
PFO5DA	39492-91-6	44.41	0.0611	0.0611	1.31	1.31			L	
PMPA	13140-29-9	3162.90	4.35	4.35	1.24	1.24				
R-EVE	2416366-22-6	1811.87	2.49	2.49	1.24	1.24				
R-PSDA	2416366-18-0	8383.90	11.5	11.5	1.24	1.24				
R-PSDCA	241636-21-5	30.67	0.0422	0.0422	1.24	1.24			L	
ES	MPPFA	4683.79	6.44					20-150%	93.7%	
	M5PFPeA	6688.75	9.20					20-150%	133.8%	
	M3PFBS	7758.21	10.7					20-150%	155.2%	Q
	M2-4:2 FTS	5925.42	8.15					20-150%	118.5%	
	M5PFHxA	4399.45	6.05					20-150%	88.0%	
	M3HFPO-DA	5821.18	8.01					20-150%	116.4%	
	M4PFHpA	4605.48	6.33					20-150%	92.1%	
	M3PFHxS	6100.74	8.39					20-150%	122.0%	
	M2-6:2 FTS	4707.30	6.47					20-150%	94.1%	
	M8PFOA	4824.21	6.63					20-150%	96.5%	
	M9PFNA	4377.80	6.02					20-150%	87.6%	
	M8PFOS	4975.56	6.84					20-150%	99.5%	
	M2-8:2 FTS	4892.94	6.73					20-150%	97.9%	
	M8FOSA-I	2775.94	3.82					20-150%	55.5%	
	M6PFDA	4545.52	6.25					20-150%	90.9%	
	d3-N-MeFOSAA	3204.75	4.41					20-150%	64.1%	
	d5-N-EiFOSAA	3327.43	4.58					20-150%	66.5%	
	M7PFUdA	4430.71	6.09					20-150%	88.6%	
	MPPDoA	5819.24	8.00					20-150%	116.4%	
	M2PFTeDA	2074.51	2.85					20-150%	41.5%	
	d3-N-MeFOSA	2935.03	4.04					10-200%	29.4%	
	d5-N-EiFOSA	2311.69	3.18					10-200%	23.1%	
	d7-N-MeFOSE	1606.44	2.21					10-200%	16.1%	
	d9-N-EiFOSE	1176.08	1.62					10-200%	11.8%	

Enthalpy Analytical

Job No.: 0922-778-1 PFAS by Isotope Dilution (non-potable water)

Brunswick County Public Utilities - NC Client Project: N/A Site: Northeast Water Plant Leland, NC

Enthalpy ID	0922-778-002-1	Prep Batch	EU14037	Sample Vol (mL)	284.42
Sample Name	092222E01	Prep Date	2022-09-23 15:18	Extract Vol (mL)	0.4
Matrix	AQ	Analysis Date	9/25/2022 8:20:33 AM	Split Factor	N/A
Sampling Date	09-22-22 0920	Analyst	brneff	Method Code	WM-026
Received Date	2022-09-22 10:00	Instrument	Pippin	Sample Type	Sample

	Compound	CAS	Extract Concentration ng/L	Sample Concentration ng/L	Formatted Result ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags	
Acids	PFBA	375-22-4	4180.18	5.88	5.88	0.134	0.563				
	PFPeA	2706-90-3	9758.76	13.7	13.7	0.149	0.563				
	PFHxA	307-24-4	7010.57	9.86	9.86	0.170	0.563				
	PFHpA	375-85-9	2682.41	3.77	3.77	0.107	0.563				
	PFOA	335-67-1	4166.62	5.86	5.86	0.156	0.563				
	PFNA	375-95-1	531.20	0.747	0.747	0.0669	0.563				
	PFDA	335-76-2	379.84	0.534	0.534	0.0743	0.563			J	
	PFUnDA	2058-94-8	ND	ND	ND	0.163	0.563			U	
	PFDoDA	307-55-1	ND	ND	ND	0.178	0.563			U	
	PFTriDA	72629-94-8	ND	ND	ND	0.133	0.563			U	
	PFTeDA	376-06-7	ND	ND	ND	0.192	0.563			U	
	Sulfonates	PFBS	375-73-5	5131.75	7.22	7.22	0.312	0.657			
		PFPeS	2706-91-4	828.65	1.17	1.17	0.181	0.530			
		PFHxS	355-46-4	4860.06	6.84	6.84	0.168	0.515			
PFHpS		375-92-8	218.29	0.307	0.307	0.119	0.536			J	
PFOS		1763-23-1	8987.28	12.6	12.6	0.141	0.521				
PFNS		68259-12-1	ND	ND	ND	0.0759	0.542			U	
PFDS		335-77-3	ND	ND	ND	0.169	0.542			U	
4:2 FTS		757124-72-4	ND	ND	ND	0.104	0.527			U	
6:2 FTS		27619-97-2	276.71	0.389	0.389	0.102	0.536			J	
8:2 FTS		39108-34-4	ND	ND	ND	0.150	0.539			U	
PFOSA		754-91-6	ND	ND	ND	0.114	0.563			U	
N-MeFOSAA		2355-31-9	ND	ND	ND	0.127	0.563			U	
N-EiFOSAA		2991-50-6	ND	ND	ND	0.0958	0.563			U	
Other		HFPO-DA	13252-13-6	2202.04	3.10	3.10	0.200	0.563			
	PFMOA	674-13-5	20917.77	29.4	29.4	1.27	1.27				
	PFMOPrA	377-73-1	35.32	0.0497	0.0497	0.211	0.563			L	
	PFO2HxA	39492-88-1	3594.20	5.05	5.05	1.27	1.27				
	PFO3OA	39492-89-2	662.96	0.932	0.932	1.27	1.27			L	
	PF04DA	39492-90-5	172.82	0.243	0.243	1.34	1.34			L	
	Nafion Byproduct 1	29311-67-9	ND	ND	ND	0.267	0.563			U	
	ADONA	919005-14-4	ND	ND	ND	0.105	0.533			U	
	9Cl-PF3ONS	756426-58-1	ND	ND	ND	0.105	0.524			U	
	11Cl-PF3OUdS	763051-92-9	ND	ND	ND	0.105	0.530			U	
	10:2 FTS	120226-60-0	ND	ND	ND	0.211	0.563			U	
	EVE Acid	69087-46-3	ND	ND	ND	1.27	1.27			U	
	FBSA	30334-69-1	544.28	0.765	0.765	0.211	0.563				
	Hydro-EVE Acid	773804-62-9	57.35	0.0807	0.0807	1.27	1.27			L	
	Hydrolyzed PSDA	2416366-19-1	3590.48	5.05	5.05	1.27	1.27				
	Hydrolyzed PSDA	2416366-19-1	2336.10	3.29	3.29	1.27	1.27				
	Nafion Byproduct 2	749836-20-2	287.58	0.404	0.404	0.267	0.563			J	
	N-EiFOSA	4151-50-2	ND	ND	ND	0.211	0.563			U	
	N-EiFOSE	1691-99-2	ND	ND	ND	6.33	6.33			U	
	NFDHA	151772-58-6	ND	ND	ND	0.211	0.563			U	
	N-MeFOSA	31506-32-8	ND	ND	ND	0.211	0.563			U	
	N-MeFOSE	24448-09-7	ND	ND	ND	6.33	6.33			U	
	NVHOS	1132933-86-8	2462.45	3.46	3.46	1.27	1.27				
	PEPA	267239-61-2	1018.35	1.43	1.43	1.27	1.27				
	PFECA-G	801212-59-9	ND	ND	ND	0.267	1.27			U	
	PFEEA	113507-82-7	ND	ND	ND	0.211	0.563			U	
	PFHxDA	67905-19-5	ND	ND	ND	1.27	1.27			U	
	PFMOBA	863090-89-5	ND	ND	ND	1.27	1.27			U	
	PFO5DA	39492-91-6	29.66	0.0417	0.0417	1.34	1.34			L	
	PMPA	13140-29-9	3210.70	4.52	4.52	1.27	1.27				
	R-EVE	2416366-22-6	2120.03	2.98	2.98	1.27	1.27				
	R-PSDA	2416366-18-0	8638.85	12.1	12.1	1.27	1.27				
	R-PSDCA	241636-21-5	38.21	0.0537	0.0537	1.27	1.27			L	
	ES	MPPFA		4647.65	6.54				20-150%	93.0%	
M5PFPeA			5938.97	8.35				20-150%	118.8%		
M3PFBS			7353.03	10.3				20-150%	147.1%		
M2-4:2 FTS			8728.09	12.3				20-150%	174.6%	Q	
M5PFHxA			3827.57	5.38				20-150%	76.6%		
M3HFPO-DA			4963.68	6.98				20-150%	99.3%		
M4PFHpA			4307.76	6.06				20-150%	86.2%		
M3PFHxS			5220.42	7.34				20-150%	104.4%		
M2-6:2 FTS			5419.62	7.62				20-150%	108.4%		
M8PFOA			3984.25	5.60				20-150%	79.7%		
M9PFNA			3222.71	4.53				20-150%	64.5%		
M8PFOS			3077.49	4.33				20-150%	61.5%		
M2-8:2 FTS			2504.25	3.52				20-150%	50.1%		
M8FOSA-I			1088.77	1.53				20-150%	21.8%		
M6PFDA			2273.83	3.20				20-150%	45.5%		
d3-N-MeFOSAA			1358.33	1.91				20-150%	27.2%		
d5-N-EiFOSAA			1203.86	1.69				20-150%	24.1%		
M7PFUdA			1483.23	2.09				20-150%	29.7%		
MPPDoA			1473.53	2.07				20-150%	29.5%		
M2PFTeDA			493.14	0.694				20-150%	9.9%	Q	
d3-N-MeFOSA			434.84	0.612				10-200%	4.3%	Q	
d5-N-EiFOSA			380.74	0.535				10-200%	3.8%	Q	
d7-N-MeFOSE			508.05	0.715				10-200%	5.1%	Q	
d9-N-EiFOSE			396.34	0.557				10-200%	4.0%	Q	

QC Data



Enthalpy Analytical

Job No.: 0922-778-1 PFAS by Isotope Dilution (non-potable water)

Brunswick County Public Utilities - NC Client Project: N/A Site: Northeast Water Plant Leland, NC

Enthalpy ID	MB-14037-PFAS	Prep Batch	EU14037	Sample Vol (mL)	250
Sample Name	MB-14037-PFAS	Prep Date	2022-09-23 15:18	Extract Vol (mL)	0.4
Matrix	aqueous	Analysis Date	9/25/2022 7:12:09 AM	Split Factor	N/A
Sampling Date		Analyst	brneff	Method Code	WM-026
Received Date		Instrument	Pippin	Sample Type	Blank

	Compound	CAS	Extract Concentration ng/L	Sample Concentration ng/L	Formalated Result ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags
Acids	PFBA	375-22-4	38.80	0.0621	0.0621	0.153	0.640			L
	PFPeA	2706-90-3	ND	ND	ND	0.170	0.640			U
	PFHxA	307-24-4	11.76	0.0188	0.0188	0.193	0.640			L
	PFHpA	375-85-9	ND	ND	ND	0.122	0.640			U
	PFOA	335-67-1	28.38	0.0454	0.0454	0.177	0.640			L
	PFNA	375-95-1	ND	ND	ND	0.0761	0.640			U
	PFDA	335-76-2	ND	ND	ND	0.0845	0.640			U
	PFUnDA	2058-94-8	ND	ND	ND	0.185	0.640			U
	PFDoDA	307-55-1	ND	ND	ND	0.202	0.640			U
	PFTriDA	72629-94-8	ND	ND	ND	0.151	0.640			U
	PFTeDA	376-06-7	ND	ND	ND	0.218	0.640			U
	PFBS	375-73-5	ND	ND	ND	0.355	0.747			U
	PFPeS	2706-91-4	ND	ND	ND	0.206	0.603			U
	PFHxS	355-46-4	47.29	0.0757	0.0757	0.191	0.586			L
Sulfonates	PFHpS	375-92-8	ND	ND	ND	0.135	0.610			U
	PFOS	1763-23-1	ND	ND	ND	0.160	0.593			U
	PFNS	68259-12-1	ND	ND	ND	0.0864	0.616			U
	PFDS	335-77-3	ND	ND	ND	0.192	0.616			U
	4:2 FTS	757124-72-4	ND	ND	ND	0.118	0.600			U
	6:2 FTS	27619-97-2	7.00	0.0112	0.0112	0.116	0.610			L
	8:2 FTS	39108-34-4	ND	ND	ND	0.171	0.613			U
	PFOSA	754-91-6	ND	ND	ND	0.130	0.640			U
	N-MeFOSAA	2355-31-9	ND	ND	ND	0.144	0.640			U
	N-EFOSAA	2991-50-6	ND	ND	ND	0.109	0.640			U
Other	HFPO-DA	13252-13-6	ND	ND	ND	0.228	0.640			U
	PFMOAA	674-13-5	ND	ND	ND	1.44	1.44			U
	PFMOPrA	377-73-1	ND	ND	ND	0.240	0.640			U
	PFO2HxA	39492-88-1	ND	ND	ND	1.44	1.44			U
	PFO3OA	39492-89-2	ND	ND	ND	1.44	1.44			U
	PF04DA	39492-90-5	ND	ND	ND	1.52	1.52			U
	Nafion Byproduct 1	29311-67-9	ND	ND	ND	0.304	0.640			U
	ADONA	919005-14-4	ND	ND	ND	0.120	0.606			U
	9Cl-PF3ONS	756426-58-1	ND	ND	ND	0.120	0.596			U
	11Cl-PF3OUdS	763051-92-9	ND	ND	ND	0.120	0.603			U
	10:2 FTS	120226-60-0	ND	ND	ND	0.240	0.640			U
	EVE Acid	69087-46-3	ND	ND	ND	1.44	1.44			U
	FBSA	30334-69-1	ND	ND	ND	0.240	0.640			U
	Hydro-EVE Acid	773804-62-9	ND	ND	ND	1.44	1.44			U
	Hydrolyzed PSDA	2416366-19-1	ND	ND	ND	1.44	1.44			U
	Hydrolyzed PSDA	2416366-19-1	ND	ND	ND	1.44	1.44			U
	Nafion Byproduct 2	749836-20-2	ND	ND	ND	0.304	0.640			U
	N-EFOSA	4151-50-2	ND	ND	ND	0.240	0.640			U
	N-EFOSE	1691-99-2	ND	ND	ND	7.20	7.20			U
	NFDHA	151772-58-6	ND	ND	ND	0.240	0.640			U
	N-MeFOSA	31506-32-8	ND	ND	ND	0.240	0.640			U
	N-MeFOSE	24448-09-7	ND	ND	ND	7.20	7.20			U
	NVHOS	1132933-86-8	ND	ND	ND	1.44	1.44			U
	PEPA	267239-61-2	ND	ND	ND	1.44	1.44			U
	PFECA-G	801212-59-9	ND	ND	ND	0.304	1.44			U
	PFEEA	113507-82-7	ND	ND	ND	0.240	0.640			U
	PFHxDA	67905-19-5	ND	ND	ND	1.44	1.44			U
	PFMOBA	863090-89-5	ND	ND	ND	1.44	1.44			U
	PFO5DA	39492-91-6	ND	ND	ND	1.52	1.52			U
	PMPA	13140-29-9	ND	ND	ND	1.44	1.44			U
	R-EVE	2416366-22-6	ND	ND	ND	1.44	1.44			U
	R-PSDA	2416366-18-0	ND	ND	ND	1.44	1.44			U
R-PSDCA	241636-21-5	ND	ND	ND	1.44	1.44			U	
ES	MPPFA		4297.08	6.88				20-150%	85.9%	
	M5PFPeA		4425.85	7.08				20-150%	88.5%	
	M3PFBS		3953.14	6.33				20-150%	79.1%	
	M2-4:2 FTS		3585.85	5.74				20-150%	71.7%	
	M5PFHxA		4286.53	6.86				20-150%	85.7%	
	M3HFPO-DA		5823.63	9.32				20-150%	116.5%	
	M4PFHpA		4270.65	6.83				20-150%	85.4%	
	M3PFHxS		5990.56	9.58				20-150%	119.8%	
	M2-6:2 FTS		3784.47	6.06				20-150%	75.7%	
	M8PFOA		4487.35	7.18				20-150%	89.7%	
	M9PFNA		3701.06	5.92				20-150%	74.0%	
	M8PFOS		3859.27	6.17				20-150%	77.2%	
	M2-8:2 FTS		3462.87	5.54				20-150%	69.3%	
	M8FOSA-I		1606.78	2.57				20-150%	32.1%	
	M6PFDA		3363.59	5.38				20-150%	67.3%	
	d3-N-MeFOSAA		2196.82	3.51				20-150%	43.9%	
	d5-N-EFOSAA		2009.28	3.21				20-150%	40.2%	
	M7PFUdA		2692.55	4.31				20-150%	53.9%	
	MPPDoA		3155.77	5.05				20-150%	63.1%	
	M2PFTeDA		863.76	1.38				20-150%	17.3%	Q
	d3-N-MeFOSA		313.06	0.501				10-200%	3.1%	Q
	d5-N-EFOSA		204.04	0.326				10-200%	2.0%	Q
	d7-N-MeFOSE		722.24	1.16				10-200%	7.2%	Q
d9-N-EFOSE		456.59	0.731				10-200%	4.6%	Q	

Enthalpy Analytical

Job No.: 0922-778-1 PFAS by Isotope Dilution (non-potable water)

Brunswick County Public Utilities - NC Client Project: N/A Site: Northeast Water Plant Leland, NC

Enthalpy ID	OPR-14037-PFAS	Prep Batch	EU14037	Sample Vol (mL)	250
Sample Name	OPR-14037-PFAS	Prep Date	2022-09-23 15:18	Extract Vol (mL)	0.4
Matrix	aqueous	Analysis Date	9/25/2022 7:34:57 AM	Split Factor	N/A
Sampling Date		Analyst	brneff	Method Code	WM-026
Received Date		Instrument	Pippin	Sample Type	Control

	Compound	CAS	Extract Concentration ng/L	Sample Concentration ng/L	Formatted Result ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags
Acids	PFBA	375-22-4	11206.31	17.9	17.9	0.153	0.640	73-129%	89.7%	
	PFPeA	2706-90-3	11491.64	18.4	18.4	0.170	0.640	72-129%	91.9%	
	PFHxA	307-24-4	10878.23	17.4	17.4	0.193	0.640	72-129%	87.0%	
	PFHpA	375-85-9	11906.63	19.1	19.1	0.122	0.640	72-130%	95.3%	
	PFOA	335-67-1	10781.11	17.2	17.2	0.177	0.640	71-133%	86.2%	
	PFNA	375-95-1	10004.22	16.0	16.0	0.0761	0.640	69-130%	80.0%	
	PFDA	335-76-2	12259.21	19.6	19.6	0.0845	0.640	71-129%	98.1%	
	PFUnDA	2058-94-8	10566.44	16.9	16.9	0.185	0.640	69-133%	84.5%	
	PFDoDA	307-55-1	9935.89	15.9	15.9	0.202	0.640	72-134%	79.5%	
	PFTeDA	72629-94-8	36452.95	58.3	58.3	0.151	0.640	65-144%	291.6%	Q
Sulfonates	PFBs	375-73-5	9607.32	15.4	15.4	0.355	0.747	72-134%	86.7%	
	PFPeS	2706-91-4	11376.46	18.2	18.2	0.206	0.603	71-127%	96.7%	
	PFHxS	355-46-4	9710.13	15.5	15.5	0.191	0.586	68-131%	85.0%	
	PFHpS	375-92-8	14858.08	23.8	23.8	0.135	0.610	69-134%	124.7%	
	PFOS	1763-23-1	11038.27	17.7	17.7	0.160	0.593	65-140%	95.2%	
	PFNS	68259-12-1	9345.67	15.0	15.0	0.0864	0.616	69-127%	77.7%	
	PFDS	335-77-3	6037.43	9.66	9.66	0.192	0.616	53-142%	50.1%	Q
	4:2 FTS	757124-72-4	9442.24	15.1	15.1	0.118	0.600	63-143%	80.6%	
	6:2 FTS	27619-97-2	9977.39	16.0	16.0	0.116	0.610	64-140%	83.9%	
	8:2 FTS	39108-34-4	12994.50	20.8	20.8	0.171	0.613	67-138%	108.3%	
Other	PFOSA	754-91-6	11946.62	19.1	19.1	0.130	0.640	67-137%	95.6%	
	N-MeFOSAA	2355-31-9	10922.99	17.5	17.5	0.144	0.640	65-136%	87.4%	
	N-EtFOSAA	2991-50-6	11033.36	17.7	17.7	0.109	0.640	61-135%	88.3%	
ES	HFPO-DA	13252-13-6	9887.00	15.8	15.8	0.228	0.640	70-130%	79.1%	
	MPFBA		4400.08	7.04				20-150%	88.0%	
	M5PFPeA		4117.74	6.59				20-150%	82.4%	
	M3PFBs		3669.43	5.87				20-150%	73.4%	
	M2-4:2 FTS		4027.93	6.44				20-150%	80.6%	
	M5PFHxA		4412.63	7.06				20-150%	88.3%	
	M3HFPO-DA		6191.11	9.91				20-150%	123.8%	
	M4PFHpA		4143.15	6.63				20-150%	82.9%	
	M3PFHxS		5643.05	9.03				20-150%	112.9%	
	M2-6:2 FTS		4370.05	6.99				20-150%	87.4%	
	M8PFOA		4355.75	6.97				20-150%	87.1%	
	M9PFNA		3420.16	5.47				20-150%	68.4%	
	M8PFOS		3333.13	5.33				20-150%	66.7%	
	M2-8:2 FTS		2988.04	4.78				20-150%	59.8%	
	M8FOSA-I		1460.05	2.34				20-150%	29.2%	
	M6PFDA		2456.44	3.93				20-150%	49.1%	
	d3-N-MeFOSAA		1852.84	2.96				20-150%	37.1%	
	d5-N-EtFOSAA		1551.73	2.48				20-150%	31.0%	
	M7PFUdA		1723.37	2.76				20-150%	34.5%	
	MPFDoA		1606.80	2.57				20-150%	32.1%	
M2PFTeDA		194.45	0.311				20-150%	3.9%	Q	

Narrative Summary



Enthalpy Analytical Narrative Summary

Company	Brunswick County Public Utilities - NC
Job No.	0922-778-1 PFAS by Isotope Dilution (non-potable water)
Client ID.	N/A Site: Northeast Water Plant - Leland, NC

1. Custody

Josie Morton received the samples on September 22, 2022 at 17.8 °C after being relinquished by Brunswick County Public Utilities - NC. The samples were received in good condition.

Prior to, during, and after analysis, the samples were kept under lock with access only to authorized personnel by Enthalpy Analytical, LLC.

Table 1 - Sample Inventory

EU Lab Sample ID	Client Sample ID	Matrix
0922-778-001-1	092222S01	AQ
0922-778-002-1	092222E01	AQ

2. Methods and Analytes

A list of analytes of interest and corresponding methods of analysis is shown in Table 3. Abbreviations are defined in the listed Appendices.

Table 3 - Methods and Analytes

EU Method	Analytes	Cleanup Method
EU-047	Brunswick PFAS List	ENVI-Carb

3. Analysis

The samples were analyzed using Waters Acquity UPLC equipped with Xevo TQ MS (LC/MS/MS "Pippin").

For aqueous samples, the sample volume was measured gravimetrically by the laboratory, and spiked with Extraction Standard (ES). The sample was then mixed well and centrifuged, if needed. The samples were then extracted via SPE, and the extracts were cleaned up using ENVI-Carb.

Each final sample extract was transferred to an autosampler vial, spiked with Injection Standard (IS), and brought to a final volume of 400µL prior to analysis.

Samples that were run in more than one sequence and their comments are as follows:

092222S01, 092222E01

The samples were analyzed on more than one instrument sequence in order to include all of the analytes of interest and to meet method acceptance criteria.

4. Calibration

In the initial calibration, the reported analytes exhibited R² of ≥ 0.99.

Enthalpy Analytical Narrative Summary

Company	Brunswick County Public Utilities - NC
Job No.	0922-778-1 PFAS by Isotope Dilution (non-potable water)
Client ID.	N/A Site: Northeast Water Plant - Leland, NC

4. Calibration, continued

Except where noted below, the reported analytes in the calibration standards, continuing calibration (concal) and Initial Calibration Verification (ICV) met the 30% accuracy criterion for native analytes.

PFO4DA, Nafion Byproduct 1, NFDHA, PFO5DA 10:2 FTS fell outside method control limits in one or more concals. These analytes were not detected in the samples; therefore, the data is reportable without adverse impact.

The Technical Director extended the method criteria for certain non-legacy analytes that do not have their own internal standard and exhibit observed variability during calibration.

5. QC Notes

Except where noted below, the QC sample analyses passed all method criteria.

QC samples that did not meet method acceptance criteria were:

OPR-14037-PFAS PFDS - fell below method recovery criteria but within marginal exceedance guidelines. This analyte was not detected in the samples and the data is reported with no adverse impact.

OPR-14037-PFAS PFTrDA - fell above method recovery criteria. This analyte was not detected in the samples and the data is reported with no adverse impact.

MB-14037-PFAS d3-N-MeFOSA, MB-14037-PFAS d5-N-EtFOSA, MB-14037-PFAS d7-N-MeFOSE, MB-14037-PFAS d9-N-EtFOSE, MB-14037-PFAS M2PFTeDA, OPR-14037-PFAS M2PFTeDA

Labeled standard in the method blank (MB) and OPR that fell above the control limits for ES recovery are denoted by the "Q" qualifier. The target analytes are quantified based on their ratio to their labeled standard analogs. As a result, low or high labeled standard recovery do not cause any change to ratios or contribute any additional error in the measurement of the target analytes. The data is reported without adverse impact.

The samples were extracted within the 28-day from collection holding time and analyzed within the 28-day from extraction to analysis holding time required by the method.

Samples received above 6 °C, client notified in order acknowledgement documentation.

Enthalpy Analytical Narrative Summary

Company	Brunswick County Public Utilities - NC
Job No.	0922-778-1 PFAS by Isotope Dilution (non-potable water)
Client ID.	N/A Site: Northeast Water Plant - Leland, NC

6. Reporting Notes

This report provides all results including detections below LOD following client instruction.

Some labeled extraction standards in the sample analyses fell outside the control limits for ES recovery, as denoted by the "Q" qualifier. The target analytes are quantified based on their ratio to their labeled standard analogs. As a result, low or high labeled standard recovery do not cause any change to ratios or contribute any additional error in the measurement of the target analytes. When detected at a signal-to-noise above 10:1 the ES peak area is used to quantify its respective target analyte using accepted isotope dilution principles. The data is reported without adverse impact.

6. Reporting Notes, continued

The results presented in this report are representative of the samples as provided to the laboratory.

These analyses met the requirements of the TNI Standard. Any deviations from the requirements of the reference method or TNI Standard have been stated above.

Enthalpy Analytical, LLC in Wilmington NC is accredited by the Louisiana Department of Environmental Quality to the 2009 TNI Standard under certificate number 05075.



General Reporting Notes – Data Qualifiers

The following are general reporting notes that are applicable to all Enthalpy Analytical, LLC - Wilmington, NC data reports, unless specifically noted otherwise.

General Data Qualifiers

- B – The analyte was found in the method blank, at a concentration that was at least 10% of the amount in the sample.
- Cxx – Two or more congeners co-elute. In EDDs, C denotes the lowest IUPAC congener in a co-elution group and additional co-eluters for the group ('xx') are shown with the number of the lowest IUPAC co-eluter.
- E – The reported concentration exceeds the calibration range (upper point of the calibration curve). For HRMS data, this condition does not imply additional measurement uncertainty. For LC-MS/MS data, these values should be considered as having measurement uncertainty higher than values within the calibration range.
- EDL – Estimated Detection Level: The EDL is unique to isotope dilution methods and reflects the conditions of analysis at the time of analysis, including the equipment used. Where the MDL is a static value, the EDL is a dynamic value.
- EMPC – Estimated Maximum Possible Concentration: EMPC is specific to Dioxin/Furan tests to indicate the determined ion-abundance ratio was outside the allowed theoretical range (usually due to being near the detection limit, although it can very rarely be caused by a co-eluting interference). The EMPC concentration is adjusted to reflect the value at the theoretical ion-abundance ratio.
- IR – The ion ratio between the primary and secondary ions was observed to be outside the method criteria. The analyte concentration may be inaccurate due to interference.
- J – The analyte has a concentration below the minimum calibration level (LOQ value) but greater than the LOD. These values should be considered as having measurement uncertainty higher than values within the calibration range
- L - Indicates that an analyte has a concentration below the Minimum Detection Limit (MDL). The reported concentration is not recommended for regulatory use as the analyte signal may have a signal-to-noise ratio less than the criteria deemed necessary to be considered a detected analyte.
- LOD – Limit of Detection: For reports conforming to the DOD ELAP QSM, this is the QSM-defined LOD. For reports conforming to TNI requirements (but not DOD ELAP QSM requirements), this value is the minimum detection limit (MDL). The LOD is adjusted for sample weight or volume.
- LOQ – Limit of Quantitation: For reports conforming to the DOD ELAP QSM, this is the QSM-defined LOQ. For reports conforming to TNI requirements (but not DOD ELAP QSM requirements), this value is the reporting limit (RL). The LOQ is adjusted for sample weight or volume.

General Reporting Notes – Data Qualifiers

- <LOD() – Analyte was not found at a concentration high enough to be reported as detected. It is reported as less than the LOD, and the LOD is given in the parentheses.
- <LOQ() – Analyte was not found at a concentration high enough to be reported as above the QSM-defined LOQ or TNI defined Reporting Limit. It is reported as less than the LOQ, and the LOQ is given in the parentheses.
- ND – Indicates a non-detect.
- NR – Indicates a value that is not reportable due to issues observed in sample preparation or analysis.
- PR – The associated congener(s) is(are) poorly resolved.
- QI – Indicates the presence of a quantitative interference.
- RL – Reporting Limit. Lowest reportable value. The level is higher than the MDL.
- SI – Denotes “Single Ion Mode” and is utilized for PCBs where the secondary ion trace has a significantly elevated noise level due to background PFK. Responses for such peaks are calculated using an EMPC approach based solely on the primary ion area(s) and may be considered estimates.
- U – The analyte was not detected.
- V / Q – The labeled standard recovery is not within method control limits.
- X – Indicates the result is from re-injection/repeat/second-column analysis.

Lab Identifiers/ Data Attributes

- AR – Indicates use of the archived portion of the sample extract.
- CU – Indicates a sample that required additional clean-up prior to HRMS injection/processing.
- D – Dilution Data. Result was obtained from the analysis of a dilution. The number that follows the “D” indicates the dilution factor.
- DE – Indicates a dilution performed with the addition of ES (Extraction Standard) solution.
- DUP – Designation for a duplicate sample.
- MS – Designation for a matrix spike.
- MSD – Designation for a matrix spike duplicate.
- R – Indicates a re-extraction of the sample.
- RJ – Indicates a reinjection of the sample extract.



General Reporting Notes – Data Qualifiers

- S – Indicates a sample split. The number that follows the “S” indicates the split factor.
- SAT – Indicates an analyte saturated the detector.

PFAS Compound Acronym List		
Acronym	CAS #	Compound Name
Target Analytes		
* Analyte is not accredited		
PFBA	375-22-4	Perfluorobutanoic Acid
PFPeA	2706-90-3	Perfluoropentanoic Acid
PFHxA	307-24-4	Perfluorohexanoic Acid
PFHpA	375-85-9	Perfluoroheptanoic Acid
PFOA	335-67-1	Perfluorooctanoic Acid
PFNA	375-95-1	Perfluorononanoic Acid
PFDA	335-76-2	Perfluorodecanoic acid
PFUnA (PFUnDA)	2058-94-8	Perfluoroundecanoic acid
PFDoA (PFDoDA)	307-55-1	Perfluorododecanoic acid
PFTriA (PFTriA)	72629-94-8	Perfluorotridecanoic acid
PFTeDA (PFTA)	376-06-7	Perfluorotetradecanoic acid
PFBS	375-73-5	Perfluorobutane sulfonic acid
PFPeS	2706-91-4	Perfluoropentane sulfonic acid
PFHxS	355-46-4	Perfluorohexane sulfonic acid
PFHpS	375-92-8	Perfluoroheptane sulfonic acid
PFOS	1763-23-1	Perfluorooctane sulfonic acid
PFNS	68259-12-1	Perfluorononane sulfonic acid
PFDS	335-77-3	Perfluorodecane sulfonic acid
4:2 FTS	757124-72-4	4:2 fluorotelomer sulfonic acid
6:2 FTS	27619-97-2	6:2 fluorotelomer sulfonic acid
8:2 FTS	39108-34-4	8:2 fluorotelomer sulfonic acid
PFOSA (FOSA)	754-91-6	Perfluorooctane sulfonamide
N-MeFOSAA	2355-31-9	N-methyl perfluorooctane sulfonamido acetic acid
N-EtFOSAA	2991-50-6	N-ethyl perfluorooctane sulfonamido acetic acid
HFPO-DA	13252-13-6	2,3,3,3-Tetrafluoro-2-(1,1,2,2,3,3,3-heptafluoropropoxy)-propanoic acid (Gen-X)
11CI-PF3OUdS	763051-92-9	11-chloroeicosafluoro-3-oxaundecane-1-sulfonic acid
9CI-PF3ONS	756426-58-1	9-chlorohexadecafluoro-3-oxanonane-1-sulfonic acid
ADONA	919005-14-4	4,8-dioxa-3H-perfluorononanoic acid
PFEESA	113507-82-7	Perfluoro(2-ethoxyethane)sulphonic acid
PFMOBA (PFMBA)	863090-89-5	Perfluoro-4-methoxybutanic acid
NFDHA	151772-58-6	Nonafluoro-3,6-dioxaheptanoic acid
PFMOPra (PFMPA)	377-73-1	Perfluoro-3-methoxypropanoic acid
* PFMOAA	674-13-5	Perfluoro-2-methoxyacetic acid
* PFO2HxA	39492-88-1	Perfluoro (3,5-dioxaheptanoic) acid
* PFO3OA	39492-89-2	Perfluoro (3,5,7-trioxaoctanoic) acid
* PFO4DA	39492-90-5	Perfluoro (3,5,7,9-tetraoxadecanoic) acid
* PFO5DA	39492-91-6	Perfluoro(3,5,7,9,11-pentaoxadodecanoic) acid
* Nafion Byproduct 1	29311-67-9	Nafion Byproduct 1
* Nafion Byproduct 2	749836-20-2	Nafion Byproduct 2
* PEPA	267239-61-2	Perfluoro-2-ethoxypropanoic acid
* PMPA	13140-29-9	Perfluoro-2-methoxypropanoic acid
* 10:2 FTS	120226-60-0	Fluorotelomer sulfonate 10:2
* N-EtFOSA	4151-50-2	N-ethylperfluoro-1-octanesulfonamide
* N-EtFOSE	1691-99-2	2-(N-methylperfluoro-1-octanesulfonamido)-ethanol
* N-MeFOSA	31506-32-8	N-methylperfluoro-1-octanesulfonamide
* N-MeFOSE	24448-09-7	2-(N-methylperfluoro-1-octanesulfonamido)-ethanol
* PFECA-G	801212-59-9	4-(Heptafluoroisopropoxy)hexafluorobutanoic acid
* PFHxDA	67905-19-5	Perfluorohexadecanoic acid
* R-PSDA (Nafion Byproduct 4)	2416366-18-0	Perfluoro-4-(2-sulfoethoxy)pentanoic acid

PFAS Compound Acronym List		
Acronym	CAS #	Compound Name
Target Analytes		
* Analyte is not accredited		
* Hydrolyzed PSDA (Nafion Byproduct 5)	2416366-19-1	2-fluoro-2-[1,1,2,3,3,3-hexafluoro-2-(1,1,2-tetrafluoro-2-sulfoethoxy)propoxy]-acetic acid
* R-PSDCA (Nafion Byproduct 6)	2416366-21-5	1,1,2,2-tetrafluoro-2-[1,2,2,3,3-pentafluoro-1-(trifluoromethyl)propoxy] ethanesulfonic acid
* EVE Acid	69087-46-3	2,2,3,3-tetrafluoro-3-({1,1,1,2,3,3-hexafluoro-3-[(1,2,2-trifluoroethenyl)oxy]propan-2-yl)oxy}propionic acid
* FBSA	30334-69-1	Perfluorobutylsulfonamide
* Hydro-EVE Acid	773804-62-9	2,2,3,3-Tetrafluoro-3-{{1,1,1,2,3,3-hexafluoro-3-(1,2,2,2-tetrafluoroethoxy)propan-2-yl}oxy}propanoic acid
* R-EVE Acid	2416366-22-6	4-(2-carboxy-1,1,2,2-tetrafluoroethoxy)-2,2,3,3,4,5,5,5-octafluoro-pentanoic acid
* NVHOS	1132933-86-8	Perfluoroethoxysulfonic acid
* PFDoS	79780-39-5	Perfluorododecane sulfonic acid
* PFOA	16517-11-6	Perfluorooctadecanoic acid
* 3:3 FTCA	356-02-5	2H,2H,3H,3H-Perfluorohexanoic acid
* 5:3 FTCA	914637-49-3	2H,2H,3H,3H-Perfluorooctanoic acid
* 7:3 FTCA	812-70-4	2H,2H,3H,3H-Perfluorodecanoic acid
* N-AP-FHxSA	50598-28-2	N-(3-(Dimethylamino)propyl)tridecafluoro-1-hexanesulfonamide
* N-CMAmP-6:2 FOSA	34455-29-3	N-(Carboxymethyl)-N,N-dimethyl-3-(((3,3,4,4,5,5,6,6,7,7,8,8,8-tridecafluorooctyl)sulfonyl)amino)1-propanaminium

Sample Custody





Chain of Custody Record

0922-778

Enthalpy Ultratrace Job#: _____ COC Page 1 of 1

Special Handling:

- Standard Turn Around Time
- Rush Turn Around Time -- Date Needed _____
- All Fast TATs Subject to Approval by Enthalpy Analytical, Inc.
- All Samples Disposed of After 6 months Unless Otherwise Instructed.

Enthalpy Analytical-Wilmington, NC has added enhancements to standard methods to improve accuracy, precision and permit an assessment of laboratory performance in the context of your specific data needs. For more information email Cindy.James@enthalpy.com.

Client Name: BRUNSWICK COUNTY UTILITIES
 Project Manager: GLENN WALKER
 Report To: SAME

Project Number: _____
 Site Name: NORTHWEST WATER PLANT
 Location: LELAND N.C.

PO#: _____
 Telephone#: _____
 Email: _____

This Chain of Custody is applicable to Non-Air samples. Standard TAT differ per analysis and are provided by request.

Client Special Instructions:

Matrix: GW-Groundwater, WW-Wastewater, NW-Non-Potable Water, DW-Drinking Water, S-Soil, SL-Sludge, BT-Biological Tissue, O-Other

Type: G=Grab C=Composite Q=Quality Control

Sample ID	Date	Time	Sample Volume	Type	Matrix	Sample Containers				Analyses:							Notes:	
						# of Bottles	# of Jars	# of Bags	# Other	Method 1613	Method 8290	Method 1668A/B/C PCB	PFAS by LC/MS/MS	PAHs by HRGC/HRMS	Sample on Hold	Method 23		ALL PFAS
092222S01	9/22/2022	0920	250 ml	G	NW	2												X
092222E01	9/22/2022	0920	250 ml	G	DW	2												X
<p>Courier, cooler, on ice, no seals, good condition from 9-22-22</p>																		

Relinquished By:

Thad Hill

Date:

9/22/2022

Received By:

Josie M

Date:

9-22-22

Time:

1000

Sample Temperature Upon Receipt:

Iced Ambient °C 17.8 T10

Iced Ambient °C _____

Iced Ambient °C _____

**This Is The Last Page
Of This Report.**

