

Brunswick County Public Utilities - NC

3954 Clearwell Dr NE
Leland, NC 28451

Northwest Water Plant

Leland, NC

Samples Received: 07/08/22

Analytical Report 0722-721

Isotope Dilution Method PFAS



Enthalpy Analytical, LLC – Ultratrace

Mark Hager

O: 910-876-6894/ F: 910-212-6886

mark.hager@enthalpy.com / www.enthalpy.com

2714 Exchange Drive, Wilmington, NC 28405

I certify that to the best of my knowledge all analytical data presented in this report:

- Have been checked for completeness
- Are accurate, error-free, and legible
- Have been conducted in accordance with approved protocol, and that all deviations and analytical problems are summarized in the appropriate narrative(s)

This analytical report was prepared in Portable Document Format (.PDF) and contains _____ pages.

Report Issued Date: _____



Summary of Results

Enthalpy Analytical

Job No.: 0722-721-2 PFAS by Isotope Dilution (non-potable water)

Brunswick County Public Utilities - NC Client Project: N/A Site: Northwest Water Plant

Summary

	Compound	CAS	070822-SO1 ng/L	070822-EO1 ng/L
Acids	PFBA	375-22-4	6.41	4.78
	PFPeA	2706-90-3	14.1	12.4
	PFHxA	307-24-4	8.58	7.73
	PFHpA	375-85-9	3.54	3.38
	PFOA	335-67-1	6.21	5.82
	PFNA	375-95-1	0.935	0.830
	PFDA	335-76-2	0.582	0.520 J
	PFUnDA	2058-94-8	0.108 L	0.108 L
	PFDoDA	307-55-1	0.0961 L	0.0235 LB
	PFTTrDA	72629-94-8	0.0542 LB	ND U
Sulfonates	PFTeDA	376-06-7	0.0593 L	ND U
	PFBS	375-73-5	5.63	4.39
	PFPeS	2706-91-4	0.986	0.843
	PFHxS	355-46-4	6.32	5.32
	PFHpS	375-92-8	ND U	0.00784 L
	PFOS	1763-23-1	13.8	13.1
	PFNS	68259-12-1	ND U	ND U
	PFDS	335-77-3	0.00678 L	ND U
	4:2 FTS	757124-72-4	ND U	ND U
	6:2 FTS	27619-97-2	0.167 J	0.285 J
Other	8:2 FTS	39108-34-4	ND U	ND U
	PFOSA	754-91-6	0.0815 L	0.0520 L
	N-MeFOSAA	2355-31-9	ND U	ND U
	N-EtFOSAA	2991-50-6	ND U	ND U
	HFPO-DA	13252-13-6	10.2	11.3
	PFMOAA	674-13-5	96.1	79.0
	PFMOPrA	377-73-1	ND U	ND U
	PFO2HxA	39492-88-1	12.6	12.6
	PFO3OA	39492-89-2	3.43	4.14
	PFO4DA	39492-90-5	0.338 L	ND U
	Nafion Byproduct 1	29311-67-9	ND U	ND U
	ADONA	919005-14-4	ND U	ND U
	9Cl-PF3ONS	756426-58-1	ND U	ND U
	11Cl-PF3OUdS	763051-92-9	ND U	ND U
	10:2 FTS	120226-60-0	ND U	ND U
	EVE Acid	69087-46-3	ND U	ND U
	FBSA	30334-69-1	1.22	0.858
	Hydro-EVE Acid	773804-62-9	0.537 L	0.467 L
	Hydrolyzed PSDA	2416366-19-1	6.17	9.12
	Nafion Byproduct 2	749836-20-2	0.530 J	0.723
	N-EtFOSA	4151-50-2	ND U	ND U
	N-EtFOSE	1691-99-2	ND U	ND U
	NFDHA	151772-58-6	ND U	ND U
	N-MeFOSA	31506-32-8	ND U	ND U
	N-MeFOSE	24448-09-7	ND U	ND U
	NVHOS	1132933-86-8	14.0	13.7
	PEPA	267239-61-2	7.22	7.74
	PFECA-G	801212-59-9	ND U	ND U
	PFEESA	113507-82-7	ND U	ND U
	PFHxDA	67905-19-5	ND U	ND U
	PFMOBA	863090-89-5	ND U	ND U
	PFO5DA	39492-91-6	ND U	ND U
	PMPA	13140-29-9	7.09	8.43
	R-EVE	2416366-22-6	7.00	7.76
	R-PSDA	2416366-18-0	17.2	19.8
	R-PSDCA	2416366-21-5	0.199 L	0.198 L

Detailed Results

Enthalpy Analytical

Job No.: 0722-721-2 PFAS by Isotope Dilution (non-potable water)

Brunswick County Public Utilities - NC Client Project: N/A Site: Northwest Water Plant

Enthalpy ID	0722-721-001-1	Prep Batch	EU13670	Sample Vol (mL)	290.54
Sample Name	070822-SO1	Prep Date	2022-07-12 12:25	Extract Vol (mL)	0.4
Matrix	Aqueous	Analysis Date	2022-07-13 23:09	Split Factor	N/A
Sampling Date	20220708 00:00	Analyst	rappelle	Method Code	WM-026
Received Date	2022-07-08 15:00	Instrument	Killi	Sample Type	Sample

	Compound	CAS	Extract Concentration ng/L	Sample Concentration ng/L	Formatted Result ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags
Acids	PFBA	375-22-4	4655.99	6.41	6.41	0.132	0.551			
	PFPeA	2706-90-3	10255.08	14.1	14.1	0.146	0.551			
	PFFhxA	307-24-4	6235.04	8.58	8.58	0.166	0.551			
	PFFHpA	375-85-9	2569.57	3.54	3.54	0.105	0.551			
	PFOA	335-67-1	4507.86	6.21	6.21	0.152	0.551			
	PFNA	375-95-1	679.41	0.935	0.935	0.0655	0.551			
	PFDA	335-76-2	422.80	0.582	0.582	0.0727	0.551			
	PFUnDA	2058-94-8	78.29	0.108	0.108	0.159	0.551			L
	PFDODA	307-55-1	69.80	0.0961	0.0961	0.174	0.551			L
	PFTriDA	72629-94-8	39.40	0.0542	0.0542	0.130	0.551			LB
Sulfonates	PFTeDA	376-06-7	43.06	0.0593	0.0593	0.188	0.551			L
	PFBS	375-73-5	4089.52	5.63	5.63	0.305	0.643			
	PFPeS	2706-91-4	716.29	0.986	0.986	0.177	0.519			
	PFFhS	355-46-4	4588.92	6.32	6.32	0.164	0.504			
	PFFHpS	375-92-8	ND	ND	ND	0.116	0.525			U
	PFOS	1763-23-1	10014.39	13.8	13.8	0.138	0.510			
	PFNS	68259-12-1	ND	ND	ND	0.0743	0.530			U
	PFDS	335-77-3	4.92	0.00678	0.00678	0.165	0.530			L
	4:2 FTS	757124-72-4	ND	ND	ND	0.102	0.516			U
	6:2 FTS	27619-97-2	120.97	0.167	0.167	0.0998	0.525			J
Other	8:2 FTS	39108-34-4	ND	ND	ND	0.147	0.528			U
	PFOSA	754-91-6	59.22	0.0815	0.0815	0.112	0.551			L
	N-MeFOSAA	2355-31-9	ND	ND	ND	0.124	0.551			U
	N-EiFOSAA	2991-50-6	ND	ND	ND	0.0938	0.551			U
	HFPO-DA	13252-13-6	7402.94	10.2	10.2	0.196	0.551			
	PFMOAA	674-13-5	69838.17	96.1	96.1	1.24	1.24			
	PFMOPrA	377-73-1	ND	ND	ND	0.207	0.551			U
	PFO2HxA	39492-88-1	9155.79	12.6	12.6	1.24	1.24			
	PF03OA	39492-89-2	2488.37	3.43	3.43	1.24	1.24			
	PF04DA	39492-90-5	245.69	0.338	0.338	1.31	1.31			L
	Nafion Byproduct 1	29311-67-9	ND	ND	ND	0.262	0.551			U
	ADONA	919005-14-4	ND	ND	ND	0.103	0.522			U
	9Cl-PF3ONS	756426-58-1	ND	ND	ND	0.103	0.513			U
	11Cl-PF3OUdS	763051-92-9	ND	ND	ND	0.103	0.519			U
	10:2 FTS	120226-60-0	ND	ND	ND	0.207	0.551			U
	EVE Acid	69087-46-3	ND	ND	ND	1.24	1.24			U
	FBSA	30334-69-1	883.28	1.22	1.22	0.207	0.551			
	Hydro-EVE Acid	773804-62-9	390.31	0.537	0.537	1.24	1.24			L
	Hydrolyzed PSDA	2416366-19-1	4479.29	6.17	6.17	1.24	1.24			
	Nafion Byproduct 2	749836-20-2	384.75	0.530	0.530	0.262	0.551			J
	N-EiFOSA	4151-50-2	ND	ND	ND	0.207	0.551			U
	N-EiFOSE	1691-99-2	ND	ND	ND	6.20	6.20			U
	NFDHA	151772-58-6	ND	ND	ND	0.207	0.551			U
	N-MeFOSA	31506-32-8	ND	ND	ND	0.207	0.551			U
	N-MeFOSE	24448-09-7	ND	ND	ND	6.20	6.20			U
	NVHOS	1132933-86-8	10172.14	14.0	14.0	1.24	1.24			
	PEPA	267239-61-2	5241.21	7.22	7.22	1.24	1.24			
	PFECA-G	801212-59-9	ND	ND	ND	0.262	1.24			U
	PFEESA	113507-82-7	ND	ND	ND	0.207	0.551			U
	PFFhDA	67905-19-5	ND	ND	ND	1.24	1.24			U
	PFMOBA	863090-89-5	ND	ND	ND	1.24	1.24			U
	PFO5DA	39492-91-6	ND	ND	ND	1.31	1.31			U
	PMPA	13140-29-9	5150.89	7.09	7.09	1.24	1.24			
	R-EVE	2416366-22-6	5082.58	7.00	7.00	1.24	1.24			
	R-PSDA	2416366-18-0	12482.06	17.2	17.2	1.24	1.24			
	R-PSDCA	2416366-21-5	144.58	0.199	0.199	1.24	1.24			L
ES	MPFBA		5312.52	7.31				20-150%	106.3%	
	M5PFPeA		8879.77	12.2				20-150%	177.6%	Q
	M3PFBS		12749.44	17.6				20-150%	255.0%	Q
	M2-4:2 FTS		10899.47	15.0				20-150%	218.0%	Q
	M5PFFhxA		4778.64	6.58				20-150%	95.6%	
	M3HFPO-DA		6423.35	8.84				20-150%	128.5%	
	M4PFFHpA		5382.14	7.41				20-150%	107.6%	
	M3PFFhS		5869.78	8.08				20-150%	117.4%	
	M2-6:2 FTS		12467.80	17.2				20-150%	249.4%	Q
	M8PFOA		5390.22	7.42				20-150%	107.8%	
	M9PFNA		5264.46	7.25				20-150%	105.3%	
	M8PFOS		5338.25	7.35				20-150%	106.8%	
	M2-8:2 FTS		9314.29	12.8				20-150%	186.3%	Q
	M8FOSA-I		4797.29	6.60				20-150%	95.9%	
	M6PFDA		5706.07	7.86				20-150%	114.1%	
	d3-N-MeFOSAA		5062.11	6.97				20-150%	101.2%	
	d5-N-EiFOSAA		4665.42	6.42				20-150%	93.3%	
	M7PFUdA		4918.18	6.77				20-150%	98.4%	
	MPFDoA		3913.75	5.39				20-150%	78.3%	
	M2PFTeDA		1357.08	1.87				20-150%	27.1%	

Enthalpy Analytical

Job No.: 0722-721-2 PFAS by Isotope Dilution (non-potable water)

Brunswick County Public Utilities - NC Client Project: N/A Site: Northwest Water Plant

Enthalpy ID 0722-721-002-1
Sample Name 070822-EO1
Matrix Aqueous
Sampling Date 20220708 00:00
Received Date 2022-07-08 15:00

Prep Batch EU13670
Prep Date 2022-07-12 12:25
Analysis Date 2022-07-13 23:32
Analyst rappelle
Instrument Killi

Sample Vol (mL) 292.99
Extract Vol (mL) 0.4
Split Factor N/A
Method Code WM-026
Sample Type Sample

	Compound	CAS	Extract Concentration ng/L	Sample Concentration ng/L	Formatted Result ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags
Acids	PFBA	375-22-4	3503.17	4.78	4.78	0.131	0.546			
	PFPeA	2706-90-3	9094.15	12.4	12.4	0.145	0.546			
	PFFhxA	307-24-4	5659.98	7.73	7.73	0.165	0.546			
	PFFHpA	375-85-9	2477.15	3.38	3.38	0.104	0.546			
	PFOA	335-67-1	4263.21	5.82	5.82	0.151	0.546			
	PFNA	375-95-1	607.98	0.830	0.830	0.0649	0.546			
	PFDA	335-76-2	380.96	0.520	0.520	0.0721	0.546			J
	PFUnDA	2058-94-8	79.37	0.108	0.108	0.158	0.546			L
	PFDODA	307-55-1	17.19	0.0235	0.0235	0.172	0.546			LB
	PFTriDA	72629-94-8	ND	ND	ND	0.129	0.546			U
Sulfonates	PFTeDA	376-06-7	ND	ND	ND	0.186	0.546			U
	PFBS	375-73-5	3214.33	4.39	4.39	0.303	0.638			
	PFPeS	2706-91-4	617.54	0.843	0.843	0.176	0.514			
	PFFhS	355-46-4	3898.57	5.32	5.32	0.163	0.500			
	PFFHpS	375-92-8	5.74	0.00784	0.00784	0.115	0.520			L
	PFOS	1763-23-1	9624.63	13.1	13.1	0.137	0.506			
	PFNS	68259-12-1	ND	ND	ND	0.0737	0.526			U
	PFDS	335-77-3	ND	ND	ND	0.164	0.526			U
	4:2 FTS	757124-72-4	ND	ND	ND	0.101	0.512			U
	6:2 FTS	27619-97-2	208.75	0.285	0.285	0.0990	0.520			J
Other	8:2 FTS	39108-34-4	ND	ND	ND	0.146	0.523			U
	PFOSA	754-91-6	38.07	0.0520	0.0520	0.111	0.546			L
	N-MeFOSAA	2355-31-9	ND	ND	ND	0.123	0.546			U
	N-EiFOSAA	2991-50-6	ND	ND	ND	0.0930	0.546			U
	HFPO-DA	13252-13-6	8263.37	11.3	11.3	0.195	0.546			
	PFMOAA	674-13-5	57851.22	79.0	79.0	1.23	1.23			
	PFMOPrA	377-73-1	ND	ND	ND	0.205	0.546			U
	PFO2HxA	39492-88-1	9255.96	12.6	12.6	1.23	1.23			
	PFO3OA	39492-89-2	3032.42	4.14	4.14	1.23	1.23			
	PFO4DA	39492-90-5	ND	ND	ND	1.30	1.30			U
	Nafion Byproduct 1	29311-67-9	ND	ND	ND	0.259	0.546			U
	ADONA	919005-14-4	ND	ND	ND	0.102	0.517			U
	9CI-PF3ONS	756426-58-1	ND	ND	ND	0.102	0.509			U
	11CI-PF3OUdS	763051-92-9	ND	ND	ND	0.102	0.514			U
	10:2 FTS	120226-60-0	ND	ND	ND	0.205	0.546			U
	EVE Acid	69087-46-3	ND	ND	ND	1.23	1.23			U
	FBSA	30334-69-1	628.54	0.858	0.858	0.205	0.546			
	Hydro-EVE Acid	773804-62-9	341.91	0.467	0.467	1.23	1.23			L
	Hydrolyzed PSDA	2416366-19-1	6680.71	9.12	9.12	1.23	1.23			
	Nafion Byproduct 2	749836-20-2	529.56	0.723	0.723	0.259	0.546			
	N-EiFOSA	4151-50-2	ND	ND	ND	0.205	0.546			U
	N-EiFOSE	1691-99-2	ND	ND	ND	6.14	6.14			U
	NFDHA	151772-58-6	ND	ND	ND	0.205	0.546			U
	N-MeFOSA	31506-32-8	ND	ND	ND	0.205	0.546			U
	N-MeFOSE	24448-09-7	ND	ND	ND	6.14	6.14			U
	NVHOS	1132933-86-8	10053.86	13.7	13.7	1.23	1.23			
	PEPA	267239-61-2	5673.01	7.74	7.74	1.23	1.23			
	PFECA-G	801212-59-9	ND	ND	ND	0.259	1.23			U
	PFEESA	113507-82-7	ND	ND	ND	0.205	0.546			U
	PFFhDA	67905-19-5	ND	ND	ND	1.23	1.23			U
	PFMOBA	863090-89-5	ND	ND	ND	1.23	1.23			U
	PFO5DA	39492-91-6	ND	ND	ND	1.30	1.30			U
	PMPA	13140-29-9	6173.97	8.43	8.43	1.23	1.23			
	R-EVE	2416366-22-6	5680.85	7.76	7.76	1.23	1.23			
	R-PSDA	2416366-18-0	14519.75	19.8	19.8	1.23	1.23			
	R-PSDCA	2416366-21-5	145.05	0.198	0.198	1.23	1.23			L
ES	MPFBA		5212.95	7.12				20-150%	104.3%	
	M5PFPeA		8053.51	11.0				20-150%	161.1%	Q
	M3PFBS		11974.78	16.3				20-150%	239.5%	Q
	M2-4:2 FTS		11169.72	15.2				20-150%	223.4%	Q
	M5PFFhxA		4760.51	6.50				20-150%	95.2%	
	M3HFPO-DA		5776.34	7.89				20-150%	115.5%	
	M4PFFHpA		5029.96	6.87				20-150%	100.6%	
	M3PFFhS		4902.13	6.69				20-150%	98.0%	
	M2-6:2 FTS		9541.26	13.0				20-150%	190.8%	Q
	M8PFOA		4674.38	6.38				20-150%	93.5%	
	M9PFNA		4151.12	5.67				20-150%	83.0%	
	M8PFOS		3427.28	4.68				20-150%	68.5%	
	M2-8:2 FTS		4475.05	6.11				20-150%	89.5%	
	M8FOSA-I		2451.08	3.35				20-150%	49.0%	
	M6PFDA		3936.22	5.37				20-150%	78.7%	
	d3-N-MeFOSAA		2694.72	3.68				20-150%	53.9%	
	d5-N-EiFOSAA		2469.88	3.37				20-150%	49.4%	
	M7PFUdA		3086.20	4.21				20-150%	61.7%	
	MPFDoA		2813.15	3.84				20-150%	56.3%	
	M2PFTeDA		2029.09	2.77				20-150%	40.6%	

QC Data

Enthalpy Analytical

Job No.: 0722-721-2 PFAS by Isotope Dilution (non-potable water)

Brunswick County Public Utilities - NC Client Project: N/A Site: Northwest Water Plant

Enthalpy ID	MB-13670-PFAS	Prep Batch	EU13670	Sample Vol (mL)	250
Sample Name	MB-13670-PFAS	Prep Date	2022-07-12 12:25	Extract Vol (mL)	0.4
Matrix	aqueous	Analysis Date	2022-07-13 22:23	Split Factor	N/A
Sampling Date		Analyst	rappelle	Method Code	WM-026
Received Date		Instrument	Kili	Sample Type	Blank

	Compound	CAS	Extract Concentration ng/L	Sample Concentration ng/L	Formatted Result ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags
Acids	PFBA	375-22-4	ND	ND	ND	0.153	0.640			U
	PFPeA	2706-90-3	ND	ND	ND	0.170	0.640			U
	PFFhxA	307-24-4	ND	ND	ND	0.193	0.640			U
	PFFHpA	375-85-9	ND	ND	ND	0.122	0.640			U
	PFOA	335-67-1	ND	ND	ND	0.177	0.640			U
	PFNA	375-95-1	ND	ND	ND	0.0761	0.640			U
	PFDA	335-76-2	ND	ND	ND	0.0845	0.640			U
	PFUnDA	2058-94-8	ND	ND	ND	0.185	0.640			U
	PFDODA	307-55-1	5.15	0.00824	0.00824	0.202	0.640			L
	PFTdA	72629-94-8	26.74	0.0428	0.0428	0.151	0.640			L
Sulfonates	PFTeDA	376-06-7	ND	ND	ND	0.218	0.640			U
	PFBS	375-73-5	ND	ND	ND	0.355	0.747			U
	PFPeS	2706-91-4	ND	ND	ND	0.206	0.603			U
	PFFhS	355-46-4	ND	ND	ND	0.191	0.586			U
	PFFHpS	375-92-8	ND	ND	ND	0.135	0.610			U
	PFOS	1763-23-1	11.93	0.0191	0.0191	0.160	0.593			L
	PFNS	68259-12-1	ND	ND	ND	0.0864	0.616			U
	PFDS	335-77-3	ND	ND	ND	0.192	0.616			U
	4:2 FTS	757124-72-4	ND	ND	ND	0.118	0.600			U
	6:2 FTS	27619-97-2	ND	ND	ND	0.116	0.610			U
Other	8:2 FTS	39108-34-4	ND	ND	ND	0.171	0.613			U
	PFOSA	754-91-6	ND	ND	ND	0.130	0.640			U
	N-MeFOSAA	2355-31-9	ND	ND	ND	0.144	0.640			U
	N-EFOSAA	2991-50-6	ND	ND	ND	0.109	0.640			U
	HFPO-DA	13252-13-6	ND	ND	ND	0.228	0.640			U
	PFMOAA	674-13-5	ND	ND	ND	1.44	1.44			U
	PFMOPrA	377-73-1	ND	ND	ND	0.240	0.640			U
	PFO2HxA	39492-88-1	ND	ND	ND	1.44	1.44			U
	PFO3OA	39492-89-2	ND	ND	ND	1.44	1.44			U
	PFO4DA	39492-90-5	ND	ND	ND	1.52	1.52			U
	Nafion Byproduct 1	29311-67-9	ND	ND	ND	0.304	0.640			U
	ADONA	919005-14-4	ND	ND	ND	0.120	0.606			U
	9CI-PF3ONS	756426-58-1	ND	ND	ND	0.120	0.596			U
	11CI-PF3OUdS	763051-92-9	ND	ND	ND	0.120	0.603			U
	10:2 FTS	120226-60-0	ND	ND	ND	0.240	0.640			U
	EVE Acid	69087-46-3	ND	ND	ND	1.44	1.44			U
	FBSA	30334-69-1	ND	ND	ND	0.240	0.640			U
	Hydro-EVE Acid	773804-62-9	ND	ND	ND	1.44	1.44			U
	Hydrolyzed PSDA	2416366-19-1	5.65	0.00904	0.00904	1.44	1.44			L
	Nafion Byproduct 2	749836-20-2	ND	ND	ND	0.304	0.640			U
	N-EFOSA	4151-50-2	ND	ND	ND	0.240	0.640			U
	N-EFOSE	1691-99-2	ND	ND	ND	7.20	7.20			U
	NFDHA	151772-58-6	ND	ND	ND	0.240	0.640			U
	N-MeFOSA	31506-32-8	ND	ND	ND	0.240	0.640			U
	N-MeFOSE	24448-09-7	ND	ND	ND	7.20	7.20			U
	NVHOS	1132933-86-8	ND	ND	ND	1.44	1.44			U
	PEPA	267239-61-2	ND	ND	ND	1.44	1.44			U
	PFECA-G	801212-59-9	ND	ND	ND	0.304	1.44			U
	PFEESA	113507-82-7	ND	ND	ND	0.240	0.640			U
	PFFhDA	67905-19-5	19.49	0.0312	0.0312	1.44	1.44			L
	PFMOBA	863090-89-5	ND	ND	ND	1.44	1.44			U
	PFO5DA	39492-91-6	ND	ND	ND	1.52	1.52			U
	PMPA	13140-29-9	ND	ND	ND	1.44	1.44			U
	R-EVE	2416366-22-6	ND	ND	ND	1.44	1.44			U
	R-PSDA	2416366-18-0	ND	ND	ND	1.44	1.44			U
	R-PSDCA	2416366-21-5	5.03	0.00805	0.00805	1.44	1.44			L
ES	MPFBA		5312.48	8.50				20-150%	106.2%	
	M5PFPeA		4715.88	7.55				20-150%	94.3%	
	M3PFBS		4737.02	7.58				20-150%	94.7%	
	M2-4:2 FTS		5909.20	9.45				20-150%	118.2%	
	M5PFFhxA		5103.14	8.17				20-150%	102.1%	
	M3HFPO-DA		7547.45	12.1				20-150%	150.9%	Q
	M4PFFHpA		5280.98	8.45				20-150%	105.6%	
	M3PFFhS		5891.12	9.43				20-150%	117.8%	
	M2-6:2 FTS		7343.91	11.8				20-150%	146.9%	
	M8PFOA		5420.73	8.67				20-150%	108.4%	
	M9PFNA		5228.40	8.37				20-150%	104.6%	
	M8PFOS		5137.33	8.22				20-150%	102.7%	
	M2-8:2 FTS		6473.05	10.4				20-150%	129.5%	
	M8FOSA-I		4489.70	7.18				20-150%	89.8%	
	M6PFDA		5570.06	8.91				20-150%	111.4%	
	d3-N-MeFOSAA		4862.53	7.78				20-150%	97.3%	
	d5-N-EFOSAA		4383.44	7.01				20-150%	87.7%	
	M7PFUDa		5192.66	8.31				20-150%	103.9%	
	MPFDoA		5124.69	8.20				20-150%	102.5%	
	M2PFTeDA		4129.37	6.61				20-150%	82.6%	

Enthalpy Analytical

Job No.: 0722-721-2 PFAS by Isotope Dilution (non-potable water)

Brunswick County Public Utilities - NC Client Project: N/A Site: Northwest Water Plant

Enthalpy ID	OPR-13670-PFAS	Prep Batch	EU13670	Sample Vol (mL)	250
Sample Name	OPR-13670-PFAS	Prep Date	2022-07-12 12:25	Extract Vol (mL)	0.4
Matrix	aqueous	Analysis Date	2022-07-13 22:46	Split Factor	N/A
Sampling Date		Analyst	rappelle	Method Code	WM-026
Received Date		Instrument	Kili	Sample Type	Control

	Compound	CAS	Extract Concentration ng/L	Sample Concentration ng/L	Formatted Result ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags
Acids	PFBA	375-22-4	10919.40	17.5	17.5	0.153	0.640	73-129%	87.4%	
	PFPeA	2706-90-3	10632.80	17.0	17.0	0.170	0.640	72-129%	85.1%	
	PFHxA	307-24-4	11587.38	18.5	18.5	0.193	0.640	72-129%	92.7%	
	PFHpA	375-85-9	10404.08	16.6	16.6	0.122	0.640	72-130%	83.2%	
	PFOA	335-67-1	11114.67	17.8	17.8	0.177	0.640	71-133%	88.9%	
	PFNA	375-95-1	11076.67	17.7	17.7	0.0761	0.640	69-130%	88.6%	
	PFDA	335-76-2	10107.79	16.2	16.2	0.0845	0.640	71-129%	80.9%	
	PFUnDA	2058-94-8	10406.44	16.7	16.7	0.185	0.640	69-133%	83.3%	
	PFDoDA	307-55-1	11001.62	17.6	17.6	0.202	0.640	72-134%	88.0%	
	PFTriDA	72629-94-8	13593.94	21.8	21.8	0.151	0.640	65-144%	108.8%	
Sulfonates	PFTeDA	376-06-7	10069.56	16.1	16.1	0.218	0.640	71-132%	80.6%	
	PFBS	375-73-5	9087.53	14.5	14.5	0.355	0.747	72-134%	82.0%	
	PFPeS	2706-91-4	10709.14	17.1	17.1	0.206	0.603	71-127%	91.0%	
	PFHxS	355-46-4	9387.23	15.0	15.0	0.191	0.586	68-131%	82.2%	
	PFHpS	375-92-8	10785.00	17.3	17.3	0.135	0.610	69-134%	90.5%	
	PFOS	1763-23-1	9978.29	16.0	16.0	0.160	0.593	65-140%	86.0%	
	PFNS	68259-12-1	11170.35	17.9	17.9	0.0864	0.616	69-127%	92.9%	
	PFDS	335-77-3	10390.59	16.6	16.6	0.192	0.616	53-142%	86.1%	
	4:2 FTS	757124-72-4	10066.60	16.1	16.1	0.118	0.600	63-143%	85.9%	
	6:2 FTS	27619-97-2	8919.81	14.3	14.3	0.116	0.610	64-140%	75.0%	
Other	8:2 FTS	39108-34-4	10589.44	16.9	16.9	0.171	0.613	67-138%	88.2%	
	PFOSA	754-91-6	9960.46	15.9	15.9	0.130	0.640	67-137%	79.7%	
	N-MeFOSAA	2355-31-9	10289.35	16.5	16.5	0.144	0.640	65-136%	82.3%	
	N-EtFOSAA	2991-50-6	11126.50	17.8	17.8	0.109	0.640	61-135%	89.0%	
ES	HFPO-DA	13252-13-6	11510.90	18.4	18.4	0.228	0.640	70-130%	92.1%	
	MPFBA		5204.21	8.33				20-150%	104.1%	
	M5PFPeA		4662.89	7.46				20-150%	93.3%	
	M3PFBS		4641.74	7.43				20-150%	92.8%	
	M2-4:2 FTS		5396.21	8.63				20-150%	107.9%	
	M5PFHxA		4905.68	7.85				20-150%	98.1%	
	M3HFPO-DA		7530.07	12.0				20-150%	150.6%	Q
	M4PFHpA		5063.46	8.10				20-150%	101.3%	
	M3PFHxS		5841.29	9.35				20-150%	116.8%	
	M2-6:2 FTS		6592.94	10.5				20-150%	131.9%	
	M8PFOA		5103.80	8.17				20-150%	102.1%	
	M9PFNA		5054.79	8.09				20-150%	101.1%	
	M8PFOS		5306.07	8.49				20-150%	106.1%	
	M2-8:2 FTS		5793.59	9.27				20-150%	115.9%	
	M8FOSA-I		4869.72	7.79				20-150%	97.4%	
	M6PFDA		5611.82	8.98				20-150%	112.2%	
	d3-N-MeFOSAA		4667.02	7.47				20-150%	93.3%	
	d5-N-EtFOSAA		4350.83	6.96				20-150%	87.0%	
	M7PFUDa		5111.80	8.18				20-150%	102.2%	
	MPFDoA		4945.31	7.91				20-150%	98.9%	
	M2PFTeDA		3853.99	6.17				20-150%	77.1%	

Narrative Summary

Enthalpy Analytical Narrative Summary

Company	Brunswick County Public Utilities - NC
Job No.	0722-721-2 PFAS by Isotope Dilution (non-potable water)
Client ID.	N/A Site: Northwest Water Plant

1. Custody

Megan Holden received the samples on July 08, 2022 at 3.9 °C after being relinquished by Brunswick County Public Utilities - NC. The samples were received in good condition.

Prior to, during, and after analysis, the samples were kept under lock with access only to authorized personnel by Enthalpy Analytical, LLC

Table 1 - Sample Inventory

EU Lab Sample ID	Client Sample ID	Matrix
0722-721-001-1	070822-SO1	Aqueous
0722-721-002-1	070822-EO1	Aqueous

2. Methods and Analytes

A list of analytes of interest and corresponding methods of analysis is shown in Table 3. Abbreviations are defined in the listed Appendices.

Table 3 - Methods and Analytes

EU Method	Analytes	Cleanup Method
EU-047	Brunswick PFAS List	ENVI-Carb

3. Analysis

The samples were analyzed using Waters Acquity UPLC equipped with Xevo TQ MS (LC/MS/MS "Kili").

For aqueous samples, the sample volume was measured gravimetrically by the laboratory, and spiked with Extraction Standard (ES). The sample was then mixed well and centrifuged, if needed. The samples were then extracted via SPE, and the extracts were cleaned up using ENVI-Carb.

Each final sample extract was transferred to an autosampler vial, spiked with Injection Standard (IS), and brought to a final volume of 400µL prior to analysis.

Samples that were run in more than one sequence and their comments are as follows:

070822-SO1, 070822-EO1

Due to acquisition requirements for analytes requested, the sample was analyzed in more than one sequence.

Enthalpy Analytical Narrative Summary

Company	Brunswick County Public Utilities - NC
Job No.	0722-721-2 PFAS by Isotope Dilution (non-potable water)
Client ID.	N/A Site: Northwest Water Plant

4. Calibration

In the initial calibration, the reported analytes exhibited R^2 of ≥ 0.99 . The reported analytes in the calibration standards, continuing calibration (concal) and Initial Calibration Verification (ICV) met the 30% accuracy criterion for native analytes.

Supplemental compounds were run using a single point calibration forced through zero.

The Technical Director extended the method criteria for certain non-legacy analytes that do not have their own internal standard and exhibit observed variability during calibration.

5. QC Notes

The QC sample analyses passed all method criteria.

The samples were extracted within the 28-day from collection holding time and analyzed within the 28-day from extraction to analysis holding time required by the method.

6. Reporting Notes

This report provides all results including detections below LOD following client instruction.

Analyte(s) were detected in the method blank (MB) at less than 1/2 LOQ that may also be less than LOD. Any of these analyte(s) detected in the samples with less than 10 times the amount detected in MB were notated with a B qualifier and are reported with no adverse impact.

Some labeled extraction standards in the sample analyses fell outside the control limits for ES recovery, as denoted by the "Q" qualifier. The target analytes are quantified based on their ratio to their labeled standard analogs. As a result, low or high labeled standard recovery do not cause any change to ratios or contribute any additional error in the measurement of the target analytes. The data have been accepted and reported with no further actions.

The results presented in this report are representative of the samples as provided to the laboratory.

These analyses met the requirements of the TNI Standard. Any deviations from the requirements of the reference method or TNI Standard have been stated above.

Enthalpy Analytical, LLC in Wilmington NC is accredited by the Louisiana Department of Environmental Quality to the 2009 TNI Standard under certificate number 05075.

General Reporting Notes – Data Qualifiers

The following are general reporting notes that are applicable to all Enthalpy Analytical, LLC - Wilmington, NC data reports, unless specifically noted otherwise.

General Data Qualifiers

- B – The analyte was found in the method blank, at a concentration that was at least 10% of the amount in the sample.
- Cxx – Two or more congeners co-elute. In EDDs, C denotes the lowest IUPAC congener in a co-elution group and additional co-eluters for the group ('xx') are shown with the number of the lowest IUPAC co-eluter.
- E – The reported concentration exceeds the calibration range (upper point of the calibration curve). For HRMS data, this condition does not imply additional measurement uncertainty. For LC-MS/MS data, these values should be considered as having measurement uncertainty higher than values within the calibration range.
- EDL – Estimated Detection Level: The EDL is unique to isotope dilution methods and reflects the conditions of analysis at the time of analysis, including the equipment used. Where the MDL is a static value, the EDL is a dynamic value.
- EMPC – Estimated Maximum Possible Concentration: EMPC is specific to Dioxin/Furan tests to indicate the determined ion-abundance ratio was outside the allowed theoretical range (usually due to being near the detection limit, although it can very rarely be caused by a co-eluting interference). The EMPC concentration is adjusted to reflect the value at the theoretical ion-abundance ratio.
- IR – The ion ratio between the primary and secondary ions was observed to be outside the method criteria. The analyte concentration may be inaccurate due to interference.
- J – The analyte has a concentration below the minimum calibration level (LOQ value) but greater than the LOD. These values should be considered as having measurement uncertainty higher than values within the calibration range
- L - Indicates that an analyte has a concentration below the Minimum Detection Limit (MDL). The reported concentration is not recommended for regulatory use as the analyte signal may have a signal-to-noise ratio less than the criteria deemed necessary to be considered a detected analyte.
- LOD – Limit of Detection: For reports conforming to the DOD ELAP QSM, this is the QSM-defined LOD. For reports conforming to TNI requirements (but not DOD ELAP QSM requirements), this value is the minimum detection limit (MDL). The LOD is adjusted for sample weight or volume.
- LOQ – Limit of Quantitation: For reports conforming to the DOD ELAP QSM, this is the QSM-defined LOQ. For reports conforming to TNI requirements (but not DOD ELAP QSM requirements), this value is the reporting limit (RL). The LOQ is adjusted for sample weight or volume.

General Reporting Notes – Data Qualifiers

- <LOD() – Analyte was not found at a concentration high enough to be reported as detected. It is reported as less than the LOD, and the LOD is given in the parentheses.
- <LOQ() – Analyte was not found at a concentration high enough to be reported as above the QSM-defined LOQ or TNI defined Reporting Limit. It is reported as less than the LOQ, and the LOQ is given in the parentheses.
- ND – Indicates a non-detect.
- NR – Indicates a value that is not reportable due to issues observed in sample preparation or analysis.
- PR – The associated congener(s) is(are) poorly resolved.
- QI – Indicates the presence of a quantitative interference.
- RL – Reporting Limit. Lowest reportable value. The level is higher than the MDL.
- SI – Denotes “Single Ion Mode” and is utilized for PCBs where the secondary ion trace has a significantly elevated noise level due to background PFK. Responses for such peaks are calculated using an EMPC approach based solely on the primary ion area(s) and may be considered estimates.
- U – The analyte was not detected.
- V / Q – The labeled standard recovery is not within method control limits.
- X – Indicates the result is from re-injection/repeat/second-column analysis.

Lab Identifiers/ Data Attributes

- AR – Indicates use of the archived portion of the sample extract.
- CU – Indicates a sample that required additional clean-up prior to HRMS injection/processing.
- D – Dilution Data. Result was obtained from the analysis of a dilution. The number that follows the “D” indicates the dilution factor.
- DE – Indicates a dilution performed with the addition of ES (Extraction Standard) solution.
- DUP – Designation for a duplicate sample.
- MS – Designation for a matrix spike.
- MSD – Designation for a matrix spike duplicate.
- R – Indicates a re-extraction of the sample.
- RJ – Indicates a reinjection of the sample extract.



General Reporting Notes – Data Qualifiers

- S – Indicates a sample split. The number that follows the “S” indicates the split factor.
- SAT – Indicates an analyte saturated the detector.

PFAS Compound Acronym List		
Acronym	CAS #	Compound Name
Target Analytes		
* Analyte is not accredited		
PFBA	375-22-4	Perfluorobutanoic Acid
PFPeA	2706-90-3	Perfluoropentanoic Acid
PFHxA	307-24-4	Perfluorohexanoic Acid
PFHpA	375-85-9	Perfluoroheptanoic Acid
PFOA	335-67-1	Perfluorooctanoic Acid
PFNA	375-95-1	Perfluorononanoic Acid
PFDA	335-76-2	Perfluorodecanoic acid
PFUnA (PFUnDA)	2058-94-8	Perfluoroundecanoic acid
PFDoA (PFDoDA)	307-55-1	Perfluorododecanoic acid
PFTriA (PFTriA)	72629-94-8	Perfluorotridecanoic acid
PFTeDA (PFTA)	376-06-7	Perfluorotetradecanoic acid
PFBS	375-73-5	Perfluorobutane sulfonic acid
PFPeS	2706-91-4	Perfluoropentane sulfonic acid
PFHxS	355-46-4	Perfluorohexane sulfonic acid
PFHpS	375-92-8	Perfluoroheptane sulfonic acid
PFOS	1763-23-1	Perfluorooctane sulfonic acid
PFNS	68259-12-1	Perfluorononane sulfonic acid
PFDS	335-77-3	Perfluorodecane sulfonic acid
4:2 FTS	757124-72-4	4:2 fluorotelomer sulfonic acid
6:2 FTS	27619-97-2	6:2 fluorotelomer sulfonic acid
8:2 FTS	39108-34-4	8:2 fluorotelomer sulfonic acid
PFOSA (FOSA)	754-91-6	Perfluorooctane sulfonamide
N-MeFOSAA	2355-31-9	N-methyl perfluorooctane sulfonamido acetic acid
N-EtFOSAA	2991-50-6	N-ethyl perfluorooctane sulfonamido acetic acid
HFPO-DA	13252-13-6	2,3,3,3-Tetrafluoro-2-(1,1,2,2,3,3,3-heptafluoropropoxy)-propanoic acid (Gen-X)
11CI-PF3OUDS	763051-92-9	11-chloroeicosafluoro-3-oxaundecane-1-sulfonic acid
9CI-PF3ONS	756426-58-1	9-chlorohexadecafluoro-3-oxanonane-1-sulfonic acid
ADONA	919005-14-4	4,8-dioxa-3H-perfluorononanoic acid
PFEESA	113507-82-7	Perfluoro(2-ethoxyethane)sulphonic acid
PFMOBA (PFMBA)	863090-89-5	Perfluoro-4-methoxybutanic acid
NFDHA	151772-58-6	Nonafluoro-3,6-dioxaheptanoic acid
PFMOPra (PFMPA)	377-73-1	Perfluoro-3-methoxypropanoic acid
* PFMOAA	674-13-5	Perfluoro-2-methoxyacetic acid
* PFO2HxA	39492-88-1	Perfluoro (3,5-dioxaheptanoic) acid
* PFO3OA	39492-89-2	Perfluoro (3,5,7-trioxaoctanoic) acid
* PFO4DA	39492-90-5	Perfluoro (3,5,7,9-tetraoxadecanoic) acid
* PFO5DA	39492-91-6	Perfluoro(3,5,7,9,11-pentaoxadodecanoic) acid
* Nafion Byproduct 1	29311-67-9	Nafion Byproduct 1
* Nafion Byproduct 2	749836-20-2	Nafion Byproduct 2
* PEPA	267239-61-2	Perfluoro-2-ethoxypropanoic acid
* PMPA	13140-29-9	Perfluoro-2-methoxypropanoic acid
* 10:2 FTS	120226-60-0	Fluorotelomer sulfonate 10:2
* N-EtFOSA	4151-50-2	N-ethylperfluoro-1-octanesulfonamide
* N-EtFOSE	1691-99-2	2-(N-methylperfluoro-1-octanesulfonamido)-ethanol
* N-MeFOSA	31506-32-8	N-methylperfluoro-1-octanesulfonamide
* N-MeFOSE	24448-09-7	2-(N-methylperfluoro-1-octanesulfonamido)-ethanol
* PFECA-G	801212-59-9	4-(Heptafluoroisopropoxy)hexafluorobutanoic acid
* PFHxDA	67905-19-5	Perfluorohexadecanoic acid
R-PSDA (Nafion Byproduct 4)	2416366-18-0	Perfluoro-4-(2-sulfoethoxy)pentanoic acid

PFAS Compound Acronym List		
Acronym	CAS #	Compound Name
Target Analytes		
* Analyte is not accredited		
* Hydrolyzed PSDA (Nafion Byproduct 5)	2416366-19-1	2-fluoro-2-[1,1,2,3,3,3-hexafluoro-2-(1,1,2,2-tetrafluoro-2-sulfoethoxy)propoxy]-acetic acid
* R-PSDCA (Nafion Byproduct 6)	2416366-21-5	1,1,2,2-tetrafluoro-2-[1,2,2,3,3-pentafluoro-1-(trifluoromethyl)propoxy] ethanesulfonic acid
* EVE Acid	69087-46-3	2,2,3,3-tetrafluoro-3-({1,1,1,2,3,3-hexafluoro-3-[(1,2,2-trifluoroethenyl)oxy]propan-2-yl}oxy)propionic acid
* FBSA	30334-69-1	Perfluorobutylsulfonamide
* Hydro-EVE Acid	773804-62-9	2,2,3,3-Tetrafluoro-3-({1,1,1,2,3,3-hexafluoro-3-(1,2,2,2-tetrafluoroethoxy)propan-2-yl}oxy)propanoic acid
* R-EVE Acid	2416366-22-6	4-(2-carboxy-1,1,2,2-tetrafluoroethoxy)-2,2,3,3,4,5,5,5-octafluoro-pentanoic acid
* NVHOS	1132933-86-8	Perfluoroethoxysulfonic acid
* PFDoS	79780-39-5	Perfluorododecane sulfonic acid
* PFODA	16517-11-6	Perfluorooctadecanoic acid
* 3:3 FTCA	356-02-5	2H,2H,3H,3H-Perfluorohexanoic acid
* 5:3 FTCA	914637-49-3	2H,2H,3H,3H-Perfluorooctanoic acid
* 7:3 FTCA	812-70-4	2H,2H,3H,3H-Perfluorodecanoic acid
* N-AP-FHxSA	50598-28-2	N-(3-(Dimethylamino)propyl)tridecafluoro-1-hexanesulfonamide
* N-CMAmP-6:2 FOSA	34455-29-3	N-(Carboxymethyl)-N,N-dimethyl-3-(((3,3,4,4,5,5,6,6,7,7,8,8,8-tridecafluorooctyl)sulfonyl)amino)1-propanaminium

Sample Custody



Enthalpy Ultratrace Job#: _____ COC Page 1 of 1

Special Handling:

X Standard Turn Around Time

☐ Rush Turn Around Time -- Date Needed

• All Fast TATs Subject to Approval by Enthalpy Analytical, Inc.

- All Samples Disposed of After 6 months Unless Otherwise Instructed.

Enthalpy Analytical-Wilmington, NC has added enhancements to standard methods to improve accuracy, precision and permit an assessment of laboratory performance in the context of your specific data needs. For more information email Cindy.James@enthalpy.com.

Client Name: **BRUNSWICK COUNTY UTILITIES**

Project Number: _____

PO#:

Project Manager: GLENN WALKER

Site Name: NORTHWEST WATER PLANT

Telephone#:

Report To: **SAME**

Location: LELAND N.C.

Email:

This Chain of Custody is applicable to Non-Air samples. Standard TAT differ per analysis and are provided by request.

Client Special Instructions:

Matrix: GW-Groundwater, WW-Wastewater, NW-Non-Potable Water, DW-Drinking Water, S-Soil, SL-Sludge, BT-Biological Tissue, O-Other

Type: G=Grab C=Composite Q=Quality Control

Courier, cooler
on ice, noseall
good condition
MM
7.8.22

Relinquished By:

Date: _____

Received By:

Date:

Time:

Sample Temperature Upon Receipt:

7/8/2022

1.822

15:18

 Iced

☐ **Ambien**

at $^{\circ}\text{C}$ 3.9 + 12

☐ Iced☐ **Ambien**

°C

☐ Iced☐ **Ambien**

°C

2714 Exchange Drive • Wilmington, NC 28405 • (910) 212-5858 • www.enthalpy.com

**This Is The Last Page
Of This Report.**