

County of Brunswick

3954 Clearwell Dr NE
Leland, NC 28451

Northwest Water Plant

Leland, NC
Samples Received: 10/29/21

Analytical Report 1021-840

Isotope Dilution Method PFAS



Enthalpy Analytical, LLC – Ultratrace

Mark Hager

M: 910-520-2526 / F: 910-212-5866

mark.hager@enthalpy.com / www.enthalpy.com

2714 Exchange Drive, Wilmington, NC 28405

I certify that to the best of my knowledge all analytical data presented in this report:

- Have been checked for completeness
- Are accurate, error-free, and legible
- Have been conducted in accordance with approved protocol, and that all deviations and analytical problems are summarized in the appropriate narrative(s)

This analytical report was prepared in Portable Document Format (.PDF) and contains _____ pages.

....."Report Issued Date: _____"



Summary of Results

Enthalpy Analytical

Job No.: 1021-840-1 PFAS by Isotope Dilution (non-potable water)

County of Brunswick N/A Northwest Water Plant, Leland, NC

Summary

	Compound	CAS	102921S01 ng/L	102921E01 ng/L
Acids	PFBA	375-22-4	3.74	25.4
	PFPeA	2706-90-3	5.97	ND U
	PFHxA	307-24-4	4.68	17.3
	PFHpA	375-85-9	2.34	5.26
	PFOA	335-67-1	3.33	16.4
	PFNA	375-95-1	0.617	1.13 J
	PFDA	335-76-2	0.448	0.899 J
	PFUnDA	2058-94-8	0.160 LB	0.869 L
	PFDoDA	307-55-1	ND U	ND U
	PFTTrDA	72629-94-8	ND U	0.0329 LB
	PFTeDA	376-06-7	ND U	0.149 LB
Sulfonates	PFBS	375-73-5	3.59	ND U
	PFPeS	2706-91-4	0.696	ND U
	PFHxS	355-46-4	2.47	5.48
	PFHpS	375-92-8	ND U	0.619 L
	PFOS	1763-23-1	7.40	10.2
	PFNS	68259-12-1	ND U	ND U
	PFDS	335-77-3	ND U	ND U
	4:2 FTS	757124-72-4	ND U	0.0477 L
	6:2 FTS	27619-97-2	ND U	1.89 J
8:2 FTS	39108-34-4	ND U	0.275 L	
other	PFOSA	754-91-6	ND U	ND U
	N-MeFOSAA	2355-31-9	ND U	2.56
	N-EtFOSAA	2991-50-6	ND U	0.757 L
	HFPO-DA	13252-13-6	8.17	ND U
	PFMOAA	674-13-5	69.5	50.7
	PFMOPrA	377-73-1	ND U	0.368 L
	PFO2HxA	39492-88-1	7.53	11.3 L
	PFO3OA	39492-89-2	3.62	3.38 L
	PFO4DA	39492-90-5	ND U	ND U
	Nafion Byproduct 1	29311-67-9	ND U	ND U
	ADONA	919005-14-4	ND U	0.0187 L
	9Cl-PF3ONS	756426-58-1	ND U	ND U
	11Cl-PF3OUdS	763051-92-9	ND U	0.277 L
	10:2 FTS	120226-60-0	ND U	ND U
	EVE Acid	69087-46-3	ND U	ND U
	FBSA	30334-69-1	0.499	1.16 L
	Hydro-EVE Acid	773804-62-9	0.425 L	ND U
	Hydrolyzed PSDA	2416366-19-1	10.9	12.3
	Nafion Byproduct 2	749836-20-2	0.333	ND U
	N-EtFOSA	4151-50-2	ND U	ND U
	N-EtFOSE	1691-99-2	ND U	ND U
	NFDHA	151772-58-6	ND U	ND U
	N-MeFOSA	31506-32-8	ND U	ND U
	N-MeFOSE	24448-09-7	ND U	ND U
	NVHOS	1132933-86-8	3.53	ND U
	PEPA	267239-61-2	ND U	ND U
	PFECA-G	801212-59-9	ND U	0.967 L
	PFEEESA	113507-82-7	ND U	0.401 L
	PFHxDA	67905-19-5	ND U	ND U
	PFMOBA	863090-89-5	ND U	ND U
	PFO5DA	39492-91-6	ND U	2.14 L
PMPA	13140-29-9	7.24	17.3	
R-EVE	2416366-22-6	9.27	4.85 L	
R-PSDA	2416366-18-0	ND U	ND U	
R-PSDCA	2416366-21-5	0.0260 L	0.0484 LB	

Detailed Results

Enthalpy Analytical

Job No.: 1021-840-1 PFAS by Isotope Dilution (non-potable water)
 County of Brunswick N/A Northwest Water Plant, Leland, NC

Enthalpy ID	1021-840-001-1	Prep Batch	EU12534	Sample Vol (mL)	266.97
Sample Name	102921S01	Prep Date	2021-11-01 16:09	Extract Vol (mL)	0.4
Matrix	Aqueous	Analysis Date	2021-11-05 04:48	Dilution Factor	1
Sampling Date	20211029 00:00	Analyst	avheadrick	Method Code	WM-026
Received Date	2021-10-29 14:20	Instrument	Killi	Sample Type	Sample

	Compound	CAS	Extract Concentration ng/L	Sample Concentration ng/L	Formatted Result ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags
Acids	PFBA	375-22-4	2494.24	3.74	3.74	0.143	0.285			
	PFPeA	2706-90-3	3982.28	5.97	5.97	0.159	0.285			
	PFHxA	307-24-4	3123.08	4.68	4.68	0.181	0.285			
	PFHpA	375-85-9	1560.91	2.34	2.34	0.114	0.285			
	PFOA	335-67-1	2221.70	3.33	3.33	0.166	0.285			
	PFNA	375-95-1	411.81	0.617	0.617	0.0713	0.285			
	PFDA	335-76-2	299.20	0.448	0.448	0.0791	0.285			
	PFUnDA	2058-94-8	106.66	0.160	0.160	0.173	0.285			LB
	PFDoDA	307-55-1	ND	ND	ND	0.189	0.285			U
	PFTrDA	72629-94-8	ND	ND	ND	0.141	0.285			U
PFTeDA	376-06-7	ND	ND	ND	0.204	0.285			U	
Sulfonates	PFBS	375-73-5	2394.85	3.59	3.59	0.332	0.332			
	PFPeS	2706-91-4	464.49	0.696	0.696	0.193	0.268			
	PFHxS	355-46-4	1648.24	2.47	2.47	0.179	0.261			
	PFHpS	375-92-8	ND	ND	ND	0.126	0.271			U
	PFOS	1763-23-1	4936.59	7.40	7.40	0.150	0.264			
	PFNS	68259-12-1	ND	ND	ND	0.0809	0.274			U
	PFDS	335-77-3	ND	ND	ND	0.180	0.274			U
	4:2 FTS	757124-72-4	ND	ND	ND	0.110	0.267			U
	6:2 FTS	27619-97-2	ND	ND	ND	0.109	0.271			U
	8:2 FTS	39108-34-4	ND	ND	ND	0.160	0.273			U
other	PFOSA	754-91-6	ND	ND	ND	0.122	0.285			U
	N-MeFOSAA	2355-31-9	ND	ND	ND	0.135	0.285			U
	N-EiFOSAA	2991-50-6	ND	ND	ND	0.102	0.285			U
	HFPO-DA	13252-13-6	5455.14	8.17	8.17	0.214	0.285			U
	PFMOAA	674-13-5	46410.45	69.5	69.5	1.35	1.35			
	PFMOPrA	377-73-1	ND	ND	ND	0.225	0.285			U
	PFO2HxA	39492-88-1	5028.03	7.53	7.53	1.35	1.35			
	PFO3OA	39492-89-2	2414.20	3.62	3.62	1.35	1.35			
	PFO4DA	39492-90-5	ND	ND	ND	1.42	1.42			U
	Nafion Byproduct 1	29311-67-9	ND	ND	ND	0.285	0.285			U
	ADONA	919005-14-4	ND	ND	ND	0.112	0.270			U
	9Cl-PF3ONS	756426-58-1	ND	ND	ND	0.112	0.265			U
	11Cl-PF3OUdS	763051-92-9	ND	ND	ND	0.112	0.268			U
	10:2 FTS	120226-60-0	ND	ND	ND	0.225	0.285			U
	EVE Acid	69087-46-3	ND	ND	ND	1.35	1.35			U
	FBSA	30334-69-1	332.77	0.499	0.499	0.225	0.285			
	Hydro-EVE Acid	773804-62-9	283.94	0.425	0.425	1.35	1.35			L
	Hydrolyzed PSDA	2416366-19-1	7287.83	10.9	10.9	1.35	1.35			
	Nafion Byproduct 2	749836-20-2	222.06	0.333	0.333	0.285	0.285			
	N-EiFOSA	4151-50-2	ND	ND	ND	0.225	0.285			U
	N-EiFOSE	1691-99-2	ND	ND	ND	6.74	6.74			U
	NFDHA	151772-58-6	ND	ND	ND	0.225	0.285			U
	N-MeFOSA	31506-32-8	ND	ND	ND	0.225	0.285			U
	N-MeFOSE	24448-09-7	ND	ND	ND	6.74	6.74			U
	NVHOS	1132933-86-8	2354.41	3.53	3.53	1.35	1.35			
	PEPA	267239-61-2	ND	ND	ND	1.35	1.35			U
	PFECA-G	801212-59-9	ND	ND	ND	0.285	1.35			U
	PFEEA	113507-82-7	ND	ND	ND	0.225	0.285			U
	PFHxDA	67905-19-5	ND	ND	ND	1.35	1.35			U
	PFMOBA	863090-89-5	ND	ND	ND	1.35	1.35			U
PFO5DA	39492-91-6	ND	ND	ND	1.42	1.42			U	
PMPA	13140-29-9	4833.02	7.24	7.24	1.35	1.35				
R-EVE	2416366-22-6	6186.78	9.27	9.27	1.35	1.35				
R-PSDA	2416366-18-0	ND	ND	ND	1.35	1.35			U	
R-PSDCA	2416366-21-5	17.32	0.0260	0.0260	1.35	1.35			L	
ES	MFPBA		4860.43	7.28				20-150%	97.2%	
	M5PFPeA		11826.27	17.7				20-150%	236.5%	Q
	M3PFBS		14000.02	21.0				20-150%	280.0%	Q
	M2-4:2 FTS		11167.54	16.7				20-150%	223.4%	Q
	M5PFHxA		4718.12	7.07				20-150%	94.4%	
	M3HFPO-DA		6039.72	9.05				20-150%	120.8%	
	M4PFHpA		4807.45	7.20				20-150%	96.1%	
	M3PFHxS		4723.08	7.08				20-150%	94.5%	
	M2-6:2 FTS		5564.08	8.34				20-150%	111.3%	
	M8PFOA		4656.31	6.98				20-150%	93.1%	
	M9PFNA		4631.50	6.94				20-150%	92.6%	
	M8PFOS		4477.66	6.71				20-150%	89.6%	
	M2-8:2 FTS		5340.98	8.00				20-150%	106.8%	
	M8FOSA-I		2915.78	4.37				20-150%	58.3%	
	M6PFDA		4439.75	6.65				20-150%	88.8%	
	d3-N-MeFOSAA		3681.25	5.52				20-150%	73.6%	
	d5-N-EiFOSAA		3570.88	5.35				20-150%	71.4%	
	M7PFUdA		3767.65	5.65				20-150%	75.4%	
	MPFDoA		2575.68	3.86				20-150%	51.5%	
	M2PFTeDA		2150.91	3.22				20-150%	43.0%	

Enthalpy Analytical

Job No.: 1021-840-1 PFAS by Isotope Dilution (non-potable water)
 County of Brunswick N/A Northwest Water Plant, Leland, NC

Enthalpy ID	1021-840-002-2	Prep Batch	EU12572	Sample Vol (mL)	30
Sample Name	102921E01	Prep Date	2021-11-09 15:10	Extract Vol (mL)	0.4
Matrix	Aqueous	Analysis Date	2021-11-15 16:14	Dilution Factor	1
Sampling Date	20211029 00:00	Analyst	avheadrick	Method Code	WM-026
Received Date	2021-10-29 14:20	Instrument	Killi	Sample Type	Sample

	Compound	CAS	Extract Concentration ng/L	Sample Concentration ng/L	Formatted Result ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags
Acids	PFBA	375-22-4	1901.70	25.4	25.4	1.28	2.53			
	PFPeA	2706-90-3	ND	ND	ND	1.42	2.53			U
	PFHxA	307-24-4	1298.21	17.3	17.3	1.61	2.53			
	PFHpA	375-85-9	394.68	5.26	5.26	1.02	2.53			
	PFOA	335-67-1	1231.75	16.4	16.4	1.48	2.53			
	PFNA	375-95-1	85.05	1.13	1.13	0.634	2.53			J
	PFDA	335-76-2	67.44	0.899	0.899	0.704	2.53			J
	PFUnDA	2058-94-8	65.16	0.869	0.869	1.54	2.53			L
	PFDoDA	307-55-1	ND	ND	ND	1.68	2.53			U
	PFTrDA	72629-94-8	2.47	0.0329	0.0329	1.26	2.53			LB
PFTeDA	376-06-7	11.21	0.149	0.149	1.82	2.53			LB	
Sulfonates	PFBS	375-73-5	ND	ND	ND	2.96	2.96			U
	PFPeS	2706-91-4	ND	ND	ND	1.72	2.39			U
	PFHxS	355-46-4	410.86	5.48	5.48	1.59	2.32			
	PFHpS	375-92-8	46.45	0.619	0.619	1.13	2.41			L
	PFOS	1763-23-1	766.57	10.2	10.2	1.33	2.35			
	PFNS	68259-12-1	ND	ND	ND	0.720	2.44			U
	PFDS	335-77-3	ND	ND	ND	1.60	2.44			U
	4:2 FTS	757124-72-4	3.57	0.0477	0.0477	0.983	2.37			L
	6:2 FTS	27619-97-2	141.84	1.89	1.89	0.967	2.41			J
	8:2 FTS	39108-34-4	20.65	0.275	0.275	1.43	2.43			L
other	PFOSA	754-91-6	ND	ND	ND	1.08	2.53			U
	N-MeFOSAA	2355-31-9	192.01	2.56	2.56	1.20	2.53			
	N-EiFOSAA	2991-50-6	56.81	0.757	0.757	0.908	2.53			L
	HFPO-DA	13252-13-6	ND	ND	ND	1.90	2.53			U
	PFMOAA	674-13-5	3804.60	50.7	50.7	12.0	12.0			
	PFMOPrA	377-73-1	27.63	0.368	0.368	2.00	2.53			L
	PFO2HxA	39492-88-1	845.70	11.3	11.3	12.0	12.0			L
	PFO3OA	39492-89-2	253.77	3.38	3.38	12.0	12.0			L
	PFO4DA	39492-90-5	ND	ND	ND	12.7	12.7			U
	Nafion Byproduct 1	29311-67-9	ND	ND	ND	2.53	2.53			U
	ADONA	919005-14-4	1.40	0.0187	0.0187	1.00	2.40			L
	9Cl-PF3ONS	756426-58-1	ND	ND	ND	1.00	2.36			U
	11Cl-PF3OUdS	763051-92-9	20.74	0.277	0.277	1.00	2.39			L
	10:2 FTS	120226-60-0	ND	ND	ND	2.00	2.53			U
	EVE Acid	69087-46-3	ND	ND	ND	12.0	12.0			U
	FBSA	30334-69-1	86.69	1.16	1.16	2.00	2.53			L
	Hydro-EVE Acid	773804-62-9	ND	ND	ND	12.0	12.0			U
	Hydrolyzed PSDA	2416366-19-1	919.03	12.3	12.3	12.0	12.0			
	Nafion Byproduct 2	749836-20-2	ND	ND	ND	2.53	2.53			U
	N-EiFOSA	4151-50-2	ND	ND	ND	2.00	2.53			U
	N-EiFOSE	1691-99-2	ND	ND	ND	60.0	60.0			U
	NFDHA	151772-58-6	ND	ND	ND	2.00	2.53			U
	N-MeFOSA	31506-32-8	ND	ND	ND	2.00	2.53			U
	N-MeFOSE	24448-09-7	ND	ND	ND	60.0	60.0			U
	NVHOS	1132933-86-8	ND	ND	ND	12.0	12.0			U
	PEPA	267239-61-2	ND	ND	ND	12.0	12.0			U
	PFECA-G	801212-59-9	72.55	0.967	0.967	2.53	12.0			L
	PFEESA	113507-82-7	30.05	0.401	0.401	2.00	2.53			L
	PFHxDA	67905-19-5	ND	ND	ND	12.0	12.0			U
	PFMOBA	863090-89-5	ND	ND	ND	12.0	12.0			U
PFO5DA	39492-91-6	160.65	2.14	2.14	12.7	12.7			L	
PMPA	13140-29-9	1299.42	17.3	17.3	12.0	12.0				
R-EVE	2416366-22-6	363.58	4.85	4.85	12.0	12.0			L	
R-PSDA	2416366-18-0	ND	ND	ND	12.0	12.0			U	
R-PSDCA	2416366-21-5	3.63	0.0484	0.0484	12.0	12.0			LB	
ES	MFPBA		5386.28	71.8				20-150%	107.7%	
	M5PFPeA		6728.10	89.7				20-150%	134.6%	
	M3PFBS		6719.11	89.6				20-150%	134.4%	
	M2-4:2 FTS		12141.43	162				20-150%	242.8%	Q
	M5PFHxA		4857.70	64.8				20-150%	97.2%	
	M3HFPO-DA		6756.45	90.1				20-150%	135.1%	
	M4PFHpA		5290.98	70.5				20-150%	105.8%	
	M3PFHxS		5984.14	79.8				20-150%	119.7%	
	M2-6:2 FTS		11796.02	157				20-150%	235.9%	Q
	M8PFOA		5374.12	71.7				20-150%	107.5%	
	M9PFNA		4821.04	64.3				20-150%	96.4%	
	M8PFOS		5724.21	76.3				20-150%	114.5%	
	M2-8:2 FTS		6874.01	91.7				20-150%	137.5%	
	M8FOSA-I		4503.28	60.0				20-150%	90.1%	
	M6PFDA		5632.24	75.1				20-150%	112.6%	
	d3-N-MeFOSAA		7158.73	95.4				20-150%	143.2%	
	d5-N-EiFOSAA		6620.43	88.3				20-150%	132.4%	
	M7PFUDa		4857.90	64.8				20-150%	97.2%	
	MPFDoA		3255.48	43.4				20-150%	65.1%	
	M2PFTeDA		2957.91	39.4				20-150%	59.2%	

QC Data

Enthalpy Analytical

Job No.: 1021-840-1 PFAS by Isotope Dilution (non-potable water)
 County of Brunswick N/A Northwest Water Plant, Leland, NC

Enthalpy ID	MB-12534-PFAS	Prep Batch	EU12534	Sample Vol (mL)	250
Sample Name	MB-12534-PFAS	Prep Date	2021-11-01 16:09	Extract Vol (mL)	0.4
Matrix	Aqueous	Analysis Date	2021-11-05 06:23	Dilution Factor	1
Sampling Date		Analyst	avheadrick	Method Code	WM-026
Received Date	2021-11-01 16:09	Instrument	Kili	Sample Type	Blank

	Compound	CAS	Extract Concentration ng/L	Sample Concentration ng/L	Formatted Result ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags	
Acids	PFBA	375-22-4	ND	ND	ND	0.153	0.304			U	
	PFPeA	2706-90-3	ND	ND	ND	0.170	0.304			U	
	PFHxA	307-24-4	ND	ND	ND	0.193	0.304			U	
	PFHpA	375-85-9	ND	ND	ND	0.122	0.304			U	
	PFOA	335-67-1	ND	ND	ND	0.177	0.304			U	
	PFNA	375-95-1	ND	ND	ND	0.0761	0.304			U	
	PFDA	335-76-2	ND	ND	ND	0.0845	0.304			U	
	PFUnDA	2058-94-8	26.63	0.0426	0.0426	0.185	0.304			L	
	PFDoDA	307-55-1	ND	ND	ND	0.202	0.304			U	
	PFTrDA	72629-94-8	16.26	0.0260	0.0260	0.151	0.304			L	
	PFTeDA	376-06-7	ND	ND	ND	0.218	0.304			U	
	PFBS	375-73-5	ND	ND	ND	0.355	0.355			U	
Sulfonates	PFPeS	2706-91-4	ND	ND	ND	0.206	0.286			U	
	PFHxS	355-46-4	ND	ND	ND	0.191	0.278			U	
	PFHpS	375-92-8	ND	ND	ND	0.135	0.290			U	
	PFOS	1763-23-1	ND	ND	ND	0.160	0.282			U	
	PFNS	68259-12-1	ND	ND	ND	0.0864	0.293			U	
	PFDS	335-77-3	ND	ND	ND	0.192	0.293			U	
	4:2 FTS	757124-72-4	ND	ND	ND	0.118	0.285			U	
	6:2 FTS	27619-97-2	ND	ND	ND	0.116	0.290			U	
	8:2 FTS	39108-34-4	ND	ND	ND	0.171	0.291			U	
	PFOSA	754-91-6	ND	ND	ND	0.130	0.304			U	
	other	N-MeFOSAA	2355-31-9	ND	ND	ND	0.144	0.304			U
		N-EtFOSAA	2991-50-6	ND	ND	ND	0.109	0.304			U
HFPO-DA		13252-13-6	ND	ND	ND	0.228	0.304			U	
PFMOA		674-13-5	ND	ND	ND	1.44	1.44			U	
PFMOPrA		377-73-1	ND	ND	ND	0.240	0.304			U	
PFO2HxA		39492-88-1	ND	ND	ND	1.44	1.44			U	
PFO3OA		39492-89-2	ND	ND	ND	1.44	1.44			U	
PFO4DA		39492-90-5	ND	ND	ND	1.52	1.52			U	
Nafion Byproduct 1		29311-67-9	ND	ND	ND	0.304	0.304			U	
ADONA		919005-14-4	ND	ND	ND	0.120	0.288			U	
9Cl-PF3ONS		756426-58-1	ND	ND	ND	0.120	0.283			U	
11Cl-PF3OUdS		763051-92-9	ND	ND	ND	0.120	0.286			U	
10:2 FTS		120226-60-0	ND	ND	ND	0.240	0.304			U	
EVE Acid		69087-46-3	ND	ND	ND	1.44	1.44			U	
FBSA		30334-69-1	ND	ND	ND	0.240	0.304			U	
Hydro-EVE Acid		773804-62-9	ND	ND	ND	1.44	1.44			U	
Hydrolyzed PSDA		2416366-19-1	ND	ND	ND	1.44	1.44			U	
Nafion Byproduct 2		749836-20-2	ND	ND	ND	0.304	0.304			U	
N-EtFOSA		4151-50-2	ND	ND	ND	0.240	0.304			U	
N-EtFOSE		1691-99-2	ND	ND	ND	7.20	7.20			U	
NFDHA		151772-58-6	ND	ND	ND	0.240	0.304			U	
N-MeFOSA		31506-32-8	ND	ND	ND	0.240	0.304			U	
N-MeFOSE		24448-09-7	ND	ND	ND	7.20	7.20			U	
NVHOS		1132933-86-8	ND	ND	ND	1.44	1.44			U	
PEPA		267239-61-2	ND	ND	ND	1.44	1.44			U	
PFECA-G		801212-59-9	ND	ND	ND	0.304	1.44			U	
PFEESA		113507-82-7	ND	ND	ND	0.240	0.304			U	
PFHxDA		67905-19-5	ND	ND	ND	1.44	1.44			U	
PFMOBA		863090-89-5	ND	ND	ND	1.44	1.44			U	
PFO5DA		39492-91-6	ND	ND	ND	1.52	1.52			U	
PMPA		13140-29-9	ND	ND	ND	1.44	1.44			U	
R-EVE		2416366-22-6	ND	ND	ND	1.44	1.44			U	
R-PSDA	2416366-18-6	ND	ND	ND	1.44	1.44			U		
R-PSDCA	2416366-21-6	ND	ND	ND	1.44	1.44			U		
ES	MPFBA		4494.02	7.19				20-150%	89.9%		
	M5PFPeA		4807.77	7.69				20-150%	96.2%		
	M3PFBS		4843.64	7.75				20-150%	96.9%		
	M2-4:2 FTS		4438.27	7.10				20-150%	88.8%		
	M5PFHxA		4540.43	7.26				20-150%	90.8%		
	M3HFPO-DA		5645.19	9.03				20-150%	112.9%		
	M4PFHpA		4728.20	7.57				20-150%	94.6%		
	M3PFHxS		4134.40	6.62				20-150%	82.7%		
	M2-6:2 FTS		5118.87	8.19				20-150%	102.4%		
	M8PFOA		4466.87	7.15				20-150%	89.3%		
	M9PFNA		4499.60	7.20				20-150%	90.0%		
	M8PFOS		4499.33	7.20				20-150%	90.0%		
	M2-8:2 FTS		5474.22	8.76				20-150%	109.5%		
	M8FOSA-I		3332.37	5.33				20-150%	66.6%		
	M6PFDA		4321.30	6.91				20-150%	86.4%		
	d3-N-MeFOSAA		4009.28	6.41				20-150%	80.2%		
	d5-N-EtFOSAA		4133.31	6.61				20-150%	82.7%		
	M7PFUDa		4085.33	6.54				20-150%	81.7%		
	MPFDoA		3124.89	5.00				20-150%	62.5%		
	M2PFTeDA		3103.99	4.97				20-150%	62.1%		

Enthalpy Analytical

Job No.: 1021-840-1 PFAS by Isotope Dilution (non-potable water)
 County of Brunswick N/A Northwest Water Plant, Leland, NC

Enthalpy ID	MB-12572-PFAS	Prep Batch	EU12572	Sample Vol (mL)	250
Sample Name	MB-12572-PFAS	Prep Date	2021-11-09 15:10	Extract Vol (mL)	0.4
Matrix	Aqueous	Analysis Date	2021-11-15 16:01	Dilution Factor	1
Sampling Date		Analyst	avheadrick	Method Code	WM-026
Received Date	2021-11-09 15:10	Instrument	Kili	Sample Type	Blank

	Compound	CAS	Extract Concentration ng/L	Sample Concentration ng/L	Formatted Result ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags
Acids	PFBA	375-22-4	ND	ND	ND	0.153	0.304			U
	PFPeA	2706-90-3	ND	ND	ND	0.170	0.304			U
	PFHxA	307-24-4	ND	ND	ND	0.193	0.304			U
	PFHpA	375-85-9	ND	ND	ND	0.122	0.304			U
	PFOA	335-67-1	ND	ND	ND	0.177	0.304			U
	PFNA	375-95-1	ND	ND	ND	0.0761	0.304			U
	PFDA	335-76-2	ND	ND	ND	0.0845	0.304			U
	PFUnDA	2058-94-8	ND	ND	ND	0.185	0.304			U
	PFDoDA	307-55-1	ND	ND	ND	0.202	0.304			U
	PFTeDA	72629-94-8	0.36	0.000581	0.000581	0.151	0.304			L
		376-06-7	27.85	0.0446	0.0446	0.218	0.304			L
Sulfonates	PFBS	375-73-5	ND	ND	ND	0.355	0.355			U
	PFPeS	2706-91-4	ND	ND	ND	0.206	0.286			U
	PFHxS	355-46-4	ND	ND	ND	0.191	0.278			U
	PFHpS	375-92-8	ND	ND	ND	0.135	0.290			U
	PFOS	1763-23-1	ND	ND	ND	0.160	0.282			U
	PFNS	68259-12-1	ND	ND	ND	0.0864	0.293			U
	PFDS	335-77-3	ND	ND	ND	0.192	0.293			U
	4:2 FTS	757124-72-4	ND	ND	ND	0.118	0.285			U
	6:2 FTS	27619-97-2	ND	ND	ND	0.116	0.290			U
	8:2 FTS	39108-34-4	ND	ND	ND	0.171	0.291			U
other	PFOSA	754-91-6	ND	ND	ND	0.130	0.304			U
	N-MeFOSAA	2355-31-9	ND	ND	ND	0.144	0.304			U
	N-EtFOSAA	2991-50-6	ND	ND	ND	0.109	0.304			U
	HFPO-DA	13252-13-6	ND	ND	ND	0.228	0.304			U
	PFMOA	674-13-5	ND	ND	ND	1.44	1.44			U
	PFMOPrA	377-73-1	ND	ND	ND	0.240	0.304			U
	PFO2HxA	39492-88-1	ND	ND	ND	1.44	1.44			U
	PFO3OA	39492-89-2	ND	ND	ND	1.44	1.44			U
	PFO4DA	39492-90-5	ND	ND	ND	1.52	1.52			U
	Nafion Byproduct 1	29311-67-9	ND	ND	ND	0.304	0.304			U
	ADONA	919005-14-4	ND	ND	ND	0.120	0.288			U
	9Cl-PF3ONS	756426-58-1	ND	ND	ND	0.120	0.283			U
	11Cl-PF3OUdS	763051-92-9	ND	ND	ND	0.120	0.286			U
	10:2 FTS	120226-60-0	ND	ND	ND	0.240	0.304			U
	EVE Acid	69087-46-3	53.55	0.0857	0.0857	1.44	1.44			L
	FBSA	30334-69-1	ND	ND	ND	0.240	0.304			U
	Hydro-EVE Acid	773804-82-9	37.46	0.0599	0.0599	1.44	1.44			L
	Hydrolyzed PSDA	2416366-19-1	71.64	0.115	0.115	1.44	1.44			L
	Nafion Byproduct 2	749836-20-2	ND	ND	ND	0.304	0.304			U
	N-EtFOSA	4151-50-2	ND	ND	ND	0.240	0.304			U
	N-EtFOSE	1691-99-2	ND	ND	ND	7.20	7.20			U
	NFDHA	151772-58-6	ND	ND	ND	0.240	0.304			U
	N-MeFOSA	31506-32-8	ND	ND	ND	0.240	0.304			U
	N-MeFOSE	24448-09-7	ND	ND	ND	7.20	7.20			U
	NVHOS	1132933-86-8	58.47	0.0936	0.0936	1.44	1.44			L
	PEPA	267239-61-2	ND	ND	ND	1.44	1.44			U
	PFECA-G	801212-59-9	ND	ND	ND	0.304	1.44			U
	PFEESA	113507-82-7	ND	ND	ND	0.240	0.304			U
	PFHxDA	67905-19-5	ND	ND	ND	1.44	1.44			U
	PFMOBA	863090-89-5	ND	ND	ND	1.44	1.44			U
PFO5DA	39492-91-6	ND	ND	ND	1.52	1.52			U	
PMPA	13140-29-9	ND	ND	ND	1.44	1.44			U	
R-EVE	2416366-22-6	ND	ND	ND	1.44	1.44			U	
R-PSDA	2416366-18-6	ND	ND	ND	1.44	1.44			U	
R-PSDCA	2416366-21-6	39.30	0.0629	0.0629	1.44	1.44			L	
ES	MIPFA		4908.67	7.85				20-150%	98.2%	
	M5PFPeA		5112.39	8.18				20-150%	102.2%	
	M3PFBS		4253.76	6.81				20-150%	85.1%	
	M2-4:2 FTS		6006.98	9.61				20-150%	120.1%	
	M5PFHxA		4109.60	6.58				20-150%	82.2%	
	M3HFPO-DA		4797.71	7.68				20-150%	96.0%	
	M4PFHpA		4439.52	7.10				20-150%	88.8%	
	M3PFHxS		3757.60	6.01				20-150%	75.2%	
	M2-6:2 FTS		6283.64	10.1				20-150%	125.7%	
	M8PFOA		4441.35	7.11				20-150%	88.8%	
	M9PFNA		4143.87	6.63				20-150%	82.9%	
	M8PFOS		4284.35	6.85				20-150%	85.7%	
	M2-8:2 FTS		6662.41	10.7				20-150%	133.2%	
	M8FOSA-I		3435.19	5.50				20-150%	68.7%	
	M6PFDA		4666.90	7.47				20-150%	93.3%	
	d3-N-MeFOSAA		5921.42	9.47				20-150%	118.4%	
	d5-N-EtFOSAA		5407.04	8.65				20-150%	108.1%	
	M7PFUDa		4110.55	6.58				20-150%	82.2%	
	MIPFDoA		3038.52	4.86				20-150%	60.8%	
	M2PFTeDA		2927.45	4.68				20-150%	58.5%	

Enthalpy Analytical

Job No.: 1021-840-1 PFAS by Isotope Dilution (non-potable water)

County of Brunswick N/A Northwest Water Plant, Leland, NC

Enthalpy ID	OPR-12534-PFAS	Prep Batch	EU12534	Sample Vol (mL)	250
Sample Name	OPR-12534-PFAS	Prep Date	2021-11-01 16:09	Extract Vol (mL)	0.4
Matrix	Aqueous	Analysis Date	2021-11-04 21:28	Dilution Factor	1
Sampling Date		Analyst	avheadrick	Method Code	WM-026
Received Date	2021-11-01 16:09	Instrument	Kili	Sample Type	Control

	Compound	CAS	Extract Concentration ng/L	Sample Concentration ng/L	Formatted Result ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags
Acids	PFBA	375-22-4	10910.57	17.5	17.5	0.153	0.304	73-129%	87.3%	
	PFPeA	2706-90-3	11676.64	18.7	18.7	0.170	0.304	72-129%	93.4%	
	PFHxA	307-24-4	11831.04	18.9	18.9	0.193	0.304	72-129%	94.6%	
	PFHpA	375-85-9	12616.94	20.2	20.2	0.122	0.304	72-130%	100.9%	
	PFOA	335-67-1	11625.64	18.6	18.6	0.177	0.304	71-133%	93.0%	
	PFNA	375-95-1	11168.98	17.9	17.9	0.0761	0.304	69-130%	89.4%	
	PFDA	335-76-2	11838.89	18.9	18.9	0.0845	0.304	71-129%	94.7%	
	PFUnDA	2058-94-8	12169.62	19.5	19.5	0.185	0.304	69-133%	97.4%	
	PFDoDA	307-55-1	12973.22	20.8	20.8	0.202	0.304	72-134%	103.8%	
	PFTTrDA	72629-94-8	15730.49	25.2	25.2	0.151	0.304	65-144%	125.8%	
Sulfonates	PFTeDA	376-06-7	14015.24	22.4	22.4	0.218	0.304	71-132%	112.1%	
	PFBS	375-73-5	10330.36	16.5	16.5	0.355	0.355	72-134%	93.2%	
	PFPeS	2706-91-4	11179.12	17.9	17.9	0.206	0.286	71-127%	95.0%	
	PFHxS	355-46-4	10329.47	16.5	16.5	0.191	0.278	68-131%	90.4%	
	PFHpS	375-92-8	10400.16	16.6	16.6	0.135	0.290	69-134%	87.3%	
	PFOS	1763-23-1	9993.89	16.0	16.0	0.160	0.282	65-140%	86.2%	
	PFNS	68259-12-1	10280.82	16.4	16.4	0.0864	0.293	69-127%	85.5%	
	PFDS	335-77-3	9877.30	15.8	15.8	0.192	0.293	53-142%	81.9%	
	4:2 FTS	757124-72-4	11728.55	18.8	18.8	0.118	0.285	63-143%	100.1%	
	6:2 FTS	27619-97-2	8404.04	13.4	13.4	0.116	0.290	64-140%	70.7%	
Other	8:2 FTS	39108-34-4	11491.40	18.4	18.4	0.171	0.291	67-138%	95.8%	
	PFOSA	754-91-6	13326.65	21.3	21.3	0.130	0.304	67-137%	106.6%	
	N-MeFOSAA	2355-31-9	11746.27	18.8	18.8	0.144	0.304	65-136%	94.0%	
	N-EtFOSAA	2991-50-6	11590.71	18.5	18.5	0.109	0.304	61-135%	92.7%	
ES	HFPO-DA	13252-13-6	13930.90	22.3	22.3	0.228	0.304	70-130%	111.4%	
	MFPBA		5051.72	8.08				20-150%	101.0%	
	M5PFPeA		5014.23	8.02				20-150%	100.3%	
	M3PFBS		4711.51	7.54				20-150%	94.2%	
	M2-4:2 FTS		4703.54	7.53				20-150%	94.1%	
	M5PFHxA		4821.26	7.71				20-150%	96.4%	
	M3HFPO-DA		5534.46	8.86				20-150%	110.7%	
	M4PFHpA		4887.19	7.82				20-150%	97.7%	
	M3PFHxS		4500.37	7.20				20-150%	90.0%	
	M2-6:2 FTS		5426.15	8.68				20-150%	108.5%	
	M8PFOA		4869.42	7.79				20-150%	97.4%	
	M9PFNA		4676.84	7.48				20-150%	93.5%	
	M8PFOS		4930.83	7.89				20-150%	98.6%	
	M2-8:2 FTS		4401.10	7.04				20-150%	88.0%	
	M8FOSA-I		3478.79	5.57				20-150%	69.6%	
	M6PFDA		4991.07	7.99				20-150%	99.8%	
	d3-N-MeFOSAA		3974.40	6.36				20-150%	79.5%	
	d5-N-EtFOSAA		3873.32	6.20				20-150%	77.5%	
	M7PFUdA		4357.09	6.97				20-150%	87.1%	
	MPFDoA		3090.32	4.94				20-150%	61.8%	
M2PFTeDA		2325.82	3.72				20-150%	46.5%		

Enthalpy Analytical

Job No.: 1021-840-1 PFAS by Isotope Dilution (non-potable water)

County of Brunswick N/A Northwest Water Plant, Leland, NC

Enthalpy ID	OPR-12572-PFAS	Prep Batch	EU12572	Sample Vol (mL)	250
Sample Name	OPR-12572-PFAS	Prep Date	2021-11-09 15:10	Extract Vol (mL)	0.4
Matrix	Aqueous	Analysis Date	2021-11-12 07:11	Dilution Factor	1
Sampling Date		Analyst	avheadrick	Method Code	WM-026
Received Date	2021-11-09 15:10	Instrument	Kili	Sample Type	Control

	Compound	CAS	Extract Concentration ng/L	Sample Concentration ng/L	Formatted Result ng/L	LOD ng/L	LOQ ng/L	Recovery Limits	Recovery	Flags
Acids	PFBA	375-22-4	10717.44	17.1	17.1	0.153	0.304	73-129%	85.7%	
	PFPeA	2706-90-3	11812.41	18.9	18.9	0.170	0.304	72-129%	94.5%	
	PFHxA	307-24-4	11510.21	18.4	18.4	0.193	0.304	72-129%	92.1%	
	PFHpA	375-85-9	10755.81	17.2	17.2	0.122	0.304	72-130%	86.0%	
	PFOA	335-67-1	11786.09	18.9	18.9	0.177	0.304	71-133%	94.3%	
	PFNA	375-95-1	11492.30	18.4	18.4	0.0761	0.304	69-130%	91.9%	
	PFDA	335-76-2	10717.08	17.1	17.1	0.0845	0.304	71-129%	85.7%	
	PFUnDA	2058-94-8	11749.37	18.8	18.8	0.185	0.304	69-133%	94.0%	
	PFDoDA	307-55-1	11572.03	18.5	18.5	0.202	0.304	72-134%	92.6%	
	PFTTrDA	72629-94-8	12301.92	19.7	19.7	0.151	0.304	65-144%	98.4%	
Sulfonates	PFTeDA	376-06-7	11400.59	18.2	18.2	0.218	0.304	71-132%	91.2%	
	PFBS	375-73-5	9456.54	15.1	15.1	0.355	0.355	72-134%	85.3%	
	PFPeS	2706-91-4	10916.30	17.5	17.5	0.206	0.286	71-127%	92.8%	
	PFHxS	355-46-4	10563.60	16.9	16.9	0.191	0.278	68-131%	92.5%	
	PFHpS	375-92-8	10916.69	17.5	17.5	0.135	0.290	69-134%	91.6%	
	PFOS	1763-23-1	9975.46	16.0	16.0	0.160	0.282	65-140%	86.0%	
	PFNS	68259-12-1	10523.01	16.8	16.8	0.0864	0.293	69-127%	87.5%	
	PFDS	335-77-3	10370.50	16.6	16.6	0.192	0.293	53-142%	86.0%	
	4:2 FTS	757124-72-4	11259.73	18.0	18.0	0.118	0.285	63-143%	96.1%	
	6:2 FTS	27619-97-2	9709.46	15.5	15.5	0.116	0.290	64-140%	81.7%	
Other	8:2 FTS	39108-34-4	9781.61	15.7	15.7	0.171	0.291	67-138%	81.5%	
	PFOSA	754-91-6	10980.04	17.6	17.6	0.130	0.304	67-137%	87.8%	
	N-MeFOSAA	2355-31-9	11134.27	17.8	17.8	0.144	0.304	65-136%	89.1%	
	N-EtFOSAA	2991-50-6	11324.25	18.1	18.1	0.109	0.304	61-135%	90.6%	
ES	HFPO-DA	13252-13-6	10524.51	16.8	16.8	0.228	0.304	70-130%	84.2%	
	MFPBA		5380.24	8.61				20-150%	107.6%	
	M5PFPeA		5212.29	8.34				20-150%	104.2%	
	M3PFBS		4843.27	7.75				20-150%	96.9%	
	M2-4:2 FTS		7104.59	11.4				20-150%	142.1%	
	M5PFHxA		4467.55	7.15				20-150%	89.4%	
	M3HFPO-DA		6108.79	9.77				20-150%	122.2%	
	M4PFHpA		4702.46	7.52				20-150%	94.0%	
	M3PFHxS		5086.60	8.14				20-150%	101.7%	
	M2-6:2 FTS		7548.78	12.1				20-150%	151.0%	Q
	M8PFOA		4676.09	7.48				20-150%	93.5%	
	M9PFNA		4175.61	6.68				20-150%	83.5%	
	M8PFOS		5121.96	8.20				20-150%	102.4%	
	M2-8:2 FTS		7068.83	11.3				20-150%	141.4%	
	M8FOSA-I		4249.31	6.80				20-150%	85.0%	
	M6PFDA		5040.94	8.07				20-150%	100.8%	
	d3-N-MeFOSAA		7100.92	11.4				20-150%	142.0%	
	d5-N-EtFOSAA		6661.30	10.7				20-150%	133.2%	
M7PFUdA		4966.32	7.95				20-150%	99.3%		
MPFDoA		4153.09	6.64				20-150%	83.1%		
M2PFTeDA		4501.23	7.20				20-150%	90.0%		

Narrative Summary



Enthalpy Analytical Narrative Summary

Company	County of Brunswick
Job No.	1021-840-1 PFAS by Isotope Dilution (non-potable water)
Client ID.	N/A Site: Northwest Water Plant, Leland, NC

1. Custody

Lois Walton received the samples on October 29, 2021 at 4.1 °C after being relinquished by County of Brunswick. The samples were received in good condition.

Prior to, during, and after analysis, the samples were kept under lock with access only to authorized personnel by Enthalpy Analytical, LLC

Table 1 - Sample Inventory

EU Lab Sample ID	Client Sample ID	Matrix
1021-840-001-1	102921S01	Aqueous
1021-840-002-2	102921E01	Aqueous

Table 2 - Sample Inventory – not reported

EU Lab Sample ID	Client Sample ID
1021-840-002-1	102921E01

2. Methods and Analytes

A list of analytes of interest and corresponding methods of analysis is shown in Table 3. Abbreviations are defined in the listed Appendices.

Table 3 - Methods and Analytes

EU Method	Analytes	Cleanup Method
EU-047	brunswick pfas list	ENVI-Carb

3. Analysis

The samples were analyzed by isotope dilution method for PFAS using Waters Acquity UPLC equipped with Xevo TQ MS (LC/MS/MS “Kill”).

For aqueous samples, the sample volume was measured gravimetrically by the laboratory, and spiked with Extraction Standard (ES). The sample was then mixed well and centrifuged, if needed. The samples were then extracted via SPE, and the extracts were cleaned up using ENVI-Carb.

Each final sample extract was transferred to an autosampler vial, spiked with Injection Standard (IS), and brought to a final volume of 400µL prior to analysis.

Samples were run in more than one sequence. See the Reporting Notes section for comments.

Enthalpy Analytical Narrative Summary

Company	County of Brunswick
Job No.	1021-840-1 PFAS by Isotope Dilution (non-potable water)
Client ID.	N/A Site: Northwest Water Plant, Leland, NC

4. Calibration

In the initial calibration, the reported analytes exhibited R^2 of ≥ 0.99 . The reported analytes in the calibration standards, continuing calibration (concal) and Initial Calibration Verification (ICV) met the accuracy criterion for native analytes.

5. QC Notes

Except where noted below, the QC sample analyses passed all method criteria.

QC samples that did not meet method acceptance criteria were:

OPR-12572-PFAS M2-6:2 FTS - The labeled extraction standard in the QC sample analysis fell outside the control limits for ES recovery, as denoted by the "Q" qualifier. The target analytes are quantified based on their ratio to their labeled standard analogs. As a result, low or high labeled standard recovery do not cause any change to ratios or contribute any additional error in the measurement of the target analytes. The data have been accepted and reported with no further actions.

The samples were extracted within the 28-day from collection holding time and analyzed within the 28-day from extraction to analysis holding time required by the method.

6. Reporting Notes

The initial analysis required reinjection due to MB contamination and failing concals; no data was reported from the original injection.

Sample 102921E01 (1021-840-002) was reinjected at D5 dilution due to negligible ES recovery for all analytes. The reinjection did not improve which required the sample to be re-extracted. The sample was re-extracted using a 30mL volume.

The summary is a combined report of the analyses of the initial and re-extracted samples.

Some labeled extraction standards in the sample analyses fell outside the control limits for ES recovery, as denoted by the "Q" qualifier. The target analytes are quantified based on their ratio to their labeled standard analogs. As a result, low or high labeled standard recovery do not cause any change to ratios or contribute any additional error in the measurement of the target analytes. The data have been accepted and reported with no further actions.

The results presented in this report are representative of the samples as provided to the laboratory.

These analyses met the requirements of the TNI Standard. Any deviations from the requirements of the reference method or TNI Standard have been stated above.

Enthalpy Analytical, LLC in Wilmington NC is accredited by the Louisiana Department of Environmental Quality to the 2009 TNI Standard under certificate number 05075.



General Reporting Notes – Data Qualifiers

The following are general reporting notes that are applicable to all Enthalpy Analytical, LLC - Wilmington, NC data reports, unless specifically noted otherwise.

General Data Qualifiers

- B – The analyte was found in the method blank, at a concentration that was at least 10% of the concentration in the sample.
- Cxx – Two or more congeners co-elute. In EDDs, C denotes the lowest IUPAC congener in a co-elution group and additional co-eluters for the group ('xx') are shown with the number of the lowest IUPAC co-eluter.
- E – The reported concentration exceeds the calibration range (upper point of the calibration curve). For HRMS data, this condition does not imply additional measurement uncertainty. For LC-MS/MS data, these values should be considered as having measurement uncertainty higher than values within the calibration range.
- EDL – Estimated Detection Level. Specific to Dioxin/Furan tests and equivalent to MDL
- EMPC – Estimated Maximum Possible Concentration Specific to Dioxin/Furan tests to indicate the signal/noise ratio was not sufficient for peak identification (the determined ion-abundance ratio was outside the allowed theoretical range), or where there was a co-eluting interference. Indicates that a peak was identified but did not meet the method specified ion-abundance ratio.
- IR – The ion ratio between the primary and secondary ions was observed to be outside the method criteria therefore the actual analyte concentration cannot be accurately determined as defined by DoD QSM Table B-15.
- J – The analyte has a concentration below the minimum calibration level (LOQ value) but greater than the LOD. These values should be considered as having measurement uncertainty higher than values within the calibration range
- L - Indicates that an analyte has a concentration below the Minimum Detection Limit (MDL). The reported concentration is not recommended for regulatory use as the analyte signal may have a signal-to-noise ratio less than the criteria deemed necessary to be considered a detected analyte.
- LOD – Limit of Detection: For reports conforming to the DOD ELAP QSM, this is the QSM-defined LOD. For reports conforming to TNI requirements (but not DOD ELAP QSM requirements), this value is the minimum detection limit (MDL). The LOD is adjusted for sample weight or volume.
- LOQ – Limit of Quantiation: For reports conforming to the DOD ELAP QSM, this is the QSM-defined LOQ. For reports conforming to TNI requirements (but not DOD ELAP QSM requirements), this value is the reporting limit (RL). The LOD is adjusted for sample weight or volume.
- <LOD() – Analyte was not found at a concentration high enough to be reported as detected. It is reported as less than the LOD, and the LOD is given in the parentheses.



General Reporting Notes – Data Qualifiers

- ND – Indicates a non-detect.
- NR – Indicates a value that is not reportable due to issues observed in sample preparation or analysis.
- PR – The associated congener(s) is(are) poorly resolved.
- QI – Indicates the presence of a quantitative interference.
- RL – Reporting Limit. Lowest reportable value. The level is higher than the MDL.
- SI – Denotes “Single Ion Mode” and is utilized for PCBs where the secondary ion trace has a significantly elevated noise level due to background PFK. Responses for such peaks are calculated using an EMPC approach based solely on the primary ion area(s) and may be considered estimates.
- U – The analyte was not detected.
- V / Q – The labeled standard recovery is not within method control limits.
- X – Results from re-injection/repeat/second-column analysis.

Lab Identifiers/ Data Attributes

- AR – Indicates use of the archived portion of the sample extract.
- CU – Indicates a sample that required additional clean-up prior to HRMS injection/processing.
- D – Dilution Data. Result was obtained from the analysis of a dilution. The number that follows the “D” indicates the dilution factor.
- DE – Indicates a dilution performed with the addition of ES (Extraction Standard) solution.
- DUP – Designation for a duplicate sample.
- MS – Designation for a matrix spike.
- MSD – Designation for a matrix spike duplicate.
- RJ – Indicates a reinjection of the sample extract.
- S – Indicates a sample split. The number that follows the “S” indicates the split factor.
- R – Indicates a re-extraction of the sample.

PFAS Compound Acronym List

Acronym	Compound Name	CAS #
Target Analytes		
PFBA	Perfluorobutanoic Acid	375-22-4
PFPeA	Perfluoropentanoic Acid	2706-90-3
PFHxA	Perfluorohexanoic Acid	307-24-4
PFHpA	Perfluoroheptanoic Acid	375-85-9
PFOA	Perfluorooctanoic Acid	335-67-1
PFNA	Perfluorononanoic Acid	375-95-1
PFDA	Perfluorodecanoic acid	335-76-2
PFUnA (PFUnDA)	Perfluoroundecanoic acid	2058-94-8
PFDoA (PFDoDA)	Perfluorododecanoic acid	307-55-1
PFTriA (PFTriA)	Perfluorotridecanoic acid	72629-94-8
PFTeDA (PFTA)	Perfluorotetradecanoic acid	376-06-7
PFBS	Perfluorobutane sulfonic acid	375-73-5
PFPeS	Perfluoropentane sulfonic acid	2706-91-4
PFHxS	Perfluorohexane sulfonic acid	355-46-4
PFHpS	Perfluoroheptane sulfonic acid	375-92-8
PFOS	Perfluorooctane sulfonic acid	1763-23-1
PFNS	Perfluorononane sulfonic acid	68259-12-1
PFDS	Perfluorodecane sulfonic acid	335-77-3
4:2 FTS	4:2 fluorotelomer sulfonic acid	757124-72-4
6:2 FTS	6:2 fluorotelomer sulfonic acid	27619-97-2
8:2 FTS	8:2 fluorotelomer sulfonic acid	39108-34-4
PFOSA (FOSA)	Perfluorooctane sulfonamide	754-91-6
N-MeFOSAA	N-methyl perfluorooctane sulfonamido acetic acid	2355-31-9
N-EtFOSAA	N-ethyl perfluorooctane sulfonamido acetic acid	2991-50-6
HFPO-DA	2,3,3,3-Tetrafluoro-2-(1,1,2,2,3,3,3-heptafluoropropoxy)-propanoic acid (Gen-X)	13252-13-6
11Cl-PF3OUdS	11-chloroeicosafluoro-3-oxaundecane-1-sulfonic acid	763051-92-9
9Cl-PF3ONS	9-chlorohexadecafluoro-3-oxanonane-1-sulfonic acid	756426-58-1
ADONA	4,8-dioxa-3H-perfluorononanoic acid	919005-14-4
* PFMOAA	Perfluoro-2-methoxyacetic acid	674-13-5
PFMOPrA (PFMPA)	Perfluoro-3-methoxypropanoic acid	377-73-1
* PFO2HxA	Perfluoro (3,5-dioxahexanoic) acid	39492-88-1
* PFO3OA	Perfluoro (3,5,7-trioxaoctanoic) acid	39492-89-2
* PFO4DA	Perfluoro (3,5,7,9-tetraoxadecanoic) acid	39492-90-5
* PFO5DA	Perfluoro(3,5,7,9,11-pentaoxadodecanoic) acid	39492-91-6
* Nafion Byproduct 1	Nafion Byproduct 1	29311-67-9
* Nafion Byproduct 2	Nafion Byproduct 2	749836-20-2
PFEESA	Perfluoro(2-ethoxyethane)sulphonic acid	113507-82-7
PFMOBA (PFMBA)	Perfluoro-4-methoxybutanic acid	863090-89-5
NFDHA	Nonafluoro-3,6-dioxaheptanoic acid	151772-58-6
* PEPA	Perfluoro-2-ethoxypropanoic acid	267239-61-2
* PMPA	Perfluoro-2-methoxypropanoic acid	13140-29-9
* 10:2 FTS	Fluorotelomer sulfonate 10:2	120226-60-0
* N-EtFOSA	N-ethylperfluoro-1-octanesulfonamide	4151-50-2
* N-EtFOSE	2-(N-methylperfluoro-1-octanesulfonamido)-ethanol	1691-99-2
* N-MeFOSA	N-methylperfluoro-1-octanesulfonamide	31506-32-8
* N-MeFOSE	2-(N-methylperfluoro-1-octanesulfonamido)-ethanol	24448-09-7
* PFECA-G	4-(Heptafluoroisopropoxy)hexafluorobutanoic acid	801212-59-9
* PFHxDA	Perfluorohexadecanoic acid	67905-19-5
* R-PSDA	Perfluoro-4-(2-sulfoethoxy)pentanoic acid	2416366-18-0

* Hydrolyzed PSDA	2-fluoro-2-[1,1,2,3,3,3-hexafluoro-2-(1,1,2,2-tetrafluoro-2-sulfoethoxy)propoxy]-acetic acid	2416366-19-1
* R-PSDCA	1,1,2,2-tetrafluoro-2-[1,2,2,3,3-pentafluoro-1-(trifluoromethyl)propoxy] ethanesulfonic acid	2416366-21-5
* EVE Acid	2,2,3,3-tetrafluoro-3-([1,1,1,2,3,3-hexafluoro-3-[(1,2,2-trifluoroethenyl)oxy]propan-2-yl)oxy)propionic acid	69087-46-3
* FBSA	Perfluorobutylsulfonamide	30334-69-1
* Hydro-EVE Acid	2,2,3,3-Tetrafluoro-3-([1,1,1,2,3,3-hexafluoro-3-(1,2,2-tetrafluoroethoxy)propan-2-yl)oxy)propanoic acid	773804-62-9
* R-EVE Acid	4-(2-carboxy-1,1,2,2-tetrafluoroethoxy)-2,2,3,3,4,5,5,5-octafluoro-pentanoic acid	2416366-22-6
NVHOS	Perfluoroethoxysulfonic acid	1132933-86-8
Extraction Standards		
MPFBA	Perfluoro-n-[13C4]butanoic acid	
M5PFPeA	Perfluoro-n-[13C5]pentanoic acid	
M3PFBS	Sodium perfluoro-1-[2,3,4-13C3]-butanesulfonic acid	
M2-4:2 FTS	Sodium 1H,1H,2H,2H-perfluoro-1-[1,2-13C2]-hexane sulfonic acid	
M5PFHxA	Perfluoro-n-[1,2,3,4,6-13C5]hexanoic acid	
M3HFPO-DA	2,3,3,3-Tetrafluoro-2-(1,1,2,2,3,3,3-heptafluoropropoxy)-13C3-propanoic acid	
M4PFHpA	Perfluoro-n-[1,2,3,4-13C4]heptanoic acid	
M3PFHxS	Sodium perfluoro-1-[1,2,3-13C3]-hexanesulfonic acid	
M2-6:2 FTS	Sodium 1H,1H,2H,2H-perfluoro-1-[1,2-13C2]-octane sulfonic acid	
M8PFOA	Perfluoro-n-[13C8]octanoic acid	
M9PFNA	Perfluoro-n-[13C9]nonanoic acid	
M8PFOS	Sodium perfluoro-1-[13C8]-octanesulfonic acid	
M2-8:2 FTS	Sodium 1H,1H,2H,2H-perfluoro-1-[1,2-13C2]-decane sulfonic acid	
M8FOSA	Perfluoro-1-[13C8]octanesulfonamide	
M6PFDA	Perfluoro-n-[1,2,3,4,5,6-13C6]decanoic acid	
d3-N-MeFOSAA	N-methyl-d3-perfluoro-1-octanesulfonamide	
d5-N-EtFOSAA	N-ethyl-d5-perfluoro-1-octanesulfonamide	
M7PFUnDA (M7PFUdA)	Perfluoro-n-[1,2,3,4,5,6,7-13C7]undecanoic acid	
MPFDoA	Perfluoro-n-[1,2-13C2]dodecanoic acid	
M2PFTeDA	Perfluoro-n-[1,2-13C2]tetradecanoic acid	
Injection Standards		
M3PFBA	Perfluoro-n-[2,3,4-13C3]butanoic acid	
M2PFOA	Perfluoro-n-[1,2-13C2]octanoic acid	
MPFDA	Perfluoro-n-[1,2-13C2]decanoic acid	
MPFOS	Sodium perfluoro-1-[1,2,3,4-13C4]-octanesulfonic acid	

* Analytes are currently not accredited under TNI Scope - Accreditation pending.

Sample Custody



**This Is The Last Page
Of This Report.**