

County of Brunswick

3954 Clearwell Dr NE
Leland, NC 28451

Northwest Plant
Leland, NC

Samples Received: 7-11-19

Analytical Report
0719-721R

Isotope Dilution Method

Legacy 24 + Gen-X PFAS



Enthalpy Analytical, LLC – Ultratrace

Lindsay Boone

O: (910) 212-5855 / F: 910-212-5866 / M: 910-544-6077

lboone@enthalpy.com / www.enthalpy.com

2714 Exchange Drive, Wilmington, NC 28405

I certify that to the best of my knowledge all analytical data presented in this report:

- Have been checked for completeness
- Are accurate, error-free, and legible
- Have been conducted in accordance with approved protocol, and that all deviations and analytical problems are summarized in the appropriate narrative(s)

This analytical report was prepared in Portable Document Format (.PDF) and contains _____ pages.

Report Issued Date: _____



Summary of Results

Summary of Results: PFAS
Enthalpy Ultratrace Batch #
10371
PFAS

Analyte	Method Blank ng/L	071119-S01 ng/L	071119-E01 ng/L
Acids			
PFBA	0.169 J	10.8	10.2
PFPeA	0.168 J	24.1	24.9
PFHxA	0.377	22.1	22.7
PFHpA	0.106 J	14.1	14.2
PFOA	0.124 J	8.52	8.24
PFNA	0.104 J	1.42	1.28
PFDA	0.178 J	1.21 B	1.05 B
PFUnA	ND U	0.502	0.332
PFDoA	0.139 J	ND U	ND U
PFTTrA	0.138 J	ND U	ND U
PFTA	ND U	ND U	ND U
Sulfonates			
L-PFBS	0.0930 J	5.71	6.00
PFPeS	ND U	2.07	1.59
PFHxS	0.0955 J	7.47	6.33
PFHpS	0.0641 J L	0.622	0.467 B
PFOS	ND U	18.1	14.9
PFNS	0.208 J	ND U	ND U
PFDS	0.200 J	ND U	ND U
4:2 FTS	ND U	ND U	ND U
6:2 FTS	0.112 J	0.258 J B	0.295 J B
8:2 FTS	0.191 J	ND U	ND U
Other			
PFOSA	0.0430 J L	ND U	ND U
N-MeFOSAA	ND U	ND U	ND U
N-EtFOSAA	0.215 J	ND U	ND U
HFPO-DA (Gen-X)	ND U	10.2 J	18.3
Lab Sample ID	LMB_10371	0719-721_10371_001	0719-721_10371_002

Narrative Summary

Enthalpy Analytical Narrative Summary

Company	County of Brunswick
Job#	0719-721 PFAS
Client Project #	n/a

Custody	Hunter Allen of Enthalpy Analytical Wilmington received the samples (via client courier) on 07/11/19 on ice at 12°C in good condition. Prior to, during, and after analysis, the samples were stored in the laboratory with access only by authorized personnel of Enthalpy Analytical, LLC.
Analysis	The samples were analyzed by isotope dilution method for PFAS using Waters Acquity UPLC equipped with Xevo TQ MS (LC/MS/MS “Kili”). For aqueous samples, 250mL aliquot was weighed and spiked with Extraction Standard (ES). The sample was then mixed well and centrifuged. Cleanup procedures were performed on the supernatant and then extracted via SPE. Each final sample extract was transferred to an autosampler vial and spiked with 400 µL of Injection Standard (IS), prior to analysis.
Calibration	The analytes and labeled standards of interest in the initial calibration exhibited RSDs less than 50%. All analytes passed the R² coefficient correlation criteria. The continuing calibration (concal) met the ±30% criteria for native analytes of interest.
QC Notes	The OPR met the ±50% criteria for ES recoveries and ±30% Recovery of target concentration. Some analytes were detected in the method blank above the LOD. Any analytes observed in the sample at more than 10 times the analyte sample amount in the MB are notated with a “B” qualifier.
Reporting Notes	This report has been revised to include all analytical parameters and supersedes the report issued 7/25/19. The opening concal did not meet method criteria for M2PFTeDA exhibiting low ES recoveries during the initial extraction. An investigation was initiated and samples re-extracted for this analyte. The analyte passed all parameters in opening and continuing concals however, continued to be an issue in the OPR and MB. The initial data is reported. The samples were originally extracted within the 14-day from collection holding time (on July 17) as well as the re-extraction (on July 25). Extracts were analyzed within the 28-days from extraction to analysis holding time required by the method.

Enthalpy Analytical Narrative Summary

(continued)

Reporting Notes (continued)

Some analytes in the samples were detected below the LOQ. Some of these analytes were also detected in the method blank exhibiting values more than 1/10 the sample amount. The analytes detected in the samples are notated with a “B” qualifier.

Some analytes in the samples fell outside the limits for ES recoveries. It is concluded to be due to matrix effects. Based on the native results in the OPR meeting criteria, the out-of- range ES recoveries have no impact on the accuracy of the target analyte (native) compounds. Therefore, the data are considered acceptable.

The results presented in this report are representative of the samples as provided to the laboratory.

These analyses met the requirements of the TNI Standard. Any deviations from the requirements of the reference method or TNI Standard have been stated above.

The samples, calibrations and standards for the data presented in this report were analyzed at 2714 Exchange Drive, Wilmington, NC 28405.



General Reporting Notes – Data Qualifiers

The following are general reporting notes that are applicable to all Enthalpy Analytical, Inc.-Wilmington, NC data reports, unless specifically noted otherwise.

General Data Qualifiers / Data Attributes

- B – The analyte was found in the method blank, at a concentration that was at least 10% of the concentration in the sample.
- C – Two or more congeners co-elute. In EDDs, C denotes the lowest IUPAC congener in a co-elution group and additional co-eluters for the group are shown with the number of the lowest IUPAC co-eluter.
- E – The reported concentration exceeds the calibration range (upper point of the calibration curve).
- EMPC – Represents an estimated maximum possible concentration. EMPCs arise in cases where the signal/noise ratio is not sufficient for peak identification (the determined ion-abundance ratio is outside the allowed theoretical range), or where there is a co-eluting interference.
- J – Indicates that an analyte has a concentration below the reporting limit (lowest point of the calibration curve).
- L - Indicates that an analyte has a concentration below the Minimum Detection Limit (MDL).
- ND – Indicates a non-detect.
- NR – Indicates a value that is not reportable.
- PR – Due to interference, the associated congener is poorly resolved.
- DI – Indicates the presence of a quantitative interference.
- SI – Denotes “Single Ion Mode” and is utilized for PCBs where the secondary ion trace has a significantly elevated noise level due to background PFK. Responses for such peaks are calculated using an EMPC approach based solely on the primary ion area(s) and may be considered estimates.
- U – The analyte was not detected. The Estimated Detection Limit (EDL) may be reported for this analyte.
- V – The labeled standard recovery was found to be outside of the method control limits.

DRBC/TMDL Specific Data Qualifiers / Data Attributes

- J – The reported result is an estimate. The value is less than the minimum calibration level but greater than the Estimated Detection Limit (EDL).
- U – The analyte was not detected in the sample at the Estimated Detection Limit (EDL).

General Reporting Notes – Data Qualifiers

- E – The reported concentration is an estimate. The value exceeds the upper calibration range (upper point of the calibration curve).
- D – Dilution Data. Result was obtained from the analysis of a dilution.
- B – Analyte found in the sample and associated method blank.
- Cxx – Co-elutes with the indicated congener, data is reported under the lowest IUPAC congener. 'xx' denotes the IUPAC number with the lowest numerical designated congener.
- NR – Analyte is not reportable because of problems in sample preparation or analysis.
- V – Labeled standard recovery is not within method control limits.
- X – Results from re-injection/repeat/second-column analysis.
- EMPC – Estimated Maximum Possible Concentration. Indicates that a peak is identified but did not meet the method specified ion-abundance ratio.

Lab Identifiers

- AR – Indicates use of the archived portion of the sample extract.
- CU – Indicates a sample that required additional clean-up prior to HRMS injection/processing.
- D – Indicates a dilution of the sample extract. The number that follows the “D” indicates the dilution factor.
- DE – Indicates a dilution performed with the addition of ES (Extraction Standard) solution.
- DUP – Designation for a duplicate sample.
- MS – Designation for a matrix spike.
- MSD – Designation for a matrix spike duplicate.
- RJ – Indicates a reinjection of the sample extract.
- S – Indicates a sample split. The number that follows the “S” indicates the split factor.

PFAS Compound Acronym List	
Acronym	Compound Name
Target Analytes	
PFBA	Perfluorobutanoic Acid
PFPeA	Perfluoropentanoic Acid
PFHxA	Perfluorohexanoic Acid
PFHpA	Perfluoroheptanoic Acid
PFOA	Perfluorooctanoic Acid
PFNA	Perfluorononanoic Acid
PFDA	Perfluorodecanoic acid
PFUnDA	Perfluoroundecanoic acid
PFDoDA (PFTDoA)	Perfluorododecanoic acid
PFTTrDA (PFTTrA)	Perfluorotridecanoic acid
PFTeDA (PFTA)	Perfluorotetradecanoic acid
PFBS	Perfluorobutane sulfonate
PFPeS	Perfluoropentane sulfonate
PFHxS	Perfluorohexane sulfonate
PFHpS	Perfluoroheptane sulfonate
PFOS	Perfluorooctane sulfonate
PFNS	Perfluorononane sulfonate
PFDS	Perfluorodecane sulfonate
4:2 FTS	4:2 fluorotelomer sulfonic acid
6:2 FTS	6:2 fluorotelomer sulfonic acid
8:2 FTS	8:2 fluorotelomer sulfonic acid
PFOSA	Perfluorooctane sulfonamide
N-MeFOSAA	N-methyl perfluorooctane sulfonamido acetic acid
N-EtFOSAA	N-ethyl perfluorooctane sulfonamido acetic acid
HFPO-DA	2,3,3,3-Tetrafluoro-2-(1,1,2,2,3,3,3-heptafluoropropoxy)-propanoic acid (Gen-X)
Extraction Standards	
M3PFBA	Perfluoro-n-[2,3,4-13C3]butanoic acid
M5PFPeA	Perfluoro-n-[13C5]pentanoic acid
M3PFBS	Sodium perfluoro-1-[2,3,4-13C3]-butanesulfonate
M2-4:2 FTS	Sodium 1H,1H,2H,2H-perfluoro-1-[1,2-13C2]-hexane sulfonate
M5PFHxA	Perfluoro-n-[1,2,3,4,6-13C5]hexanoic acid
M3HFPO-DA	2,3,3,3-Tetrafluoro-2-(1,1,2,2,3,3,3-heptafluoropropoxy)-13C3-propanoic acid
M4PFHpA	Perfluoro-n-[1,2,3,4-13C4]heptanoic acid
M3PFHxS	Sodium perfluoro-1-[1,2,3-13C3]-hexanesulfonate
M2-6:2 FTS	Sodium 1H,1H,2H,2H-perfluoro-1-[1,2-13C2]-octane sulfonate
M8PFOA	Perfluoro-n-[13C8]octanoic acid
M9PFNA	Perfluoro-n-[13C9]nonanoic acid
M8PFOS	Sodium perfluoro-1-[13C8]-octanesulfonate
M2-8:2 FTS	Sodium 1H,1H,2H,2H-perfluoro-1-[1,2-13C2]-decane sulfonate
M8FOSA	Perfluoro-1-[13C8]octanesulfonamide
M6PFDA	Perfluoro-n-[1,2,3,4,5,6-13C6]decanoic acid
d3-N-MeFOSAA	N-methyl-d3-perfluoro-1-octanesulfonamide
d5-N-EtFOSAA	N-ethyl-d5-perfluoro-1-octanesulfonamide
M7PFUnDA (M7PFUdA)	Perfluoro-n-[1,2,3,4,5,6,7-13C7]undecanoic acid
MPFDoA	Perfluoro-n-[1,2-13C2]dodecanoic acid
M2PFTeDA	Perfluoro-n-[1,2-13C2]tetradecanoic acid

Injection Standards	
MPFBA	Perfluoro-n-[13C4]butanoic acid
M2PFOA	Perfluoro-n-[1,2-13C2]octanoic acid
MPFDA	Perfluoro-n-[1,2-13C2]decanoic acid
MPFOS	Sodium perfluoro-1-[1,2,3,4-13C4]-octanesulfonate

Sample Custody



Chain of Custody Record

Enthalpy Ultratrace Job#: _____ COC Page _____ of _____

Special Handling:

- ☒ Standard Turn Around Time
- ☐ Rush Turn Around Time -- Date Needed _____
- All Fast TATs Subject to Approval by Enthalpy Analytical, Inc.
- All Samples Disposed of After 6 months Unless Otherwise Instructed.

Enthalpy Analytical-Wilmington, NC has added enhancements to standard methods to improve accuracy, precision and permit an assessment of laboratory performance in the context of your specific data needs. For more information email Cindy.James@enthalpy.com.

This Chain of Custody is applicable to Non-Air samples. Standard TAT differ per analysis and are provided by request.

Client Name: Browns ix County WATER
Project Manager: GLENN WALKER
Report To: JANE

Project Number: _____
Site Name: N.W. PLANT LAB
Location: LELAND

PO#: _____
Telephone#: _____
Email: _____

Client Special Instructions:

Matrix: GW-Groundwater, WW-Wastewater, NW-Non-Potable Water, DW-Drinking Water, S-Soil, SL-Sludge, BT-Biological Tissue, O-Other

Type: G=Grab C=Composite Q=Quality Control

[illegible]

Relinquished By:

Date:

Received By:

Date:

Time:

Sample Temperature Upon Receipt:

7-11-19

Heckler

7/11/19	12:19
---------	-------

☒ Iced ☐ Ambient °C 12 Tg

☐ Iced ☐ Ambient °C☐ Iced ☐ Ambient °C

2714 Exchange Drive • Wilmington, NC 28405 • (910) 212-5858 • www.enthalpy.com

1 Cooper by courier on Ice good condition no seals HA 7/11/19

**This Is The Last Page
Of This Report.**